



# LX3V-1WT

## User manual<sub>v3.1</sub>



Website: <http://www.we-con.com.cn/en>

Technical Support: [liux@we-con.com.cn](mailto:liux@we-con.com.cn)

Skype: “fcwkkj” or “Jason.chen842”

Phone: 86-591-87868869

QQ Group: 465230233

Technical forum: <http://wecon.freeforums.net/>



# 1. Weighing module Operating principle

Electrical resistance of metal material changes in proportion to the forces being applied to deform it. The strain gauge measures the deformation as a change in electrical resistance, which is a measure of the strain and hence the applied forces (load).

## 2. Introduction

- 1) WECON LX3V-1WT<sub>v3</sub> expansion module's resolution is 24-bit. The module can be used for reading signals from 4- or 6- wire configuration;
- 2) Please read through the manual before powering on the module.
- 3) This manual is only applicable for model number: LX3V-1WT<sub>v3</sub>. Please double check the mark on your module.
- 4) Using FROM/TO command to read/write data on PLC LX3V.

### 2.1 Specification

Table 2- 1

Item	Description
Channel	Signal channel
A/D converter	24 bit $\Delta\Sigma$ A/D
Resolution	24bit (signed)
Speed	7.5/10/25/50/60/150/300Hz available
Polarity	Unipolar and bipolar
Non-linearity	$\leq 0.01\%$ full scale(25°C)
Zero drift	$\leq 0.2\mu\text{V}/^\circ\text{C}$
Gain drift	$\leq 10\text{ppm}/^\circ\text{C}$
Excitation Voltage/ load	5V, load impedance $\geq 200\Omega$
Sensor sensitivity	1mV/V-15mV/V
Isolation	Transformer (power supply) and the optical coupler (signal)
Lamp	Power supply lamp, communication lamp
Power supply	24V $\pm 20\%$ 2VA
Operating temperature	0~60°C

Storage temperature	-20~80 °C
Dimension	90(L)x58(W)x80(H) mm

## 2.2 Valid bits

Refer to sampling frequency in Section 5.2, Chapter 5 of this manual.

## 3. Dimensions




Figure 3-1

- |                                     |                                 |
|-------------------------------------|---------------------------------|
| ① Extension cable and connector     | ⑥ Analog signal output terminal |
| ② LED COMM: lit when communicating  | ⑦ Extension module interface    |
| ③ Power LED: Lit when power present | ⑧ DIN rail mounting slot        |
| ④ State LED: Lit when normal        | ⑨ DIN rail hook                 |
| ⑤ Module number                     | ⑩ Mounting holes (φ4.5)         |




Figure 3-2


- Use the crimp terminals that meet the dimensional requirements showed in the left figure.
- Apply 0.5 to 0.8 N.m (5 to 8 kgf.cm) torque to tighten the terminals against disoperation.

### 3.1 Terminals instruction

Table 3- 1

Terminals	Instruction
24V+	Power supply+
24V-	Power supply-
GND	Grounding
FG1	Sensor grounding
E1-	Power supply- (5V) for sensor
E1+	Power supply+ (5V) for sensor
S1-	Signal output – of sensor
S1+	Signal output + of sensor
F1-	Feedback – of sensor
F1+	Feedback + of sensor
●	

### 4. Wiring



**Note:**

- 1) Impedance of the weighing sensor is greater than 50 Ω.
- 2) Sensors with 4 wires need to have E1+ and F1+ connected, E1- and F1- connected.

### 5. BFM instruction

## 5.1 BFM list

Table 5- 1

BFM	Latched	Read/Write	Function	Default	Range	Description
0	O	R	Model	5011		LX3V-1WT model number
1	O	R	System version	15004		Software & hardware version
2	O	R/W	Unipolar/ Bipolar	0	0-1	0: bipolar 1: unipolar
3	O	R/W	Frequency	1	0-9	0: 7.55 Hz;      5: 150 Hz; 1: 10 HZ;        6: 300 Hz; 2: 25 Hz;        7: 600 Hz; 3: 50 Hz;        8: 960 Hz; 4: 60 Hz;        9: 2400 Hz;
4	X	R	State	0		b0: CH1 no-load; b1: Reserved; b2: CH1 overload; b3: Reserved; b4: CH1 measured value is stable; b5-b15: Reserved;
5	X	R	Error Code	0		0: No error; 1: Error; b0: Power supply error b1: Hardware error b2: CH1 conversion error b4:CH1 write calibration parameter error Others: Reserved
6	X	R/W	Tare weight Preset	0		Use average weight as tare weight: 0: Disabled 1: Set tare weight then reset to 0;
7	O	R/W	Gross/Net weight	0		Display gross weight or net weight 0: CH1 gross weight;

						1: CH1 net weight; Others: CH1 invalid;
8	X	R/W	Weight Calibration	0		<p>The adjustment is to make the module match the weight value of the load cell of the weighing module. The default value is 0.</p> <p>0x0001: CH1 reset command 0x0002: CH1 weight base point command 0x0003: CH1 calibration command without weight 0x0004: CH1 modify calibration parameter command</p> <p>User adjustment steps: (indicated by CH1)</p> <p>There is a weight calibration:</p> <p>Step1: Do not put any weight on the load cell; Step2: The value of #8 is written as 0x0001; Step3: Add standard weights to the load cell; Step4: Write the weight of the current weight on the chassis #twenty three; Step5: The value of #8 is written as 0x0002.</p> <p>Calibration without weight:</p> <p>Step1: Do not put any weight on the load cell; Step2: Write the maximum range of the sensor to #23; Step3: Write the sensor sensitivity to #39, accurate to three decimal places;</p>

						<p>Step4: The value of #8 is written as 0x0003.</p> <p>Modify calibration parameters:</p> <p>Step1: Modify the calibration parameter values in BFM#35~BFM#38;</p> <p>Step2: The value of #8 is written as 0x0004.</p> <p>Remark: After writing the value to BFM#8 using the device monitoring, it will be automatically reset to 0.</p>
9	X	R/W	Reset to default	0	1:reset	Reset all BFM values to default
10	O	R/W	Filtering mode	0	0-1	Recalibration required after change
11	O	R/W	Filtering strength	3	0-7	Recalibration required after change
12	O	R/W	No Load Zero tracking intensity	0	0-20000	0: zero tracking disabled Other: intensity of zero tracking
13	O	R/W	No Load Zero tracking range	0	0-300	0: no limit Others: up limit
14	O	R/W	No load Zeroing at startup	0	0-4	0: Disabled; 1: ±2%MAX; 2: ±5%MAX; 3: ±10%MAX; 4: ±20%MAX;
15	X	R/W	Sensor sensitivity setting (inside the module)	4	0-5	0: < 1V/V 1: < 125mV/V 2: < 62.5mV/V 3: < 31.25V/V 4: < 15.625mV/V 5: < 7.812 mV/V Note: Please recalibrate after setting <b>(This function only is</b>

						available in Software & hardware version 13904 or later)
16	X	R	CH1 average weight L	0	Signed 32-bit integer	Average weight of CH1 (Low word)
17			CH1 average weight H			Average weight of CH1 (High word)
18	O	R/W	CH1 sliding average	5	1-50	Setting range: K1~K50; settings outside of this range will be changed to the nearest value in the range.
19	O	R/W	CH1 tare weight	0		User can write or read tare weight by command #7 Range: K-2147483648~2147483647 Default value: K0
20						
21	O	R/W	CH1 standstill checking times	200	0-20000	Stability inspection time, used in conjunction with the stability inspection range, unit: ms
22	O	R/W	CH1 checking range	10	1-10000	Example: checking time: 10ms, standstill checking times: 10, checking range: 1000, when variation is greater than 1000, this measured value is not stable, and BMF #4-b4 will be 0. If not BMF#4-b4 will be 1.
23	O	R/W	CH1 weight value adjustment (weight basis point weight, sensor range (weight))	1000	-2147483648~2147483647	See #8
24	O					
25	O	R/W	CH1 maximum	32767	-2147483648~2147483647	User can set the max value, it will record the error code when measured value
26	O	R/W				



					47	exceed set value
27	0	R/W	CH1 zero weight detection up limit	10	-2147483648~2147483647	Zero weight detection function, used to tell if all loads have been removed. Reading of the bit to indicate stable reading becoming 0 means all loads have been removed.
28	0	R/W				
29	0	R/W	CH1 zero weight detection down limit	-10	-2147483648~2147483647	stable reading becoming 0 means all loads have been removed.
30	0	R/W				
31	X	R/W	Additional function options	0	0~1	0: Default, disable additional functions; 1: Enable filter reset function. Other: Reserved <b>(This function only is available in Software &amp; hardware version 13904 or later)</b>
32	X	R/W	Additional function parameters	0	0~100	Enable filter reset function: 0: Default; 0~100: The number of sampling cycles to wait for the filter to restart. The value collected during the accumulation of the average, as the initial value of filtering <b>(This function only is available in Software &amp; hardware version 13904 or later)</b>
33	X	R	Digital value L	0	-	Digital quantity collected by ADC
34	X	R	Digital value H			
35	0	R/W	Calibration parameter A	1	-3.402823E+38~3.402823E+38	Explain by CH1: After modifying the calibration parameters, #8 does not write 4, which is only displayed, not used for
36	0	R/W				
37	0	R/W	Calibration parameter B	0	-3.402823E+38~3.402823E+38	
38	0	R/W				

					2823E+38	weight value calculation, and will not be saved after power off; #8 After writing 4, if the parameter range is correct, write and save it for weight value calculation, # 4 Error code Bit4 is set to 0, if the parameter range is wrong, no write operation will be performed, #4 error code Bit4 is set to 1.
39	0	R/W	Sensor sensitivity (specification)	0	0~32767	The default setting of 2000 represents 2mV/V, and calibration without weights needs to set the sensor sensitivity accuracy. The sensitivity range can be set to 0~32.767mV/V, the sensor sensitivity BFM#39 enters a negative value, and it is directly converted to 32767 for execution. Example: Modified to 1942 means 1.942mV/V.
40	X	R/W	Sensor feedback voltage L		--	Write: 0: do not display 1: Real-time display of current sensor feedback voltage 2: Display the zero point voltage during calibration 3: Display the voltage of the weight applied during calibration Read: Display the low digit of the voltage value in uV.
41	X	R	Sensor feedback		--	Read:

			voltage H			Display the high digit of the voltage value in uV.
--	--	--	-----------	--	--	--

**Note:**

- 1) O: yes;
- 2) X: no;
- 3) R: read;
- 4) W: write;

## 5.2 Buffer (BFM) description

### 1) BFM0: Module code

LX3V-1WT<sub>v3</sub> code: 5011

### 2) BFM1: module version

Module version (decimal)

**Example**

BFM1=116, means V1.1.6

### 3) BFM2: Polarity

For bipolar, the signal will go through zero while it is in changing process, but unipolar will not. The result of the conversion from analog value to digital value is signed, so for bipolar signal the value could be minus.

### 4) BFM3: Sampling frequency

The frequency of input signal reading, the lower the frequency is, the more stable the value it gets, and the higher the precision is, but the lower speed gets.

Table 5- 2

Setting	Sample frequency (HZ)	Sample precision (Bits)	Setting	Sample frequency (HZ)	Sample precision (Bits)
0	7.5	23.5	5	150	21.5
1	10	23.5	6	300	21
2	25	23	7	600	20.5
3	50	22	8	960	20
4	60	22	9	2400	17.5

### 5) BFM4: State code

Table 5- 3

Bit No.	Description	
	1	0
Bit 0	CH1 no-load	CH1 load
Bit 2	CH1 over-load	CH1 not over-load
Bit 4	CH1 stable	CH1 unstable
Bit 6	CH1 uncalibrated/calibrated error	CH1 calibration successful
Bit 8	00: no error	01: No-load calibration
Bit 9	10: The base point of the weight is too heavy	11: Not calibrated
Bit 12	CH1 exceeds the sensor range Note: Determined by sensor feedback voltage	CH1 within the sensor range
Bit 14	CH1 Enter calibration without weight	CH1 has not entered the calibration without weight
Other Bit	Reserved	

## 6) BFM5: Error code

Table 5- 4

Bit No.	Value	Error	Bit No.	Value	Error
bit 0	K1(H0001)	Power failure	bit 1	K1(H0001)	Hardware failure
bit 2	K4(H0004)	CH1 conversion error	Other Bit		Reserved
Bit 4	K16(H0010)	CH1 write calibration parameter error			

Note: Data register used to store all error states.

## 7) BFM6: Tare weight setting

Set the current weight value (BFM16-17) as a tare (BFM19-20) weight. Every bit represents a different channel, which is set to 1 to mean enabled, reset to 0 after being set.

### For example

The current weight is 100, after setting tare weight;

If it displays gross weight (BFM7 = 0) currently, the tare weight (BFM19-20) will become 100, the current weight is still 100;

If it displays net weight (BFM7 = 1), the tare weight (BFM19-20) will be original value + current weight value, the current weight value becomes zero;

## 8) BFM11: filtering strength

The higher the filter strength is, the more stable and accurate the weight value is. But the delay

time will increase accordingly, and the sensitivity will decrease.

### 9) BFM12: zero tracking strength

Zero-tracking is to have a constant 0 when there's no load. Zero tracking intensity means the weight counts 0 when it's within the range to reduce the influence of temperature drift.

Table 5- 5

Setting	Description	Note
0	Zero tracking OFF	Default
1-200	Range of weight value	10 means $\pm 10$
Others	Reserved	
<b>Note:</b> This feature can be disabled when high precision is not required.		

### 10) BFM13:Range of Zero tracking

Accumulated range of zero tracking, stop tracking when out of range

Table 5- 6

Setting	Description	Note
0	Disable zero tracking	Default
1-300	Range of weight value	10 means $\pm 10$
Others	Reserved	
<b>Note:</b> This feature can be disabled when high precision is not required.		

#### Example

Setting value is 100, when the position within  $\pm 100$ , it will be read as no-load.

### 11) BFM15: Set AD chip gain

It can be set according to the sensor range

BFM15	Voltage range	Sensor sensitivity
0	$\pm 5V$	$< 1V/V$
1	$\pm 625mV$	$< 125mV/V$
2	$\pm 312.5 mV$	$< 62.5mV/V$
3	$\pm 156.2 mV$	$< 31.25V/V$
4	$\pm 78.125 mV$	$< 15.625mV/V$
5	$\pm 39.06 mV$	$< 7.812 mV/V$

## 5.3 Function Instructions

### 1) Net weight measurement

It can be set to measure net weight or gross weight. The Net weight means the weight of the product itself, that is, the actual weight of the product without its external packaging.

The weight of the packaging is called the tare weight. The gross weight is the total weight, namely the net weight plus the tare weight.

- Tare weight: weight of the packaging
- Net weight: the weight of the product, excluding the packaging.
- Gross weight: the net weight plus the tare of the product.
- Gross weight= net weight + tare weight.

**For example:** A product weighs 10kg and the carton contains it weighs 0.2kg, then its gross weight is 10.2 kg (net weight=10kg, tare weight=0.2kg, gross weight=10.2kg)

**Example:** Use the measured value at CH1 as the net weight. If you know the weight of the packaging already, you can skip the step of reading tare weight.

- Read the tare weight
  - Step 1: Write H0000 into BFM7.
  - Step 2: Place the packaging on the CH1 load cell.
  - Step 3: Write H0001 into BFM6 to take the weight of the packaging as the tare weight.
- Set BFM7 = H00F1.

### 2) Standstill check function

When an object is placed on the load cell to measure its weight, you can use the standstill check function to know whether the current reading has been stabilized.

- If the measured value shifts within the range (BFM 22) of standstill check set up by the user, BFM4'bit 4 will be set to "1".
- If the measured value shifts beyond the range for standstill check set up by the user, bit4 will be set to "0". They will be set to "1" again when the range is returned to the set range.

#### Example

The measuring time is 10ms, the times of standstill check is 10, and the range for standstill check is 1,000. When the range for standstill check exceeds 1,000, the reading is considered

unstable, i.e. BFM4'bit4 will be set to 0. When the measuring time is within 100ms ( $10 \times 10\text{ms}$ ) and the range returns to be within 1,000, BFM4'bit4 will be set to 1 again. We recommend you check if the measured value is stable enough before operating it.

### 3) Zero detection function

Users can use this function to know whether the object has been removed from the load cell. If the BFM4'bit4 is 1, and the BFM4'bit0 and bit1 are 1 as well, the object has been removed from the load cell already, and you can proceed to the next step.

### 4) Filtering

This setting is used to exclude noises from the readings, which are introduced by environmental factors.


## 6. Example

### 1) Current state of weight




Read the current state BFM4. More information, please refer to [5.2](#)

### 2) Get current weight value



Write average weight value (BFM16) to D0


### 3) Calibrating weight




\*In the new version, the step 1 can be used for manual reset.

Adjustment and calibration are to make sure the weight values of module and the heavy load units of module to be consistent.

#### 4) Tare weight and gross weight




#### 5) Filter method and strength



After setting the filtering mode and filtering strength, need to calibrate again.

#### 6) Zero tracking



Zero tracking is used to reduce the temperature drift interference;

Set Zero Tracking Intensity to 0 to disable tracking. Set Zero Tracking Range to 0 to make it is unlimited.


#### 7) Calibration without weights

Calibration without weights is performed by the zero point of the sensor and the maximum range of



the sensor. The accuracy is related to the sensor specifications and depends on the sensor sensitivity (mV/V).

Example: The sensitivity of LAB-B-B sensor is  $2.0 \pm 10\%$  mV/V, and there may be a maximum error of 10%, so it is best to use a sensor with a small sensor sensitivity error to use this function.



Step1: Write the sensor range in D8 to BFM23:


Example: measuring range 3kg, D8 value setting 3000

Step2: write the sensor sensitivity in D9 into BFM39:

Example: Sensitivity: 1.942mV/V, D9 value set to 1942;

Step3: write value K4 to BFM8 and confirm to write calibration parameters.

## 8) Modify calibration parameters



Step1: Write the floating point number in D10 into BFM35~BFM36;

Step2: Write the floating point number in D11 into BFM37~BFM38;

Step3: Write value K4 to BFM8 and confirm to write calibration parameters.

**Note:** BFM35, BFM36, BFM37, and BFM38 are real number types (float). Real numbers need to be input when inputting. If the input exceeds the range, BFM5 will report an error in writing calibration parameters.

## 7. Diagnosis

---

### 7.1 Check

- 1) Make sure all cables are connected properly;
- 2) Make sure all rules regarding LX3V expansion modules are met. Such as expansion modules other than digital inputs and outputs are no more than 8 in total. The total number of digital inputs and outputs are no greater than 256.
- 3) Make sure to select the correct operating range in application;
- 4) Make sure power supply is working properly;
- 5) LX3V CPU unit is in RUN mode;

### 7.2 Check the error

- If the special function module LX3V-1WT v3 does not operate normally, please check the following items.
  - Check the status of the LINK indicator
    - Flashing: The extension cable is connected correctly
    - Otherwise: Check the connection of the extension cable.
- Check the status of the "24V" LED indicator (upper right corner of LX3V-1WT v3)
  - Lit: LX3V-1WT v3 is normal, and the 24VDC power supply is normal.
  - Otherwise: the 24V DC power supply may be faulty. If the power supply is normal, it is LX3V-1WT v3 fault.
- Check the status of the "COM" LED indicator (upper right corner of LX3V-1WT v3)
  - Flashing: Value conversion is operating normally.
  - Otherwise: check buffer memory #5 (error status).
  - If any bit (b0, b1, b2) is ON, that is why the COM indicator is off. Detailed description
  - Please refer to "(6) BFM5: Error Code" in "5.2 Buffer Register (BFM) Description" in "Chapter 5" of this manual.
- Check the sensor and measure whether the voltage between S+ and S- is less than (5\*sensor sensitivity) mv. The sensitivity of the sensor can be found on the sensor manual, and the unit is (mv/v). If the voltage at this point exceeds the range, it means the sensor Deformation or wiring error occurred. Measure whether the voltage between F+ and F- is 5V. If it is not 5V, check the sensor wiring.

Version: V3.1

Date: Sep 2021