Preface

This user manual is applicable to Wecon VD3E series bus servo drives.

In order to use this series of servo drives correctly, please read this manual carefully in advance and save it for later use.


During use, if you have any doubt about the function and performance of this equipment, please contact our technicians for relevant assistance to use this equipment smoothly.

The company's products are constantly being improved and upgraded, and the contents of this manual are subject to change without notice.

This manual is suitable for introductory and use reference books for elementary and intermediate readers. At the same time, all interpretation rights of this manual belong to our company.



The danger caused by failure to operate as required may result in serious injuries or even death.



The danger caused by failure to operate as required may result in moderate or minor injuries, and equipment damage.

User Manual Change Record

Date	Changed version	Changed content	Applicable models
October 2022	V1.0	First edition	★ VD3E-0□□SA1G model
August 2023	V2.0	Chapter 7: Add the supplementary explanation of touch probe function and DI touch probe function; Add homing mode 35, and add 60E6 to set absolute coordinates and relative coordinate modes; Chapter 8: Add 60E0, 60C5h and 60C6h object dictionaries; Delete 6071, 6074, 607D: 01 object dictionaries; Modify the data range and default value of some object dictionaries; U0-57 is added to support 64-bit absolute position display; Add U0-48 servo power-on counting description, U0-52 encoder bit monitoring value; Update the object dictionary table and add 6000 groups of data format standard device sub-protocol areas; Add 2001-17, 2000-18, 2000-1F and other object dictionaries; Add JOG acceleration time 2001-25 and JOG deceleration time 2001-25; Add 2004-12 speed feedback filter time; Add 2004-05 motor model and 200A-07 manual motor code; Speed feedforward filtering time P2-10 default value and range unit changed; Torque limit source P1-14 added: EtherCAT control; Chapter 10: Add Er.43 drive overload fault and A-80 power limit alarm; Er.27 [Encoder disconnected] changed to be unclearable. Modify the fault logic and troubleshooting method of A-91; Add temporary solutions to A-93; Chapter 11: Add the hardware requirements of European EMC certification standard; Add EMC input noise filter recommendation; Add cable and wiring requirements, etc.	★VD3E-0□□SA1G model
July 2024	V2.1	Add the main circuit terminal description of VD3E	★ VD3E-0□□TA1G model

		type B drive (380V);	
		Add the main circuit terminals schematic diagram	
		of VD3E type B drive (380V);	
		Add three-phase 380V main circuit wiring of VD3E	
		type B drive;	
		Add the example of encoder line connection	
		between power wiring servo drive and servo	
		motor;	
		Chapter 5	
		Add description of VD3E quick stop status panel	
		display;	
		Chapter 6	
		Add description of the PDO maximum added	
		quantity;	
		Chapter 7	
		Add Cyclic Synchronous Velocity mode (CSV);	
		Add Cyclic Synchronous Torque mode (CST);	
		Add profile torque mode (PT);	
		Chapter 8	
		Add 2000-20, 2001-09, 2001-11, 2001-12 and	
		other object dictionaries;	
		Add 2002-07, 2002-08, 2002-10, 2002-14, 2002-15,	
		2002-16, 2002-17, 2002-18 and 2002-19 and other	
		object dictionaries;	
		Add 200A-04, 200A-0B and other object	
		dictionaries;	
		Add 6065, 6071, 60B2, 60F4, 60FD and other	
		object dictionaries;	
		Chapter 9	
		Add model tracking control function;	
		Add gain switching function;	
		Chapter 10	
		Add drive stalled and over-temperature	
		protection fault;	
		Chapter 1	
		Add 1.7 Leakage protection description and	
		circuit-breaker recommendation	
		Chapter 2	
		2.1.3 (2) Basic specifications	
		Chapter 3	
		3.1.3 Installation environment	
October		3.2.3 Installation environment	★ VD3E-0□□SA1G model
2024	V3.1	Chapter 8	★ VD3E-0□□TA1G model
		Add object dictionaries such as 605B, 605C, 605E,	Y ADSE-OFFICIATO MODEL
		60FF, and 6502;	
		Add historical maximum values of bus voltage	
		201E-41 and 201E-42 average	
		historical maximum values of power;	
		Modify 6040 and 605A object ordinary	
		Modify 2002-01 default value	
		Chapter 10	

		10.2 Add Er.19 Software overcurrent	
February 2025	V3.2	Chapter 7 7 7.8.3 Delete [60E6] Position calculation method, object dictionary. Chapter 8 8.3 Add [P06-34] Forced DO output; [P05-23], [P05-24] Probe filter time constant; [P05-25], [P05-26] Probe on/off compensation time; Monitoring quantity [U2-12] [U2-13] [U2-14] [U2-15] [U2-16]; [P01-20] Software overcurrent detection window; [P10-06] Multi-turn absolute encoder reset, range modification 8.4 Add [60FE] Digital output object dictionary.	★ VD3E-0□□SA1G model ★ VD3E-0□□TA1G model

Content

Chapte	er 1 Safety Reminder1	
1.	1 Safety Precautions	1
1.	2 Precautions for Storage and Transportation	3
1.	3 Precautions During Installation	3
1.	4 Precautions During Wiring	5
1.	5 Precautions During Operation	5
1.	.6 Precautions During Maintenance and Inspection	6
Chapte	er 2 Product Information9	
2.	1 Servo Drives	9
	2.1.1 Servo Drive Model Naming	9
	2.1.2 The Composition of Servo Drive	10
	2.1.3 Specification of Servo Drive	11
2.	2 Servo Motors	15
	2.2.1 Servo Motor Model Naming	15
	2.2.2 Composition of Servo Motor	16
	2.2.3 Specification of Servo Motor	17
2.	3 Servo System Wiring Diagram	18
Chapte	er 3 Installation of Servo Drive and Motor19	1
3.	1 Installation of Servo Drive	.19
	3.1.1 Dimensions (Unit: mm)	.19
	3.1.2 Installation Site	19
	3.1.3 Installation Environment	20
	3.1.4 Installation Precautions	20
3.	2 Installation of Servo Motor	23
	3.2.1 Dimensions (unit: mm)	23
	3.2.2 Installation Site	25
	3.2.3 Installation Environment	26
	3.2.4 Installation Precautions	27
Chapte	er 4 Wiring28	
4.	1 Main Circuit Wiring	28
	4.1.1 Main Circuit Terminals	.28
	4.1.2 Power Wiring Example	30

4.1.3 Precautions for Main Circuit Wiring	33
4.2 Power Line Connection of Servo Drive and Servo Motor	35
4.2.1 Power Cable	35
4.2.2 Brake Device Cable	36
4.3 Encoder Cable Connection of Servo Drive and Servo Motor	37
4.4 Servo Drive Control Input and Output Terminal Wiring	42
4.4.1 CN2 Pin Distribution	42
4.4.2 Digital Input and Output Signals	42
4.4.3 Brake Wiring	46
4.5 Communication Signal Wiring	47
Chapter 5 Panel Composition	48
5.1 Panel Composition	48
5.2 Panel Display	48
5.2.1 Display Switching	50
5.2.2 Status Display	50
5.2.3 Parameter Display	52
5.2.4 Fault Display	54
5.2.5 Monitor Display	55
5.3 Panel Operation	56
5.3.1 Parameter Setting	56
5.3.2 Jog Operation	57
5.3.3 Factory Reset	58
Chapter 6 Communication Network Configuration	60
6.1 EtherCAT Operation	60
6.2 EtherCAT Communication Fundamentals	61
6.2.1 EtherCAT Communication Specification	61
6.2.2 Communication Structure	61
6.2.3 State Machines	62
6.2.4 Communication Indicator Lamp	63
6.2.5 Process Data PDO	63
6.2.6 Email Data SDO	66
6.2.7 Distributed Clock	67
6.2.8 Status Indication	67

6.2.9 Introduction to CiA402 Control	71
6.2.10 Basic Characteristics	73
Chapter 7 Operation Running	75
7.1 Basic Settings	75
7.1.1 Pre-operation Inspection	75
7.1.2 Power on	75
7.1.3 Jog Operation	76
7.1.4 Rotation Direction Selection	76
7.1.5 Braking Resistance	77
7.1.6 Servo Operation	78
7.1.7 Servo Stop	78
7.1.8 Brake Holding Device	82
7.2 Servo State Setting	88
7.2.1 Control Word	89
7.2.2 Status Word	90
7.3 Servo Mode Settings	92
7.3.1 Servo Mode Introduction	92
7.3.2 Mode Switching	92
7.3.3 Communication Cycles Supported by Different Modes	93
7.4 Cyclic Synchronous Position Mode (CSP)	93
7.4.1 Control Block Diagram	93
7.4.2 Related Objects	95
7.4.3 Related Function Settings	96
7.4.4 Recommended Configuration	96
7.5 Homing Mode (HM)	97
7.5.1 Control Block Diagram	104
7.5.2 Related Objects	105
7.5.3 Related Function Settings错误	! 未定义书签。
7.5.4 Introduction of Zero Return Mode	106
Chapter 8 Object Dictionary	162
8.1 Overview of Object Dictionaries	162
8.1.1 Object Dictionary Area Allocation	162
8.1.2 Explanation of Related Terms in Object Dictionary	162

8.2 Communication Sub-protocol Area (1000h to 1FFFh)	164
8.3 Vendor Customized Area (2000h to 2FFFh)	172
Group 2000h: Basic Settings	172
Group 2001h: Control Parameters	176
Group 2002h: Gain Adjustment	180
Group 2003h: Self-adjusting Parameters	183
Group 2004h: Vibration Suppression	188
Group 2005h: Signal Input and Output	190
Group 2006h: DIDO Configuration	192
Group 200Ah: Auxiliary Function	197
Group 200Dh Communication Input and Output Terminal	199
Group 201Eh Universal Monitoring	202
201Fh Group: Warning Monitoring	211
2020h Group: Device Monitoring	215
8.4 Standard Equipment Sub-protocol Area (6000h to 6FFFh)	219
Chapter 9 Adjustments	236
9.1 Overview	236
9.2 Inertia identification	237
9.3 Gain Adjustment	239
9.3.1 Automatic Gain Adjustment	239
9.3.2 Manual Gain Adjustment	241
9.3.3 Feedforward Gain	244
9.4 Mechanical Resonance Suppression	245
9.4.1 Mechanical Resonance Suppression Methods	255
9.4.2 Notch Filter	256
Chapter 10 Malfunctions	259
10.1 Faults and Warnings Handling at Startup	259
10.2 Faults and Warnings Handling During Operation	259
10.2.1 Overview	259
10.2.2 Fault and Warning Code Table	261
10.2.3 Troubleshooting	264
10.2.3 Troubleshooting	

	Group 1000	298
	Group 2000	300
	Group 2001	300
	Group 2002	301
	Group 2003	301
	Group 2004	302
	Group 2005	303
	Group 2006	303
	Group 200A	304
	Group 200D	305
	DI/DO channel function definition	306
	Group 201E	308
	Group 201F	310
	Group 2020	311
	Group 6000	312
11.2	List of Fault and Warning Codes	315
11.3	Wire	318
11 4	Correspondence of international standards	221

Chapter 1 Safety

1.1 Safety Precautions

This section describes the important items that users must observe, such as product confirmation, storage, transportation, installation, wiring, operation, inspection, and disposal. Please follow the steps required by this manual for trial operation.



- ◆After the power is turned off for more than 5 minutes and the power indicator is off, use a multimeter to confirm that the voltage across the high-voltage capacitor has dropped to a safe voltage, and then proceed with the disassembly and assembly of the drive, otherwise the residual voltage may cause electric shock.
- ◆ Please never touch the inside of the servo drive, otherwise it may cause electric shock.
- ◆ Please insulate the connection part of the power terminal, otherwise it may cause electric shock.
- ◆The grounding terminal of the servo drive must be grounded, otherwise it may cause electric shock.
- ◆Please install the servo drive, servo motor, and external braking resistor on non-combustible materials, otherwise it may cause a fire.
- ◆ Be sure to connect an electromagnetic contactor and a non-fuse circuit breaker between the power supply and the main circuit power supply of the servo drive.

 Otherwise, when the equipment fails, it may cause fire because it cannot cut off the large current.
- ◆In the servo drive and servo motor, please do not mix with oil, grease and other flammable foreign objects and screws, metal pieces and other conductive foreign objects, otherwise it may cause a fire.
- ◆ When the servo motor is connected to the machine, in case of any error in operation, it will not only cause damage to the machine, but also sometimes cause personal safety accidents.
- ◆ Do not damage or pull the cable forcefully, do not impose excessive force on the cable, or place heavy objects underneath, otherwise electric shock may occur, causing

the product to stop operating or burn out.

- ◆Do not use the brake of the brake motor for normal braking, otherwise it may cause a malfunction.
- ◆ Except for the designated operator, please do not set up, disassemble and repair the equipment, otherwise it may cause electric shock or injury.
- ◆ Do not remove the cover, cables, connectors and optional accessories while the power is on, otherwise it may cause electric shock.
- ◆ Please install a stop device on the machine side to ensure safety.
- ◆Please take measures to ensure that your personal safety will not be endangered when restarting, otherwise it may cause injury.
- ◆ Do not modify this product, otherwise it may cause personal injury or mechanical damage.

1.2 Precautions for Storage and Transportation



Notice

Please keep and install the product in the following environment:

- **◆**Places without direct sunlight;
- ◆Places where the ambient temperature does not exceed product specifications;
- ◆ Places where the relative humidity does not exceed product specifications;
- ◆ Places where condensation will not occur due to rapid changes in temperature;
- ◆ Places free of corrosive gas and flammable gas;
- **◆**Places without combustible materials nearby;
- ◆Places with less dust, salt and metal powder;
- ◆ Places where there is no splash of water, oil, medicine, etc.;
- ◆ Places where vibration or shock will not affect the product (places that exceed product specifications);
- ◆Places that will not be exposed to radiation;

Storage or installation in environments other than the above may cause product failure or damage:

- ◆ Please use the correct method for handling according to the weight of the product;
- **◆** Do not hold the motor cable or motor shaft for transportation;
- ◆When operating the servo unit and servo motor, please pay attention to sharp parts such as the corners of the device.

1.3 Precautions During Installation



Notice

- ◆ Do not install this product in a p2lace free from water splashed or in an environment prone to corrosion;
- ◆ Please be sure to comply with the device installation direction, otherwise it may cause device failure;
- ◆When installing, please make sure to keep the specified distance between the servo drive and the inner surface of the electric cabinet and other machines, otherwise it may cause fire or device failure:

- ◆ Do not apply excessive impact, otherwise it may cause equipment failure;
- ◆Do not sit on the product or place heavy objects on it, otherwise it may cause personal injury;
- ◆Do not use this product near flammable gases and combustibles, otherwise there may be a risk of electric shock or fire;
- ◆Do not block the suction and exhaust ports, and do not allow foreign objects to enter the product, otherwise it may cause device failure or fire due to the aging of internal components.

1.4 Precautions During Wiring



Notice


- ◆ Do not connect the three-phase power supply to the output terminals U, V, W of the servo drive, otherwise it may damage the device or cause a fire;
- ◆Please connect the output U, V, W of the servo drive and the U, V, W of the servo motor directly. Do not use the electromagnetic contactor during the connection, otherwise it may cause abnormal operation or malfunction of the device;
- ◆When the DO output terminals are connected to the relay, please pay attention to the polarity of the freewheeling diode, otherwise the drive may be damaged and the signal can not be output normally;
- ◆Please fix the power terminal and the motor terminal firmly, otherwise it may cause a fire hazard;
- ◆Do not connect the 220V servo unit directly to the 380V power supply;
- ◆Do not pass the power line and signal line through the same pipe or bundle them together. When wiring, the power line and signal line should be placed at an interval of more than 30cm;
- ◆Use twisted-pair shielded cables for signal cables and encoder cables, and the shielding layer should be grounded at both ends;
- ◆The wiring length of the signal input line is recommended to be within 3M, and the wiring length of the encoder is recommended to be within 15M;
- ♦ When using in the following places, please take adequate shielding measures.
 - When interference occurs due to static electricity.
 - Places where strong electric or magnetic fields are generated;
 - Places where there may be radiation;
- ◆When checking the status, please make sure that the CHARGE indicator is off.

1.5 Precautions During Operation



Notice

- ◆ During trial operation, in order to prevent accidents, please run the servo motor without load (not connected to the drive shaft), otherwise it may cause injury.
- ◆When the servo motor is running, do not touch its rotating parts, otherwise it may cause injury.
- ◆Be sure to set the correct rotational inertia ratio, otherwise it may cause vibration.
- ♦ When it is installed on the supporting machine and starts to run, please set the user parameters in accordance with the machine in advance. If the operation is started without parameter setting, the machine may lose control or fail.
- ◆When installing on the supporting machinery and starting to run, please put the servo motor in a state where it can be stopped in an emergency at any time, otherwise you may get injured.
- ◆When using a servo motor on a vertical axis, please install a safety device to prevent the workpiece from falling under states such as alarm and overrun. In addition, please perform servo lock stop setting when overrun occurs, otherwise the workpiece may fall in overrun status.
- ◆Since extreme user parameter adjustments and setting changes will cause the servo system to become unstable, please never make settings, otherwise it may cause injury.
- ◆When an alarm occurs, reset the alarm after removing the cause and ensuring safety, and restart the operation, otherwise it may cause injury.
- ◆ Except for special purposes, do not change the maximum speed threshold (P01-10). If user change it carelessly, it may damage the machine or cause injury.
- ♦ When the power is turned on and within a period of time after the power is cut off, the cooling fin of the servo drive, the external braking resistor, the servo motor, etc. may be exposed to high temperature. Please do not touch it, otherwise it may cause burns.
- ◆If the power supply is restored after an instantaneous power failure occurs during operation, the machine may restart suddenly, so please do not stay close to the machine, and press the stop button when the power is off, and operate after the power supply is stable.
- 1.6 Precautions During Maintenance and Inspection



- ◆The power on and off operations should be carried out by professional operators.
- ♦ When testing the insulation resistance of the drive, please cut off all the connections with the drive first, otherwise it may cause the drive to malfunction.
- ◆ Do not use gasoline, alcohol, acid and alkaline detergents to avoid discoloration or damage to the casing.
- ♦ When replacing the servo drive, please transfer the user parameters of the servo drive to be replaced to the new servo drive before restarting operation, otherwise the machine may be damaged.
- ◆ Do not change the wiring when the power is on, otherwise it may cause electric shock or injury.
- ◆Do not disassemble the servo motor, otherwise it may cause electric shock or injury.

1.7 Leakage protection and circuit breaker recommendations

Servo Drive			Recomm	ended ci	rcuit breaker	
Voltage level	Drive model	Rated input current IN(A)	Manufacturer	Current (A)	Model	
		VD3E-0xx	kSA1G	•		
	VD3E-003SA1G	0.9		2	OSMC32N2D2	
	VD3E-010SA1G	3.61	Schneider	6	OSMC32N2D6	
Single-phase	VD3E-014SA1G	6.76		16	OSMC32N2D16	
220V	VD3E-016SA1G	16.23		25	OSMC32N2D25	
	VD3E-021SA1G	19.84		32	OSMC32N2D32	
	VD3E-016SA1G	9.37		16	OSMC32N3D16	
	VD3E-021SA1G	11.46		20	OSMC32N3D20	
Three-phase 220V	VD3E-025SA1G	13.54		25	OSMC32N3D25	
	VD3E-030SA1G	15.62		25	OSMC32N3D25	
	VD3E-0xxTA1G					
Three-phase 380V	VD3E-021TA1G	9.04	Schneider	16	OSMC32N3D16	



If a residual current operated protective device(RCD) is to be used for device, please conform the following conditions for selection:

Drive device can generate DC leakage current in protective conductors, be sure to use B type Residual Current Action Protection Device(RCD);

When the driver is running, a certain high-frequency leakage current will be generated. In order to avoid RCD malfunctioning, select not less than 100 mA of operating current RCD for each drive;

When multiple drives are connected in parallel sharing oneRCD, the operating current should be selected not less than 300 mA of RCD;

Please do not change the wiring when the power is on, otherwise it may lead to electric shock or injury;

Recommend Chint and Schneider RCD.

Chapter 2 Product Information

2.1 Servo Drives

Figure 2-3

2.1.1 Servo Drive Model Naming




Figure 2-1 Servo drive model

Wecon VD3E series bus servo drive nameplate and appearance are shown in Figure 2-2 and

Figure 2-2 Type A servo drive nameplate and appearance




Figure 2-3 Type B servo drive nameplate and appearance

2.1.2 The Composition of Servo Drive




Figure 2-4 Composition of VD3E type A servo drive




Figure 2-5 Composition of VD3E type B servo drive

Remarks: When using external braking resistor or internal braking resistor, special short-circuit treatment is required, which is shown in Figure 2-6.




Figure 2-6 Short circuit schematic diagram of braking resistance

2.1.3 Specification of Servo Drive

(1) Electrical specification

Table 2-1 Electrical specification for single-phase 220V class servo drives

Item		VD3E Type A		VD3E Type B	
Model	VD3E-003SA1G	VD3E-010SA1G	VD3E-014SA1G	VD3E-016SA1G	VD3E-019SA1G
Maximum output	3A	10A	14A	16A	19A

Chapter 1 Safety reminder

current							
Control							
power		-		Single-phase A	AC 200V ~ 240V		
supply					50/60 Hz		
Power		Single pha	oco AC 200V to 240V E0/60 I	ш-,			
supply		Single-phase AC 200V to 240V 50/60 Hz					
Braking	Support ovtornal	Supp	ort built in and ovtornal	Support built i	in and external		
resistor	Support external	Supp	ort built-in and external	Support built-i	in and external		

Table 2-2 Electrical specification for type B servo drives

Item	VD3E Type B			
Model	VD3E-021SA1G	VD3E-025SA1G	VD3E-030SA1G	
Maximum output current	21A	25A	30A	
Control power supply	Single phaseAC198-242V, 50/60 Hz			
Power supply	Three phaseAC198-242V, 50/60 Hz			
Braking resistor	Support built-in and external connection			

Table 2-3 Electrical Specifications of Three-phase 380V Servo Drive

Project	VD3E Type T							
Model	VD3E-016TA1G VD3E-019TA1G VD3E-021TA1G							
Maximum output current	16A	19A	21A					
Control power supply	Sir	Single-phase AC 342 to 440V, 50/60Hz						
Power supply	Three-phase AC 342V to 440V, 50/60Hz							
Braking resistor	Support built-in and external connection							

(2) Basic specifications

Project			Description
		Temperatur e	0°C to 40°C
	Usage	Humidity	20% to 90%, no condensation
Environment		Shock	3M4, 3mm [2~9Hz], Class 1 area
		Vibration	3M4, 1G [9~200Hz], Class 1 area
	Storage	Temperatur e	-20°C to 65°C

		Humidity	20% to 90%, no condensation	
		Vibration	2M2, 3.5 mm [2~9Hz]	
	Protection level		IP20	
	Contamir	nation level	II	
	Overvol	tage level	III	
			The highest elevation reaches 2000m.	
			No derating is required for use at 1000m and below;	
	Ait	itude	Each rise above 1000m 100m derating 1%;	
			l Please contact the manufacturer for over 2000m.	
	Contro	l method	IGBT PWM control, sine wave current drive mode	
	Drive	model	VD3E-0xxSA1G	
Basic information	Encoder feedback		17bit absolute value encoder 23bit absolute value encoder	
	Operating temperature		0~45℃	
	Operatin	g humidity	Below 90% RH (no condensation)	
	Communication protocol		EtherCAT protocol	
	Support services		СоЕ	
	Synchronization mode		DC	
	Physic	cal layer	100BASE-TX	
Basic Performance of EtherCAT Slave Station	Bau	d rate	100Mbit/s	
	Duple	x mode	Full duplex	
	Topologic	al structure	Ring, linear	
	Slave stati	ion quantity	It is recommended that the actual networking use be lower than 128 units.	
	Synchror	nous jitters	1 μs	
	FMN	1U unit	8	
EtherCAT Configuration Unit	Storage synchronization snap-in		8	
Comiguration offit	Process	data RAM	8KB	
	Distributed clock		64-bit	
1			1	

Chapter 1 Safety reminder

	EEPROM capacity	32Kbit				
Input and output	Digital input (DI) signal	6-channel DI				
mparama saspar	Digital output signal	3-channel DO				

(3) Support function

Project		Description				
	Digital input (DI) signal	Servo enable (S-ON), fault and warning clear (A-CLR), forward drive disable (POT), reverse driveMovement prohibition (NOT), deviation counter cleared (CL), emergency shutdown (E-STOP), origin signal (HOMEORG)				
Input and output	Digital output signal	Servo Ready (RDY), Fault Signal (ALM), Speed Limit (V-LIMIT), Brake Output (BRK-OFF), Warning signal (WARN warning signal), servo on status output (SRV-ST), rotation detection (TGON), Correspondence VDO1 output (COM_VDO1), communication VDO2 output (COM_VDO2), communication VDO3Output (COM_VDO3), ZSP (zero speed signal), positioning complete (P-COIN), speed approaching (V-NEAR), Torque arrival (T-COIN).				
	Electronic gear ratio	The range is [0.001×Encoder Resolution/10000, 4000×Encoder Resolution/10000].				
Built-in function	Protective function	Overcurrent protection, overvoltage protection, undervoltage protection, overload protection, main circuit phase loss protection, overtemperature protection, parameter abnormality protection, encoder protection, others.				
	LED display function	Panel 5-bit LED				
	Others	Gain adjustment, fault and alarm recording, inching operation				

2.2 Servo Motors

2.2.1 Servo Motor Model Naming




Figure 2-7 Naming of servo motor




Figure 2-8 Servo motor nameplate

2.2.2 Composition of Servo Motor




Figure 2-9 Composition of 40/60/80 flange motor




Figure 2-10 Composition of 40/60/80 flange motor




Figure 2-11 Composition of 110/130 flange motor

2.2.3 Specification of Servo Motor

Table 2-4 Wecon motor specifications

Wecon motor model	Motor Code	Flange size	Rated power (kW)	Rated torque (N.m)	Voltage (V)	Rated speed (rpm)	Encoder type	Brake function
WE130M-10025S-A1F	A091	130	1.0	4.0	220	2500	17-bit single turn absolute magnetic	Not supported
WE130M-15025S-A1G	A111	130	1.5	6.0	220	2500	17-bit single turn absolute magnetic	Supported
WE130M-26025S-C1F	C191	130	2.6	10	220	2500	17-bit multi turn absolute magnetic	Not supported
WE80M-12030S-C1G	C231	80	1.2	4.0	220	3000	17-bit multi turn absolute magnetic	Supported
WE110M-18030S-D2G	D131	110	1.8	6.0	220	3000	23-bit multi turn absolute optical	Supported
WE130M-23015S-D2F	D161	130	2.3	15.0	220	1500	23-bit multi turn absolute optical	Not supported

Note: Only part of the motor models is displayed, please refer to [Model Selection Manual] for details.

2.3 Servo System Wiring Diagram




Figure 2-12 Wiring diagram of single-phase 220V servo drive system



- ① When using external brake, need to remove the shorting cap or short wiring between terminal C and D of servo drive before operating!
- 2 Pay attention to the power capacity of the brake power supply. When powering multiple brake devices at the same time, if the power supply capacity is insufficient, the brake will fail!
- 3 It is strictly forbidden to use electromagnetic brake for motor operation and stop operation!

 Otherwise, the instantaneous high voltage generated by the motor may break down the contactor!
- 4 In order to prevent cross-shock accidents in the servo system, please use a fuse or a circuit breaker for wiring on the input power supply!

Chapter 3 Installation of Servo Drive and Motor

3.1 Installation of Servo Drive

3.1.1 Dimensions (Unit: mm)




Figure 3-1 Installation Dimensions of VD3E Type A Servo Drive




Figure 3-2 Installation Dimensions of VD3E Type B Servo drive

3.1.2 Installation Site

- 1) Please install the device in an installation cabinet free from sunlight and rain;
- 2 In a place without vibration;
- ③Please do not install in the environment exposed to high temperature, humidity, dust and metal dust;
- (4) Do not use this product near corrosive and flammable gases such as hydrogen sulfide, chlorine, ammonia, sulfur, chlorinated gas, acid, alkali, salt or combustible materials.

3.1.3 Installation Environment

The installation environment of the servo drive has a direct impact on the normal function of it and its service life. Therefore, the installation environment of servo drive must meet the following conditions:

Project	Specifications
Ambient temperature	0°C~40°C (not freezing)
Ambient humidity	20%-90% RH (No condensation)
Storage temperature	-20℃-65℃
Storage humidity	20%-90% RH (No condensation)
Protection level	IP20
Contamination level	II
Overvoltage level	III
	The highest elevation reaches 2000m.
	No derating is required for use at 1000m and below;
Altitude	■ Each rise above 1000m100m derating1%;
	Please contact the manufacturer for over 2000m.
Vibration	Less than 0.5G (4.9m/s2), 10-60Hz
	(discontinuous operation)
Power Systems	TN system*

Note: The neutral point of the power system is directly connected to the ground, and the exposed metal objects are connected to the ground via protective ground conductors.

3.1.4 Installation Precautions

(1) Installation specifications

In order to achieve a good cooling cycle effect, ensure that there is enough ventilation space around it when installing the servo drive, and be sure to comply with the installation standards in the control cabinet shown in the figure below, otherwise it may cause the drive to malfunction. See Figure for typical minimum installation dimensions 3-3.




Figure 3-3 Minimum mounting size

(2) Parallel installation

When multiple units are installed in parallel, the minimum distance between each other should be 20mm, and the distance between each other in vertical dimension should be at least 100mm. Please refer to Figure 3-4 and Figure 3-5 for details. To prevent temperature rise, a cooling fan can be placed on the upper part. For smaller spacing installation, please consult Wecon.




Figure 3-4 Parallel installation dimensions of multiple type A drives




Figure 3-5 Parallel installation dimensions of multiple type B drives

(3) Installation direction

When installing the servo drive, face the front (panel interface) of the servo drive to the operator so that the servo drive is perpendicular to the wall.

3.2 Installation of Servo Motor

3.2.1 Dimensions (unit: mm)

(1) Installation dimensions of WD series 40 flange servo motor

Specification	WD series 40 flange motor
Rated torque (N.m)	0.318
LA without brake (mm)	74.8
LA with brake (mm)	108

Figure 3-6 WD series 40 flange servo motor installation dimension drawing

(2) Installation dimensions of 60 flange servo motor

1 WD series motor

Specification	WD series 60 flange motor			
Rated torque (N.m)	0.64	1.27		
LA without brake (mm)	75	92		
LA with brake (mm)	104.5	121.5		




Figure 3-7 Installation dimension drawing of WD series 60 flange servo motor

2WE series motor

Specification	WE series 80 flange motor			
Rated torque (N.m)	3.5	4.0		
LA without brake (mm)	179	191		
LA with brake (mm)	221	233		




Figure 3-8 Installation dimension drawing of WE series 80 flange servo motor

(4) Installation dimensions of WE series 110 flange servo motor

Specification	WE series 110 flange motor				
Rated torque (N.m)	4	5	6		
LA without brake (mm)	189	204	219		
LA with brake (mm)	254	269	284		




Figure 3-10 Installation dimensions of WE series 110 flange servo motor

(5) Installation dimensions of WE series 130 flange servo motor

Specification	WE series 130 flange motor							
Rated torque (N.m)	4	5	6	7.7	10		15	
Rateu torque (N.III)	7				1500rpm	2500rpm	1500rpm	2500rpm
LA without brake (mm)	166	171	179	192	213	209	241	231
LA with brake (mm)	226	231	239	252	276	276	304	294




Figure 3-11 Installation dimension drawing of WE series 130 flange servo motor

3.2.2 Installation Site

- 1. Do not use the motor near corrosive, flammable gas environment, combustible materials such as hydrogen sulfide, chlorine, ammonia, sulfur, chlorinated gas, acid, base, salt, etc.
- 2. Do not remove the oil seal in places where there is grinding fluid, oil mist, iron powder, cutting, etc.

- 3. Do not use the motor in a closed environment. Closed environment will cause high temperature of the motor and shorten the service life.
- 4. A place far away from heat sources such as stoves.

3.2.3 Installation Environment

The installation environment of the servo motor has a direct impact on the normal function of it and its service life. Therefore, the installation environment of the servo motor must meet the following conditions:

Project	Specification
Ambient temperature	-10℃ to 40℃ (no freezing)
Ambient humidity	-20% to 90%RH (no condensation)
Storage temperature	-20℃ to 60℃
Storage humidity	-20%~90%RH (no condensation)
Protection level	IP65
Vibration	Less than 0.5G (4.9m/s2), 10~60Hz (non-continuous operation)

3.2.4 Installation Precautions

Project	Specification
Rust inhibitor	Before installation, please wipe clean the "anti-rust agent" on the shaft extension end of the
	servo motor, and then do the relevant anti-rust treatment.
	When installing a pulley on a servo motor shaft with a keyway, use a screw hole at the
	shaft end. In order to install the pulley, first insert the double-headed nail into the screw hole
	of the shaft, use a washer on the surface of the coupling end, and gradually lock the pulley
	into the pulley with a nut;
Encoder	Secondary For the servo motor shaft with keyway, use the screw hole on the shaft end to install;
notice	Secondary For shafts without keyway, adopt friction coupling or similar methods
	When removing the pulley, use a pulley remover to prevent the bearing from being
	strongly impacted by the load;
	Solution To ensure safety, install a protective cover or similar device in the rotating area, such as a solution and the safety install a protective cover or similar device in the rotating area, such as a solution and the safety install a protective cover or similar device in the rotating area, such as a solution and the safety install a protective cover or similar device in the rotating area.
	pulley installed on the shaft.
Centering	When linking with the machine, please use the coupling, and keep the axis of the servo motor
	and the axis of the machine in a straight line.
Installation	
direction	The servo motor can be installed horizontally or vertically.
	When using in a place with dripping water, please use it after confirming the protection level
Oil and water countermeasures	of the servo motor. When using it in a place where oil drips on the shaft penetration part, do
	not remove the oil seal of the servo motor.
	The use conditions of the servo motor with oil seal:
	When using, please make sure the oil level is lower than the lip of the oil seal;
	The oil seal can be used in a state with a good degree of splashing of oil foam;
	When the servo motor is installed vertically upwards, please be careful not to accumulate
	oil on the oil seal lip.
Stress condition	Do not "bend" the wire or apply "tension" to it, especially the signal wire whose core
of the cable	diameter is 0.2mm or 0.3mm. During the wiring process, please do not make it too tight.
or the cable	
Processing of the	Regarding the connector part, please note the following matters:
	When connecting the connector, please make sure that there is no foreign matter such as
	garbage or metal pieces in the connector;
	When connecting the connector to the servo motor, be sure to connect it from the side of
	the main circuit cable of the servo motor first, and the grounding of the main line cable must
_	be reliably connected. If you connect one side of the encoder cable first, the encoder may
connector part	malfunction due to the potential difference between PEs;
	When connecting, please make sure that the pin arrangement is correct;
	The connector is made of resin, please do not apply impact to avoid damage to the
	connector;
	Do not apply stress to the connector part during handling while the cable is connected. If
	stress is applied to the connector part, the connector may be damaged.

Chapter 4 Wiring

4.1 Main Circuit Wiring

4.1.1 Main Circuit Terminals

(1) Main circuit terminal distribution of VD3E type A servo drive




Figure 4-1 VD3E Type A Servo Drive Main Circuit Terminal Schematic

Table 4-1 Name and function of main circuit terminal of VD3E type A servo drive

Terminal number	Terminal name	Terminal function	
L1			
L2	Power input terminal	Single-phase 220V AC input is connected to L1 and L3.	
L3			
P+		Use internal braking resistor: short-circuited C-D.	
С	Braking resistor terminal	Use an external braking resistor: please disconnect the	
D		short wire between C-D, and then connect the external braking resistor between P+ and C;	
U		Connect with the LLV W of the meter to comply never to	
V	Motor power line terminal	Connect with the U, V, W of the motor to supply power to the motor.	
W		the motor.	
Ground terminal	Ground terminal	Grounding of the servo drive.	

(2) Main circuit terminal distribution of VD3E type B servo drive




Figure 4-2 Schematic Diagram of VD3E Type B Servo Drive Main Circuit Terminal

Table 4-2 Name and function of main circuit terminal of VD3E type B servo drive

Terminal number	Terminal name	Terminal function	
L1			
L2	Power input terminal	Single-phase 220V AC input is connected to L1 and L3. Three-phase 220V AC input is connected to L1, L2, L3;	
L3		Timee-phase 2200 Ac imput is connected to £1, £2, £3,	
L1C	Control power input	Single whose 220V AC insurt connected to 14C and 12C	
L1C	terminal	Single-phase 220V AC input connected to L1C and L2C	
P+		Use internal braking resistor: short connected C-D.	
С	Braking resistor terminal	Use an external braking resistor: please disconnect the short wire between C-D, and then connect the external	
D		braking resistor between P+ and C;	
U			
V	Motor power line terminal	Connect with the U, V, W of the motor to supply power to the motor.	
W		the motor.	
Ground terminal	Ground terminal	Grounding of the servo drive.	




Figure 4-3 Schematic diagram of main circuit terminals of VD3E Type B servo drive (380V)

Table 4-3 Names and Functions of Main Circuit Terminals of VD3E Type B Servo Drive (380V)

Terminal number	Terminal name	Terminal function
L1	Power input	
L2	terminal	Three-phase AC 380V input connect to L1, L2, L3
L3	· · · · · · · · · · · · · · · · · · ·	
L1C	Control power input	Single phase AC 200V input connected to L1C L2C
L1C	terminal	Single-phase AC 380V input connected to L1C, L2C
P+	5 1	Use internal brake resistors: Short circuit C-D.
С	Braking resistor terminal	Use external brake resistors: Please disconnect C-D short circuit wiring first, and then connect the
D		external brake resistor between P+ and C.
U	Motor nower line	
V	Motor power line terminal	Connect with the U, V, W of the motor to supply power to the motor.
W		poster to the motor
Ground terminal	Ground terminal	Grounding treatment of the servo drive

4.1.2 Power Wiring Example

(1) VD3E Type A Drive Single-phase 220V Main Circuit Wiring




Figure 4-4 VD3E Type A Drive Single-phase 220V Main Circuit Wiring

(2) VD3E Type B Drive Single-phase 220V Main Circuit Wiring




Figure 4-5 VD3E Type B Drive Single-phase 220V Main Circuit Wiring

(3) VD3E Type B Drive Three-phase 220V Main Circuit Wiring




Figure 4-6 VD3E Type B Drive Three-phase 220V Main Circuit Wiring

Figure 4-7 VD3E Type B Drive Three-phase 380V Main Circuit Wiring

4.1.3 Precautions for Main Circuit Wiring

- 1 The input power line cannot be connected to the output terminals U, V and W, otherwise the servo drive will be damaged. When using the built-in braking resistor, C and D must be connected (factory default connection).
- (2) When the cables are bundled and used in pipes, etc., due to the deterioration of heat dissipation conditions, please consider the allowable current reduction rate.
- (3) When the temperature in the cabinet is higher than the cable temperature limit, please choose a cable with a larger cable temperature limit, and it is recommended that the cable wire use Teflon wire. Please pay attention to the warmth of the cable in the low temperature

environment. Generally, the surface of the cable is prone to hardening and breakage under the low temperature environment.

4 The bending radius of the cable should be more than 10 times the outer diameter of the cable itself to prevent the core of the cable from breaking due to long-term bending.

4.2 Power Line Connection of Servo Drive and Servo Motor

4.2.1 Power Cable





Figure 4-8 Connection schematic diagram of servo drive and servo motor

Wecon VD3E series servo drives have 3 kinds of interface power cables: rectangular plug, aviation plug and in-line type.

Table 4-4 Power cable servo motor side connector

Connector exterior	Terminal pin distribution		Pin desc	ription	Adaptation Motor flange
		F	Rectangu	lar plug	
	4 _ 2	Pin number	Signal name	Color	
		1	U	Red	40
A		2	V	White	60
	3 1	3	W	Black	80
		4	PE	Yellow-green	
	•		Aviatio	n plug	
		Pin number	Signal name	Color	
		2	U	Red	110
		4	V	Yellow	110
		3	w	Blue	130
		1	PE	Yellow-green	

Chapter 4 Wiring



Note: The color of the lines is subject to the actual product. The lines described in this manual are all lines of Wecon.

4.2.2 Brake Device Cable

Connector shape and terminal pin distribution		Pin description		Adaptable motor flange
WD Series		Pin number 1 2	Signal name BR+ BR-	60 80
WE Series	2 3	Pin number 1 2 3	Signal name DC 24V GND -	80 110 130

4.3 Encoder Cable Connection of Servo Drive and Servo Motor




Figure 4-9 Encoder cable connection schema

Table 4-5 Encoder cable servo drive side connector

Connector exterior	Terminal pin distribution	Pin description
	5	Pin number Signal name 1 5V 2 GND 3 - 4 - 5 SD+ 6 SD-

Table 4-6 Absolute encoder cable connector (rectangular plug)

Connector shape and terminal pin distribution					Adapted motor Flange
Connect servo drive CN:	nector of encoder I-out cable	Encoder lea	d-out cable		
View from here	963 963 741	View from here		000 000 000	60 80
	Pin number	Signal name			
	8	5V GND			
	4	SD+			
	5	SD-			
	3	Shield			
	2	Battery+			
		Battery-			

Table 4-7 Encoder cable pin connection relationship

Drive side J1394			Motor side		
Pin number	Signal name	Description	Rectangular plug pin number	Cable color	
1	5V	Encoder +5v power	7	Blue	
2	GND	Encoder power ground	8	Orange	
5	SD+	Serial communication signal +	4	Green	
6	SD-	Serial communication signal -	5	Brown	
Shell	Shield	Shield	3	-	
-	-	Battery+	1*	Pink	
-	-	Battery-	2*	Pink-Black	

Note: The color of the cable is subject to the actual product. The cables described in this manual are all cables of Wecon!

Table 4-7 Absolute value encoder cable connector (aviation plug)

	Connector shape and termi	nal pin distribution	Adapted motor Flange
Connect servo drive	Connector of encoder pinot	Encoder connected	to a socket
		#3 #1 #4 #6 #7	#2 110 130
	Pin number	Signal name	
	7	5V	
	5	GND	
	6	SD+	
	4	SD-	
	1	Shield	
	3	Battery+	
	2	Battery-	

Table 4-8 Encoder cable pin connection relationship

Drive side J1394		Description	Motor side		
Pin number	Signal name	Bescription	Aviation plug pin number	Cable color	
1	5V	Encoder +5v power	7	Blue	
2	GND	Encoder power ground	5	Orange	
5	SD+	Serial communication signal +	6	Green	
6	SD-	Serial communication signal -	4	Brown	
Shell	Shield	Shield	1	-	
-	-	Battery+	3*	Pink	
-	-	Battery-	2*	Pink-Black	

Note: The color of the cable is subject to the actual product. The cables described in this manual are all cables of Wecon!

Table 4-10 Absolute value encoder cable connector (in-line type)

Connector shape and terminal pin distribution

Adapted




Table 4-11 Encoder cable pin connection relationship

Drive sid	le J1394	Description	Motor side	
Pin number	Signal name	Description	Aviation plug pin number	Cable color
1	5V	Encoder +5v power	7	Blue
2	GND	Encoder power ground	5	Orange
5	SD+	Serial communication signal +	6	Green
6	SD-	Serial communication signal -	4	Brown
Shell	Shield	Shield	1	-
		Battery positive pole	3*	Brown
		Battery negative pole	2*	Black

Note: The color of the cable is subject to the actual product. The cables described in this manual are all cables of Wecon!

	Adapted
Connector shape and terminal pin distribution	motor flange

Chapter 4 Wiring




Table 4-10 Encoder cable pin connection relationship

Drive side J1394		Function description	Motor side		
Pin number	Signal name	runction description	Aviation plug pin number	Cable color	
1	5V	Encoder+5V power supply	1	White	
2	GND	Encoder power ground	2	Brown	
5	SD+	Serial communication signal+	3	Green	
6	SD-	Serial communication signal-	4	Yellow	
Housing	Shield	Shield	5		
		Battery+	6*	Pink	
		Battery-	7*	Black	

Note:

Please be subject to the real object for the cable color. The cables described in this manual are all Wecon cables!

4.4 Servo Drive Control Input and Output Terminal Wiring

4.4.1 CN2 Pin Distribution




Figure 4-8 Shape and pin distribution of control input and output terminals

Pin number Signal name Pin number Signal name Pin number Signal name DO2-DO1-DO3-1 6 11 2 DO2+ 7 DO1+ 12 DO3+ 3 SS 8 13 4 DI2 9 DI1 14 DI6 5 DI4 10 DI3 15 DI5

Table 4-14 CN2 Interface Definition

4.4.2 Digital Input and Output Signals

Table 4-12 DI/DO signal description

Pin number	Signal name	Default function
9	DI1	None
4	DI2	Fault and warning clear
10	DI3	Forward drive prohibition
5	DI4	Reverse drive prohibition
15	DI5	None
14	DI6	None
3	SS	Power input (12 ~ 24V)
6	DO1-	Datation datastics
7	DO1+	Rotation detection
1	DO2-	Fault signal
2	DO2+	Fault signal
11	DO3-	Comice woods:
12	DO3+	Servo ready

1) Digital input circuit

Taking DI1 as an example, the interface circuits of DI1 ~ DI6 are exactly the same.

When the control device (HMI/PLC) is relay output




Figure 4-11 Relay output When the control device (HMI/PLC) is open collector output




Figure 4-12 Open collector output

Digital output circuit

Taking DO1 as an example, the interface circuits of DO1 $^{\sim}$ DO3 are exactly the same.

When the control device (HMI/PLC) is relay input





Figure 4-11 Relay input

When the control device (HMI/PLC) is optocoupler input



Note1: The maximum current should not exceed 50ma

Figure 4-12 Optocoupler input

4.4.3 Brake Wiring

The brake is a mechanism that prevents the servo motor shaft from moving when the servo drive is in a non-operating state, and keeps the motor locked in position, so that the moving part of the machine will not move due to its own weight or external force.

The brake input signal is non-polar, and the user needs to prepare 24V power supply. The standard connection diagram of brake signal BK and brake power supply is as follows:




Figure 4-15 Brake wiring (taking three-phase 220V input as an example)

4.5 Communication Signal Wiring

The CN5 port of the first servo drive is connected to Wecon PLC LX6V




Figure 4-16 Communication topology networking schema

Table 4-16 CN5\ CN6 interface definition

Pin	Name	Function description
1	RX-	Computer sends negative terminal (drive receives negative)
2	RX+	Computer sends terminal (drive receives positive)
3	TX-	Computer receives negative terminal (drive sends negative)
4	GND	Ground terminal
5	Not used	Not used
6	TX+	Computer receives positive terminal (drive sends positive)
7	NC	Not used
8	NC	Not used

Chapter 5 Panel

5.1 Panel Composition




Figure 5-1 Appearance schematic diagram of servo drive panel

The panel of Wecon VD3E series bus servo drive is composed of a display (5-bit LED digital tube) and buttons, which can be used for various display and parameter setting functions of servo drive. Taking parameter setting as an example, the conventional functions of buttons are shown in Table 5-1.

Table 5-1 Brief introduction of key function

lcon	Name	Function
M	Mode	Mode switching Return to the previous menu
	Increase	Increase the value of the LED flashing bit
	Down (decrease)	Decrease the value of the LED flashing bit
	SHIFT (Settings)	 Change the LED flashing bit View the high-order values of data with a length greater than 4 bits
	Confirm (Enter)	Enter the next menu Execute instructions such as storing parameter setting values

5.2 Panel Display

When servo drive is in operation, the panel could be used for status display, parameter display, fault display and monitoring display of the servo.

Status display: Display the current operating status of servo drive.

Parameter display: Display the object dictionary and the setting value of the object dictionary corresponding to different functions.

Fault display: Display the fault code of servo drive.

Monitor display: Display the current operating parameter values of servo drive.

5.2.1 Display Switching




Figure 5-2 Switching schema of each display type of panel

Description:

- 1 Power on, the panel display of the servo drive enters [status display mode]
- ② When an operation failure occurs, the panel immediately switches to the bit failure display mode, and all the digital tubes flash synchronously, press the "mode" key to switch to the parameter display mode.
- ③ Press the "Mode" key to switch between different display modes. The switching conditions are shown in Figure 5-2.

5.2.2 Status Display

Table 5-2 Status display example

Display	Name	Display occasion	Meaning
rESEL	Reset Servo initialization	Servo drive is powered on within 1 second	The servo drive is in an initialized or reset state. After waiting for initialization or reset to complete, automatically switch to other states
nr	nr Servo is not ready	After initialization is complete, but servo is not ready	The servo drive is in a non-operational state
	ry Servo ready	Servo ready	The servo is in a ready state, waiting for the upper computer to give an enable signal
rn	rn Servo is running	Servo enable signal is active (S-ON is ON state)	The servo drive is in operation

Chapter 5 Panel

		napter 5 Paner	
nF	nF Servo trouble-free	Servo drive has no fault	Servo drive has no fault
75	Qs Servo quick stop	Servo is in quick stop	Servo is in quick stop
	1-A Control mode	-	Displays the current operation mode of the servo drive in hexadecimal digital form: 1: Contour position mode 3: Contour velocity mode 4: Contour torque mode 6: Homing mode 8: Cyclic synchronous position mode 9: Periodic Synchronous speed mode A: Periodic synchronous torque mode
	1 - 8 Communication Status	-	Displays the Ether CAT status machine status of the slave station in character form: 1: Initialization status 2: Pre-operating status 4: Safe operation status 8: Operating status
	CN6 Interface Connection Indication	-	Keep dark constantly: No communication connection detected
	CN5 Interface Connection Indication	-	Keep bright constantly: A communication connection has been established

Control mode

- 1: Profile position control
- 3: Profile speed mode
- 4: Profile torque mode
- 6: Homing mode
- 7: Interpolation mode
- 8: Cyclic Synchronous Position Mode
- 9: Cyclic Synchronous Position Mode
- A: Cyclic Synchronous Position Mode




Figure 5-3 Status indication schema

5.2.3 Parameter Display

Wecon VD3E series bus servo drive is divided into 13 groups of function codes according to different parameters and functions, which can quickly locate the position of function codes according to the group of function codes. For specific parameters, please refer to "Chapter 8 Object Dictionary".

(1) Parameter group display

The parameter display is the display of different function codes. The format of the function code is PXX.YY, where PXX represents the group number of the function code, and YY represents the number within the function code group.

Display	Name	Content
PXX.YY	Function code group number	Number in function code group

For example, the function code 2000.01 is shown as follows:


Display	Name	Content
PII.I i	Function code 2000-01	00: Function code group number 01: Number in function code group

(2) Display of different length data

1 Data display of four digits and below

Using single page display, if it is a signed number, the highest bit of the data is "-".

Examples:



Display Data more than five bits

Display in pages from low to high digits, each 4 bits is a page. Display method: current page + current value, as shown, switch the current page by pressing the "shift" key.

For example: 2147483646 is displayed as follows:




Figure 5-4 2147483646 Display Action

For example: -2147483647 is displayed as follows:





Figure 5-5 -2147483647 Display Operation

(3) Decimal point display

Digital tube of individual bit data ". "Represents the decimal point, and the decimal point". "No flashing, as shown below:



(4) Parameter setting display

Table 5-3 Parameter setting display

Display	Name	Display occasion	Meaning
donE	Done Parameter setting completed	Restore factory settings	
P. in it	P. Init Parameter restore factory setting value	Restore factory settings	The servo drive is in the process of parameter restoration to factory settings
Error	Error parameter error	Parameter setting exceeds the limit (Or not allowed to exceed the limit)	Prompt that the parameter setting exceeds the limit

5.2.4 Fault Display

The panel can display current or historical fault and warning codes. Please refer to the analysis and troubleshooting of faults and warnings"Chapter 7 Failure".

When a single fault or warning occurs, the panel immediately displays the current fault or warning code; when multiple faults or warnings occur, the highest fault code is displayed. When a fault occurs, when switching from the auxiliary function to the parameter display function, the corresponding fault or warning code will be displayed. You can view the current fault and warning codes and the past five fault and warning codes through the monitor display on the panel. You can view the current fault and warning codes and the last five fault and warning codes through the monitoring display of the panel.

Table 5-4 Warning display case

Display	Name	Content
A-84	Parameter modification that needs to be powered on again	Modified the parameters that need to be re-powered on to take effect

Table 5-5 Fault display case

Display	Name	Content
Er.J4	Motor overload protection	Motor overload protection

5.2.5 Monitor Display

After the servo drive is powered on or the servo enable is turned on, you can press the "Mode" key to enter the monitoring display mode.

Table 5-6 Monitoring quantity display schema

	Monitoring			
Display	volume	Name	Unit	Meaning
	U0-02	Servo motor speed	rpm	Indicates the actual running speed of servo motor, which is expressed in decimal system
	U0-31	Bus voltage	V	Represents the voltage value, the DC bus voltage between P+ and - of the drive
DI6 DI4 DI2 DI5 DI3 DI1 High High High High High High High 1 1 1 1 1	U0-17	Input signal status	-	Indicates the level status corresponding to the 6 DI terminals. The upper half of the LED light indicates high level, and the lower half light indicates low level.
DO2 DO3 DO1 High Low High 1 0 1	U0-19	Output signal status	-	Indicates the level status corresponding to the 3 DO terminals. The upper half of the LED light indicates high level, and the lower half light indicates low level.

5.3 Panel Operation

5.3.1 Parameter Setting

The servo drive panel can be used to set parameters. For details, please refer to "Chapter 6 Parameters" Taking 2000.01 as an example, the control mode of servo drive is changed from position control mode to speed control mode. The specific setting steps are shown in Figure 5-5. Description:

The power supply is in Rdy state after power on.

Press "Mode" key to enter the function code parameter interface.

Press "Confirm" key to enter the function code value modification interface after completing the function code selection.

Press the "Up" and "Down" keys to modify the parameter value.

Press the "Confirm" key twice to complete the value modification.




Figure 5-6 Schematic diagram of parameter setting steps

5.3.2 Jog Operation

In order to test run the servo motor and the servo drive, you can use the jog running function.

The operation steps are shown in .

Description:

(1) Adjust the function code to P10.01 after power on.

Press the "Enter" key to enter the next menu to set the JOG jog speed.

After the "JOG jog speed" setting is completed, press the "Enter" key, the panel displays "JOG" in a flashing state, press the "Enter" key again to enter the JOG mode.

Long press the "Up" key and "Down" key to realize the forward and reverse rotation of the motor.

Press the "Mode" key to exit the JOG mode.

Note 1: Press the Up/Down key for a long time, and the motor will continue to rotate; Press the Up/Down key, and the motor will be inching and rotating.

Note 2: Exit the "inching operation" status through the "Mode" keyboard and return to the superior menu at the same time.

Note 3: Display Error cause: Please refer to the corresponding fault code "Chapter 10 Failure".




Figure 5-7 Inching operation setting step

5.3.3 Factory Reset

The factory settings can be restored through the servo drive panel. The specific operation steps are shown in Figure 5-8.

Illustrate:

After power on, modify the function code to P10.02.

Press the "Enter" key to enter the next menu to set the parameters.

- (3) After the parameter is set to 1, press the "Confirm" key, at this time, the digital tube flashes to display "00001", and press the "Confirm" key again, and the digital tube displays P.init.
- 4 Long press the "Enter" key for 3s, the panel digital tube will gradually light up from left to right until 88888 is displayed.
- 5 You can release the "confirm" key during the display of 8.8. 8.8. 8.
- **(6)** Digital tube shows done, indicating that the factory settings are restored. At this time, it is recommended to re-power up and down the servo drive.

Note 1: Display Error Reason: When the parameter value of P10.02 is set beyond the set range (0 ~ 1), Error will be displayed.

Note 2: When the setting value is displayed as 0, press the Down key, and the panel will display Error. After displaying for 1 second, the setting value will automatically jump to 1.




Figure 5-8 Restore factory setting steps

Chapter 6 Communication Network Configuration

6.1 EtherCAT Operation




Figure 6-1 EtherCAT Operation Configuration Flow

6.2 EtherCAT Communication Fundamentals

6.2.1 EtherCAT Communication Specification

Hierarchy	Content	Specification
Application layer	PDO	Variable PDO mapping
	SDO	SDO request, SDO reply
	CIA 402	Cyclic Synchronous Position Mode (CSP)
		Origin return mode (HM)
Physical layer	Transport protocol	100BASE-TX (IEEE802.3)
	Communication interface	RJ45 Port * 2 (IN, OUT)

6.2.2 Communication Structure

Wecon VD3E series bus servo drives adopt IEC 61800-7 (CiA402)-CANOpen motion control sub-protocol.




Figure 6-2 Communication structure

PDO (Process Data Object) is composed of Object Dictionary (Object Dictionary) which can be mapped in PDO, and the content of process data is defined according to PDO mapping.

Email is a kind of aperiodic communication and can read and write all object dictionaries.

6.2.3 State Machines

EtherCAT devices support four states and are responsible for coordinating the state relationship between master and slave applications at initialization and running:

Init: Initialization, abbreviated as I;

Pre-Operational: Pre-Operational, abbreviated as P;

Safe-Operational: Safe operation, abbreviated as S;

Operational: Operational, abbreviated as O.




Figure 6-3 Communication structure

When changing from initialization state to operational state, it must be changed in the order of "initialization \Rightarrow pre-Operational \Rightarrow Safe Operational \Rightarrow Operational"!

Leapfrog transition when returning from operational state. Refer to the following table for state transition operation and initialization process:

Status	Operation
Initialization	There is no communication in the application layer, and the master station can only
	read and write ESC registers
	The master station configures the site address of the slave station;
Initialization →	Configure Email channels;
pre-operational	Configure DC distributed clock;
	Request "pre-Operational" status
Pre-operation	Application Layer Email Data Communication (SDO)
	The master station uses Email to initialize the process data mapping;
Pre-operation → safe	The master station configures the SM channel used for process data communication;
operation	The main station is configured with FMMU;
	Request "safe status"
Safe operation	Allow input data to be read without output signal (SDO, TPDO)
Safe operation →	The master station sends valid output data;
operation	Request "operation" status
Operation	Input and output are all valid and can use Email communication (SDO, TPDO, RPDO)

6.2.4 Communication Indicator Lamp

The communication indicator for the VD3E servo drive is located on the CN5 (IN), CN6 (OUT) sockets, as shown INFigure 6-5As shown in.




Figure 6-4 Communication indicator position

(1) Connection lamp (yellow)

Used to display the status of CN5 and CN6 communication interfaces, and the display contents are shown in the following table.

Connection lamp status	Explanation
OFF	The port is not connected to the network cable
ON	The port is connected to the network cable

(2) Communication lamp (green)

Used to display the status of CN5 and CN6 communication connections, as shown in the following table.

Connection lamp status	Explanation
ON	No communication connection was established with the master station
BLINKING	A communication connection has been established with the master station

6.2.5 Process Data PDO

PDO outputs process data in real time. PDO can be divided into RPDO (for receiving instructions from master station) and TPDO (for feeding back its own status from slave station).




Figure 6-6 PDO schematic diagram

(1) PDO mapping parameters

PDO mapping is used to establish the mapping relationship between object dictionary and PDO. 1600h-17FFh is RPDO, 1A00h-1BFFh is TPDO:

Name	Parameter	Nature	
RPDO	1600h	Variable mapping	
KPDO	1701h ~ 1705h	Fixed mapping	
TPDO	1A00h	Variable mapping	
IFBO	1B01h	Fixed mapping	

The following figure is an example of RxPDO mapping.

index	sub-index	name		data	type			
6040		control word		U	UINT			
607A	-	target position		D	DINT			
		>	inde	X S	ub-in	dex	data	ty
	RxPDO	1	6040		00		UI	NT
	(1600h)		607A	Ų.	00		DI	NT

Figure 6-7 Examples of RxPDO mapping

10

The data type is defined as follows:

Data type	Description	Numerical range
SINT	Signed 8bit	-128 ~ 127
USINT	Unsigned 8bit	0 ~ 255
INT	Signed 16bit	-32768 ~ 32767
UINT	Unsigned 16bit	0~65535

DINT	Signed 32bit	-21247483648 ~ 21247483647
UDINT	Unsigned 32bit	0 ~ 4294967295
STRING	String Value	ASCII

The following figure is an example of TxPDO mapping.

index	sub-index	name	data type	,	
6041		control word	UINT		
6064		position feedback	DINT		
607A		actual speed	DINT		
	ĺ			_	
	L		index	sub-index	da
		1	6041	00	
		2	6040	00	
		PDO .00h) 3	606C	00	
					_

Figure 6-8 Examples of TxPDO mapping

10

ta type

UINT

DINT

DINT

The following figure is an example of a SyncManager PDO mapping.




Figure 6-8 SyncManager PDO Mapping Example

(2) Synchronize management of PDO allocation settings

In EtherCAT periodic data communication, process data can contain multiple PDO mapping data objects. The data objects 0x1C10 ~ Ox1C2F used in CoE protocol define the corresponding PDO

mapping object list of SM (Synchronous Management Channel), and multiple PDO can be mapped in different sub-indexes.

Index (hex)	Sub-index (hex)	Content
1C12	01	Choose to use one of 0x1600, 0x1701-0x1705 as the actual RPDO
1C13	01	Select to use one of 0x1A00, 0x1B01-0x1B04 as the actual TPDO

(3) PDO configuration

The PDO mapping parameter contains a pointer to the PDO corresponding process data that the PDO needs to send or receive, including index, sub-index and mapping object length. The sub-index 0 records the number N of objects mapped by the PDO, and the length of each PDO data can reach 4N bytes at most, which can map one or more objects at the same time.

Sub-index ~ N is the mapping content. The mapping parameter content is defined as follows:

Number of digits	31		16	15		8	7		0
Description		Index			Sub-index		C	Object lengt	h

The index and sub-index together determine the position of the object in the object dictionary, and the object length indicates the specific bit length of the object (hexadecimal representation)

Object length	bit length
08h	8
10h	16
20h	32

For example, the mapping parameter of 6040h-00 (control word) is 60400010h



The PDO configuration can only be designed when the EtherCAT communication state machine is in pre-operation (Pro-Operation, panel display 2), otherwise an error will be reported.

The PDO configuration parameters cannot be stored in the EEPROM. Therefore, after each power-on, please reconfigure the mapping object, otherwise, the mapping object is the default parameter of the drive

The SDO fault codes are returned when:

Modify PDO parameters in non-pre-operation state;

Pre-write values other than $1600/1701 \sim 1705$ in 1C12; Values other than $1A00/1B01 \sim 1B04$ are pre-written in 1C13.

No more than 10 variable mappings can be added, otherwise the servo activation failure may occur.

6.2.6 Email Data SDO

EtherCAT Email data SDO is used to transmit aperiodic data, such as configuration of communication parameters, servo drive operation parameters and so on. EtherCAT's CoE service types include:

(1) Emergency information; ② SDO request; ③ SDO response; ④ TxPDO; ⑤ RxPDO; ⑥ Remote TxPDO sending request; ⑦ Remote RxPDO sending request; ⑦ SDO information. Wecon VD3E series bus servo drives currently support ② SDO requests; ③ SDO response.

6.2.7 Distributed Clock

Distributed clock enables all EtherCAT devices to use the same system time, thus controlling the synchronous execution of tasks of each device. The slave station device can generate a synchronization signal according to the synchronized system time. We con VD3E series bus servo drives only support DC synchronous mode.




Figure 6-9 DC Synchronous Mode Schematic Diagram

6.2.8 Status Indication




Figure 6-10 Status indication schema

Description:

(1) Communication connection status

The first digit tube from the left of the 5-bit LED indicator on the servo drive panel is used to display the connection status of the two Ethernet communication ports: upper "-" CN6 (OUT) and lower "-" CN5 (IN)

Long dark: No communication connection detected


Long Bright: A communication connection has been established

(2) Communication Operating status

The servo drive panel of the 5-bit LED indicator lamp is the second digit tube from the left, which is used to display the EtherCAT state machine status of the slave station in character form.

Panel display			Meaning
	0		Initialization state
	I		Pre-operation status
			Safe operation status

Chapter 6 Communication Network Configuration



(3) Display of servo operation mode

Servo drive panel 5-bit LED indicator from the left of the third digit tube, used to display hexadecimal digital form display servo drive current operation mode.

Panel display	Meaning
Û Û	Contour position control mode
J	Contour speed control mode
H	Contour torque control mode
6	Homing mode
J	Interpolation mode
	Cyclic Synchronous Position mode
J	Periodic synchronous speed mode
A	Periodic synchronous torque mode

(4) Servo status display

Servo drive panel 5-bit LED indicator from the left of the fourth- and fifth-digit tube, used to display the servo status of the slave station.

Panel display	Definition

Chapter 6 Communication Network Configuration

	Not ready nr
	Ready ry
	Run rn
	Failure-free nF
75	Quick stop qs

6.2.9 Introduction to CiA402 Control

The use of Wecon VD3E Series Bus Type servo drives must be guided according to the procedure specified in Standard 402 Protocol.




Figure 6-11 CiA402 state machine switching schema

Status	Description
Initialization	Drive initialization, internal self-test has completed. Parameters cannot be set, and servo drive function cannot be performed.
Servo trouble-free	There is no fault in the servo drive. Parameters can be set.
Servo ready	Servo drives are ready. Parameters can be set.
Wait to turn on servo enable	The servo drive waits to turn on the servo enable. Parameters can be set.
Servo operation	The servo drive is running normally.
Quick stop	The servo drive is performing the quick shutdown function. Only function codes with the attribute "Run valid" can be set.
Malfunction shutdown	The servo drive is performing the fault shutdown function.

Chapter 6 Communication Network Configuration

	Only function codes with the attribute "Run valid" can be set.
Fault	Failure shutdown is complete, and all drive functions are disabled.
	Allow parameters to be changed to troubleshoot.

6.2.10 Basic Characteristics

EtherCAT network cable is connected to the CN5 (IN), CN6 (OUT) interfaces, and its electrical characteristics conform to IEEE 802.3 standard.




Figure 6-12 Communication port

Pin	Name	Function description
1	TX+	Sending data+
2	TX-	Sending data-
3	RX+	Receiving data+
4	-	-
5	-	-
6	RX-	Receiving data-
7	-	-
8	-	-

EtherCAT communication topology connections are very flexible, taking linear connections and ring connections as examples:




Figure 6-13 Linear connection




Figure 6-14 Ring connection

7.1 Basic Settings

7.1.1 Pre-operation Inspection

Table 7-1 Check contents before operation

Number	Content							
	Wiring							
1	The main circuit input terminals (L1, L2 and L3) of servo drive must be properly connected.							
2	The main circuit output terminals (U, V, W) of the servo drive and the main circuit cables (U, V, W) of the servo motor must have the same phase and be connected correctly.							
3	The main circuit power input terminals (L1, L2 and L3) and the main circuit output terminals (U, V and W) of servo drive cannot be short-circuited.							
4	The wiring of each control signal cable of the servo drive is correct: the external signal wires such as brake and overtravel protection have been reliably connected.							
5	Servo drive and servo motor must be grounded reliably.							
6	When using an external braking resistor, the short wiring between drive C and D must be removed.							
7	The force of all cables is within the specified range.							
8	The wiring terminals have been insulated.							
	Environment and Machinery							
1	There is no iron filings, metal, etc. that can cause short circuits inside or outside the servo drive.							
2	The servo drive and external braking resistor are not placed on combustible objects.							
3	The installation, shaft and mechanical structure of the servo motor have been firmly connected.							

7.1.2 Power on

Connect the main circuit power supply

(1) After power on the main circuit, the bus voltage indicator shows no abnormality, and the panel display "ry", indicating that the servo drive is in an operational state, waiting for the upper computer to give the servo enable signal.

If the drive panel displays other fault codes, please refer to <u>"Chapter 10 Faults"</u> to analyze and eliminate the cause of the fault.

(2) Set the servo drive enable (S-ON) to invalid (OFF)

Please refer to "6.2.9 CiA402 Control Introduction" for relevant process description

7.1.3 Jog Operation

Inching operation is used to judge whether the servo motor can rotate normally, and whether there is abnormal vibration and abnormal sound when rotating. Inching operation can be through panel inching operation function, and the motor takes the current stored value of object dictionary P10-01 (200A-01) as inching speed.

(1) Panel jog operation

Enter P10-01 (200A-01) through panel key operation. After pressing the confirmation key, the panel will display the current inching speed. At this time, the inching running speed can be adjusted by pressing the "up" or "down" key; After adjusting the inching speed, press the "Confirm" key. At this time, the panel displays "JOG" and is in a flashing state. Press the "Confirm" key again to enter the inching operation mode (at this time, the motor is powered on!). Press the "up" key and "down" key for a long time to realize the continuous forward or reverse rotation of the motor. Press the "Mode" key to exit the inching operation mode. Please refer to "5.3.2 Inching display".

Index code	Name	Setting method	Valid time	Default	Range	Definition	Unit
200A-01	JOG speed	Execute Setting	Valid immediately	0	0~3000	JOG speed	rpm

(2) Jog operation of the servo debugging platform

Open the jog operation interface of the software "Wecon SCTool", set the jog speed value in the "set rotating speed" in the "manual operation", click the "servo on" button on the interface, and then achieve the jog forward and reverse function through the "forward rotation" or "reverse rotation" button on the interface. After clicking the "Servo Close" button, exit the inching operation mode.



Notice

The communication control function of EtherCAT master station and the inching operation of servo drive can not be used at the same time;

If you enter the inching mode, you need to exit the inching operation before you can use EtherCAT to control;

If you enter the EhterCAT activation step, you need to exit the EtherCAT control before you can perform the inching operation of the servo drive.

7.1.4 Rotation Direction Selection

By setting the rotate direction, the rotate direction of the motor can be changed without changing the polarity of the input command

Index code	Name	Setting method	Valid time	Default	Range	Definition	Unit
2000-04	Rotate direction	Shutdown Setting	Valid immediately	0	0 to 1	Forward rotation: Face the motor shaft to watch 0: standard setting (CW is forward rotation) 1: reverse mode (CCW is forward rotation)	-

7.1.5 Braking Resistance

The servo motor is in the generator state when decelerating or stopping, the motor will transfer energy back to the drive, which will increase the bus voltage. When the bus voltage exceeds the braking point, The drive can consume the feedback energy in the form of thermal energy through the braking resistor. braking resistors can be built-in or external, but they cannot be used at the same time. When selecting an external braking resistor, the short tab on the servo drive needs to be removed.

The basis for judging whether the braking resistor is built-in or external.

- (1) The maximum brake energy calculated value > the maximum brake energy absorbed by capacitor, and the brake power calculated value ≤ the built-in braking resistor power, use the built-in braking resistor.
- (2) The maximum brake energy calculated value > the maximum brake energy absorbed by capacitor, and the brake power calculated value > the built-in braking resistor power, use external braking resistor.

Index code	Name	Setting method	Valid time	Default	Range	Definition	Uni t
2000-09	Braking resistance setting	Execute Setting	Valid immediately	0	0 to 3	O: use built-in braking resistor 1: use external braking resistor and natural cooling 2: use external braking resistor and forced air cooling; (cannot be set) 3: No braking resistor is used, it is all absorbed by capacitor.	
2000-0 A	External braking resistor resistance	Execute Setting	Valid immediately	50	0 to 65535	Used to set the resistance value of the external braking resistor of a certain type of drive	Ω

2000-0B	External braking resistor power	Execute Setting	Valid immediately	100	0 to 65535	It is used to set the external braking resistor power of a certain type of drive.	w	•
---------	---------------------------------	--------------------	----------------------	-----	---------------	---	---	---

7.1.6 Servo Operation

(1) Set servo enable (S-ON) to active (ON)

The servo drive is in an operation state, and the monitor displays "rn", but because there is no command input at this time, the servo motor does not rotate and is in a locked state.

S-ON can be configured and selected according to the function selection of DI terminal in DIDO configuration of object dictionary.

(2) Input the instruction and the motor rotates

Input appropriate instructions during operation, first run the motor at a low speed, and observe the rotation to see if it conforms to the set rotation direction. Through Wecon SCTools software, the actual running speed, bus voltage and other parameters of the motor were observed.

(3) Timing diagram of power on




Figure 7-1 Power on timing diagram

7.1.7 Servo Stop

According to different shutdown modes, it can be divided into free shutdown and zero-speed shutdown, and their respective characteristics are shown in Table 7-2. According to the shutdown state, it can be divided into free running state and position keeping lock, as shown in Table 7-3:

Table 7-2 Comparison of two shutdown modes

Shutdown mode	Shutdown description	Shutdown characteristics
Free stop	Servo motor is not energized and decelerates freely to 0. The deceleration time is affected by factors such as mechanical inertia and mechanical friction.	Smooth deceleration, small mechanical shock, but slow deceleration process.
Zero-speed stop	The servo drive outputs reverse braking torque, and the motor quickly decelerates to zero-speed.	Rapid deceleration with mechanical shock, but fast deceleration process.

Table 7-3 Comparison of two shutdown states

Shutdown status	Free operation status	Position locked
Characteristics	After the motor stops rotating, the motor is not energized, and the motor shaft can rotate freely.	After the motor stops rotating, the motor shaft is locked and cannot rotate freely.

Servo enable (S-ON) OFF shutdown

Relevant parameters of servo OFF shutdown mode are shown in Table 7-4.

Table 7-4 Parameter details of servo OFF shutdown mode

Index code	Name	Setting method	Valid time	Default	Range	Definition	Unit
2000-05	Servo OFF shutdown mode	Shutdown Setting	Valid immediately	0	0 to 1	O: Free shutdown, and the motor shaft remains free state; 1: Zero speed shutdown, and the motor shaft remains in a free state.	-

(2) Emergency shutdown

It is free shutdown mode at present, and the motor shaft remains in a free state. The corresponding configuration and selection could be selected through the DI terminal function of the function code "DIDO configuration".

(3) Overtravel shutdown

Overtravel means that the movable part of the machine exceeds the set area. In some occasions where the servo moves horizontally or vertically, it is necessary to limit the movement range of the workpiece. The overtravel is generally detected by limit switches, photoelectric switches or the multi-turn position of the encoder, that is, hardware overtravel or software overtravel.

Once the servo drive detects the action of the limit switch signal, it will immediately force the speed in the current direction of rotation to 0 to prevent it from continuing, and it will not be affected for reverse rotation. The overtravel shutdown is fixed at zero speed and the motor shaft remains locked.

The corresponding configuration and selection can be selected through the DI terminal function of the object dictionary "DIDO configuration". The default function of DI3 is POT and DI4 is NOT, as shown

Function code	Name	Setting method	Valid time	Default	Range	Definition	Unit
P06-08	DI_3 channel function selection	Operation Setting	Power on again	3	0 to 32	0: Close (Not used) 01: S-ON Servo enable 02: A-CLR Fault and alarm clear 03: POT Forward drive forbidden 04: NOT Reverse drive forbidden 06: CL Clear 08: E-STOP Emergency stop 26: HOMEORG Homing mode Other: Reserved	-
P06-09	DI_3 channel logic selection	Operation Setting	Valid immediately	0	0 to1	DI port input logic valid function selection 0: Always on input, 1: Always off input.	-
P06-10	DI_3 input source selection	Operation Setting	Valid immediately	4	0 to 1	Select enabled Di_3 port type 0: Hardware DI_3 input terminal 1: Virtual DI_3 input terminal	-
P06-11	DI_4 channel function selection	Operation Setting	Valid immediately	0	0 to 1	0: Close (Not used) 01: S-ON Servo enable 02: A-CLR Fault and alarm clear 03:POT Forward drive forbidden 04: NOT Reverse drive forbidden 06: CL Clear 08:E-STOP Emergency stop 26: HOMEORG Homing mode Other: Reserved	-
P06-12	DI_4 channel logic selection	Operation Setting	Valid immediately	0	0 to 1	DI port input logic validity function selection 0: Always on input. Switch closed 1: Always off input.	-
P06-13	DI_4 input	Operation	Valid	0	0 to 1	Select enabled DI_4 port	-

source	Setting	immediately		type	
selection				0: Hardware DI_4 input	
				terminal	
				1: Virtual DI_4 input	
				terminal	

(4) Malfunction shutdown

When the machine fails, servo will perform a fault shutdown operation. The current shutdown mode is fixed to the free shutdown mode, and the motor axis remains in a free status.

7.1.8 Brake Holding Device

The brake is a mechanism that prevents the servo motor axis from moving when the servo drive is in a non-operating state, and keeps the motor locked in position, so that the moving part of the machine will not move due to its own weight or external force.



Notice

The brake device is built into the servo motor, which is only used as a non-energized fixed special mechanism. It cannot be used for braking purposes, and can only be used when the servo motor is kept stopped;

- After the servo motor stops, turn off the servo enable (S-ON) in time;
- The brake coil has no polarity;
- When the brake coil is energized (that is, the brake is open), magnetic flux leakage may occur at the shaft end and other parts. If users need to use magnetic sensors and other device near the motor, please pay attention!
- When the motor with built-in brake is in operation, the brake device may make a clicking sound, which does not affect the function.

(1) Wiring of brake device

Brake input signal is no polar. You need to use 24V power. The standard wiring between brake signal BK and brake power is as below.




Figure 7-2 Brake wiring



- 1 The length of the motor brake cable needs to fully consider the voltage drop caused by the cable resistance, and the brake operation needs to ensure that the voltage input is 24V.
- 2 It is recommended to use the power supply alone for the brake device. If the power supply is shared with other electrical device, the voltage or current may decrease due to the operation of other electrical device, which may cause the brake to malfunction.
- (3) It is recommended to use cables above 0.5 mm².

(2) Brake software setting

For a servo motor with brake, one DO terminal of servo drive must be configured as function 141 (BRK-OFF, brake output), and the valid logic of the DO terminal must be determined.

Related function code

DO function code	Function name	Function
141	BRK-OFF, brake output	The output signal indicates that the brake of the servo motor is
141	bin-Orr, blake output	released

Index code	Name	Setting method	Valid time	Default	Range	Definition	Unit
2001-1E	Delay from brake output to instruction reception	Execute Setting	Valid immediately	250	0 to 500	Set delay that from the brake (BRK-OFF) output is ON to servo drive allows to receive input instruction. Between. When the brake output (BRK-OFF) is not allocated, this function code has no	ms

						effect.	
2001-1F	In the static state, delay from the brake output is OFF to the motor is not energized.	Execute Setting	Valid immediately	150	1 to 1000	When the motor is in a static state, set the delay time from the brake (BRK-OFF) output is OFF to the servo drive is in the non-powered state. When the brake output (BRK-OFF) is not allocated, this function code has no effect.	ms
2001-20	Rotation status, when the brake output OFF, the speed threshold.	Execute Setting	Valid immediately	30	0 to 3000	When the motor is rotating, the motor speed threshold that is allowed when the brake (BRK-OFF) output is OFF. When the brake output (BRK-OFF) is not allocated, this function code has no effect.	rpm
2001-21	Rotation status, servo enable OFF to brake output OFF Delay	Operation Setting	Valid immediately	500	1~2000	The motor is rotating, the delay time that is allowed from the brake (BRK-OFF) output OFF to the servo enable (S-ON) OFF. When the brake output (BRK-OFF) is not allocated, this function code has no effect.	ms

Table 7-6 Relevant parameters of brake setting

According to the state of the servo drive, the working sequence of the brake mechanism can be divided into the brake sequence in the normal state of the servo drive and the brake sequence in the fault state of the servo drive.

(3) Servo drive brake timing in normal state

The brake timing of the normal state can be divided into:

The servo motor is stationary (the actual speed of the motor is lower than 20rpm) and the servo motor is rotating (the actual speed of the motor is 20 rpm and above).

1) Brake timing when the servo motor is stationary

When the servo enable is changed from ON to OFF, if the actual speed of the current motor is lower than 20rpm, the servo drive acts according to the stationary braking timing, and the specific timing actions are as follows Figure 7-18 As shown in.



(1) After the brake output is set from OFF to ON, do not input the position/speed/torque command during 2001-1Eh, otherwise the command will be lost or run incorrectly.

Nhen applied to a vertical axis, the external force or the weight of the mechanical moving part may cause the machine to move slightly. When the servo motor is stationary, and the servo enable is OFF, the brake output will be OFF immediately. However, the motor is still powered on within the time of 2001-1Fh to prevent mechanical movement due to its own weight or external force.




Figure 7-3 Braking timing when the motor is stationary

Note: Please refer to the relevant specifications of the motor for the delay time of the brake contact at ② in the figure.

2) The brake timing when the servo motor is rotating

When the servo enable is from ON to OFF, if the actual motor speed is greater than or equal to 20 rpm, the drive will act in accordance with the rotation brake sequence. The specific sequence action is shown in Figure 7-4.



When the servo enable is turned from OFF to ON, within 2001-30, do not input position, speed or torque instructions, otherwise the instructions will be lost or operation errors will be caused;

™When the servo motor rotates, the servo enable is OFF and the servo motor is in the
zero-speed shutdown state, but the brake output must meet any of the following
conditions before it could be set OFF:

2001-21h time has not arrived, but the motor has decelerated to the speed set in 2001-20h; 2001-21h time is up, but the motor speed is still higher than the set value of 2001-20h. After the brake output changes from ON to OFF, the motor is still in communication within 50ms to prevent the mechanical movement from moving due to its own weight or external force.




Figure 7-4 Braking timing when the motor rotates

(4) Brake timing when the servo drive fails

The brake timing (free shutdown) in the fault status is as follows.




Figure 7-5 Braking timing in fault state (free shutdown)

Note: The "delay arrival" of the brake signal is about 20ms, and the actual parameter is subject to the motor manufacturer.

7.2 Servo State Setting

The use of Wecon VD3E Series Bus Type servo drives must be guided according to the procedure specified in Standard 402 Protocol.




Figure 7-6 CiA402 state machine switching schema

Status	Description		
Initialization	Drive initialization, internal self-test has completed.		
IIIItialization	Parameters cannot be set, and servo drive function cannot be performed.		
Servo trouble-free	There is no fault in the servo drive.		
Servo trouble-free	Parameters can be set.		
Samue meeds	Servo drives are ready.		
Servo ready	Parameters can be set.		
Wait to turn on servo enable	The servo drive waits to turn on the servo enable.		
wait to turn on servo enable	Parameters can be set.		
Servo operation	The servo drive is running normally.		
Quick chutdown	The servo drive is performing the quick shutdown function.		
Quick shutdown	Only function codes with the attribute "Run valid" can be set.		
Malfunction shutdown	The servo drive is performing the fault shutdown function.		
Manunction shutdown	Only function codes with the attribute "Run valid" can be set.		
Fault	Failure shutdown is complete, and all drive functions are disabled.		
rault	Allow parameters to be changed to troubleshoot.		

State switching Control word 6040h

Power on =>Initialization	Natural transition without control instruction			
	Natural transition without control instruction			
Initialization =>Servo trouble-free	If there is an error in the initialization process, go directly to the			
	"failure shutdown" state.			
Servo trouble-free =>Servo ready	0x0006			
Servo ready =>Wait to turn on servo enable	0x0007			
Wait to turn on servo enable =>Servo operation	0x000F			
Servo operation =>Wait to turn on servo enable	0x0007			
Wait to turn on servo enable =>Servo ready	0x0006			
Servo ready =>Servo trouble-free	0x0000			
Servo operation =>Servo ready	0x0006			
Servo operation =>Servo trouble-free	0x0000			
Wait to turn on servo enable =>Servo	0x0000			
trouble-free	UNUUU UUU UUU UUU UUU UUU UUU UUU UUU U			
Servo operation =>Quick shutdown	0x0002			
Quick shutdown =>Servo trouble-free	The quick shutdown mode 605A is selected as 0 $^{\sim}$ 3. After the shutdown is completed, it will transition naturally without control instruction.			
=>Failure shutdown	Once the servo drive fails, it automatically switches to the "fault shutdown" state without control instruction.			
Failure shutdown =>Malfunction	After the fault shutdown is completed, it will make a natural transition without control instructions.			
Failure =>Servo trouble-free	0x80			
Quick shutdown =>Servo operation	The quick shutdown mode 605A is selected as 0 $^{\sim}$ 3, and 0x0F is sent after the shutdown is completed.			

7.2.1 Control Word

	Name	Setting method	Valid time	Default	Set range	Application category	Unit
6040h	Control word	Operation	Valid	0	0~65535	Basic	
	Control word	setting	immediately	0	0 03333	settings	-

Used to set control instructions. It is meaningless to assign each bit of a control word separately, and it must be combined with other bits to form a certain control instruction.

bit0 ~ bit3 have the same meaning in each control mode of servo drive, and commands must be sent in sequence before the servo drive can be switched according to CiA402 state machine.

bit	Name	Description
0	Servo operation can be started	0: Invalid
	Servo operation can be started	1: valid
1	Turn on the main circuit	0: Invalid
1	rum on the main circuit	1: valid
2	Quick shutdown	0: Invalid
	Quick shataown	1: valid
3	Servo operation	0: Invalid
	Servo operation	1: valid
4 - 6	Operation mode	It is related to the operation mode of servo drive
		Used to clear reset faults:
7	Fault reset	The rising edge of bit7 is valid;
		bit7 is kept at 1, and other control instructions are invalid.

7.2.2 Status Word

COAAL	Name	Setting method	Valid time	Default	Set range	Application category	Unit
6041h	Status word	Operation setting	Valid immediately	0	0~65535	-	-

Used to reflect the status of servo drive.

Bit	Name	Description
0	Same was die	0: Invalid
"	Servo ready	1: Valid
1	Sorve appration can be started	0: Invalid
•	Servo operation can be started	1: Valid
2	Servo operation	0: Invalid
	Servo operation	1: Valid
3	Fault	0: Invalid
	Tault	1: Valid
4	Electrical connection of main circuit	0: Invalid
	Electrical confection of main circuit	1: Valid
5	Quick shutdown	0: Invalid
	Quick shataown	1: Valid
6	Servo is not operational	0: Invalid
	Servo is not operational	1: Valid
7	Warning	0: Invalid
	waitiiig	1: Valid
8	-	-
9	Remote control	0: Invalid
	Remote Control	1: Valid
10	Target arrival	0: Invalid
10	iaiget ailivai	1: Valid

Bit 0 ~ bit 9 have the same meaning in all control modes of servo drive. After the control word 6040h sends commands in sequence, the servo feeds back the determined state.

Setting value (binary number)	Description
xxxx xxxx x0xx 0000	Servo is not ready

xxxx xxxx x1xx 0000	Startup failure	
xxxx xxxx x01x 0001	Servo ready	
xxxx xxxx x01x 0011	Start up	
xxxx xxxx x01x 0111	Servo enable	
xxxx xxxx x00x 0111	Fault shutdown valid	
хххх хххх х0хх 1111	Fault response valid	
хххх хххх х0хх 1000	Fault	

7.3 Servo Mode Settings

7.3.1 Servo Mode Introduction

The object dictionary 6060h is used to display servo modes supported by servo drives.

cocol	Name	Setting method	Valid time	Default	Set range	Application category	Unit
6060h	Servo mode selection	Stop setting	Valid immediately	0	0~10	-	-

Used to set the operation mode of servo drive.

Setting value	Name	Remark
0	-	
1	Contour position control mode	
2	-	
3	Contour speed control mode	
4	Contour torque control mode	Please refer to "7.7 Profile torque mode (PT)" for details
5	-	
6	Origin return mode	Please refer to "7.8 Homing Mode (HM)" for details
7	Interpolation mode	
8	Cyclic Synchronous Position mode	Please refer to "7.4 Cyclic Synchronous Position mode (CSP)" for details
9	Periodic synchronous speed mode	Please refer to "7.5 Cyclic Synchronous Velocity mode (CSV)" for details-
10	Periodic synchronous torque mode	Please refer to "7.6 Cyclic Synchronous Torque mode (CST)" for details

7.3.2 Mode Switching

Pay attention to the following when switching modes:

- 1 Whatever the servo drive state is, the unexecuted position command will be discarded after switching from the Cyclic Synchronous Position mode to other modes.
- 2 Whatever the servo drive state is, after switching into other modes from the periodic synchronous speed mode, servo first executes ramp shutdown, and then switch into other modes after the shutdown is completed.
- (3) When the servo drive is running the origin return mode, it is not allowed to switch to other modes; When origin return is completed or interrupted (failure or invalid enable), other modes can be switched into.

4 When the servo drive is in run state, when switching from other modes to periodic synchronous mode, please send command at an interval of at least 1ms, otherwise instructions will be lost or wrong.

7.3.3 Communication Cycles Supported by Different Modes

Mode Cycle time	Cyclic Synchronous Position mode	Cyclic Synchronous Velocity mode	Homing Mode
125us	V	•	~

7.4 Cyclic Synchronous Position Mode (CSP)

7.4.1 Control Block Diagram




Figure 7-7 Input and output Servo mode **Operating mode display** selection 6060h 6061h **Control word Status word** 6041h 6040h **Target position Position deviation** 607Ah 60F4h **Position Offset Position** 60B0h command 60FCh Control **Position reaches Actual position functions** threshold 6067h 6063h **Location** arrival **Actual speed** window 6068h 606Ch **Actual torque** Gear ratio 6091h 6077h **Excessive position** Error code 603Fh deviation threshold 6091h

object

7.4.2 Related Objects

(1) Control word 6040h

Bit	Name	Description
0	Servo operation can be started	
1	Turn on the main circuit	When bit0 to bit3 are
2	Quick shutdown	all 1, it indicates the start of operation
3	Servo operation	

(2) Status word 6041h

Bit	Name	Description
10	Target arrival	-
11	Software internal position overrun	-
12	Slave station following instruction	-
13	Following error	-
14	DDL motor angle identification complete	-
15	Origin return completed	-

Index (Hex)	Object dictionary name	Accessibility	Unit	Bit length	Set range
603F	Error code	RO	-	16	0 to 65535
6040	Control word	RW	-	16	0 to 65535
6041	Status word	RO	-	16	0 to 65535
6060	Servo mode selection	RW	-	8	0 to 10
6061	Run mode display	RO	-	8	0 to 10
6062	Position instruction	RO	Instruction unit	32	-
6063	Position feedback	RO	Encoder unit	32	-
6064	Position feedback	RO	Instruction unit	32	-
6065	Threshold of excessive position deviation	RW	Instruction unit	32	0 to 2 ³² -1
6067	Position reaches threshold	RW	Encoder unit	32	0 to 2 ³² -1
6068	Position arrival window	RW	ms	32	0 to 65535
606C	Actual speed	RO	Instruction		-

			unit/s		
6077	Actual torque	RO	0.1%		-5000 to 5000
607A	Target location	RW	Instruction unit	32	-2 ³¹ to 2 ³¹ -1
6091: 01	Electronic gear ratio numerator	RW	-	32	1 to 2 ³² -1
6091: 02	Electronic gear ratio denominator	RW	-	32	1 to 2 ³² -1
2002-01	1st position loop gain	RW	0.1Hz	16	0 to 6200
2002-02	1st speed loop gain	RW	0.1Hz	16	0 to 35000
2002-03	1st speed loop integral time constant	RW	0.1ms	16	10 to 65535
2002-09	Speed feedforward gain	RW	0.1%	16	0 to 1000
2002-0A	Speed feedforward filter time constant	RW	0.01ms	16	0 to 500
2002-0B	Torque feedforward gain	RW	0.1%	16	0 to 2000
2002-0C	Torque feedforward filter time constant	RW	0.01ms	16	0 to 10000

7.4.3 Related Function Settings

(1) Positioning Completed

Index (Hex)	Name	Content
6067	Positioning completion threshold	When the position deviation is in the range of 6067 and the time reach 6068, the positioning completion signal is valid.
6068	Positioning completion window	

(2) Position deviation limit

Index (Hex)	Name	Content
6065	Threshold of excessive position deviation	When the position deviation is greater than the set value of this parameter, Er.36 (excessive position deviation) will occur.

7.4.4 Recommended Configuration

Please refer to the following table for the basic configuration of this mode:

RPDO	TPDO	Remark
6040 (Control word)	6041 (Status word)	Required
607A (Target location)	6064 (Position feedback)	Required
6060 (Servo mode selection)	6061 (Running mode display)	Optional

7.5 Cyclic Synchronous velocity (CSV)




Figure 7-9 Cyclic synchronous speed mode control block diagram




Figure 7-10 Input and output objects

7.5.2 Related objects

(1) Control word 6040h

Bit	Name	Description
0	Servo operation can be started	
1	Connect the main circuit	When all of bit0-bit3 is 1, it means that it starts running
2	Quick stop	
3	Servo running	
8	Pause	

(2) Status word 6041h

Chapter 7 Operation Running

Bit	Name	Description
10	Target reach	
11	Software internal position overrun	
12	Slave station following instruction	
15	Homing completed	

Index (Hex)	Object dictionary name	Accessibility	Unit	Bit length	Range
603F	Error code	Read only		16	0 to 65535
6040	Control word	Read and write		16	0 to 65535
6041	Status word	Read only		16	0 to 65535
6060	Servo mode selection	Read and write		8	0 to 10
6061	Running mode display	Read only		8	0 to 10
6063	Position feedback	Read only	Encoder unit	32	
6064	Position feedback	Read only	Instruction unit	32	
606C	Actual speed	Read only	Instruction unit/s	32	
6077	Actual torque	Read only	0.1%		-3000 to 3000
607F	Maximum speed	Read and write	Instruction unit/s	32	0 to 2 ³² -1
6083	Acceleration	Read and write	Instruction unit/s²	32	0 to 2 ³² -1
6084	Deceleration	Read and write	Instruction unit/s²	32	0 to 2 ³² -1
60B1	Velocity bias	Read and write	Instruction unit/s	32	-2 ³¹ ~2 ³¹ -1
60B2	Torque offset	Read and write	0.1%	32	-3000 to 3000
60E0	Forward direction maximum torque limit	Read and write	0.1%	16	0 to 3000
60E1	Reverse direction maximum torque limit	Read and write	0.1%	16	0 to 3000
60FF	Target velocity	Read and write	Instruction unit/s	32	-2 ³¹ ~2 ³¹ -1
2002-02	1st speed loop gain	Read and write	0.1Hz	16	1 to 35000
2002-03	1st velocity loop integration time constant	Read and write	0.1ms	16	100 to 65535
2002-0B	Torque feedforward gain	Read and write	0.1%	16	0 to 2000
2002-0C	Torque feedforward filter time constant	Read and write	0.01ms	16	0 to 10000

7.5.3 Related Function Settings

(1) Speed arrival function

Index (Hex)	Name	Content
606D	Speed reached threshold	When the difference between the target speed 60FF (converted to motor speed/rpm) and the
606E	Velocity arrival window	actual motor speed is in the ±606D interval, and the time reaches 606E, the speed arrival signal is valid.

7.5.4 Recommended configuration

Please refer to the following table for the basic configuration of this mode:

RPDO	TPDO	Remark
6040 (Control word)	6041 (Status word)	Required
60FF (Target speed)	/	Required
/	6064 (Position feedback)	Optional
/	606C (Speed feedback)	Optional
6060 (Servo mode selection)	6061 (running mode display)	Optional

7.6 Cyclic Synchronous Torque Mode (CST)

7.6.1 Control block diagram




Figure 7-11 Cyclic synchronous torque mode control block diagram




Figure 7-12 Input and output objects

7.6.2 Related objects

(1) Control word 6040h

Bit	Name	Description
0	Servo operation can be started	
1	Connect the main circuit	When all of bit0-bit3 is 1, it means
2	Quick stop	that it starts running
3	Servo running	
8	Pause	0: Servo settings at bit0~bit3 1: The servo is set at 60D5h

(2) Status word 6041h

Bit	Name	Description
10	Target reach	
12	Slave station following instruction	
15	Homing completed	

Index (Hex)	Object dictionary name	Accessibility	Unit	Bit length	Range
603F	Error code	Read only		16	0 to 65535
6040	Control word	Read and write		16	0 to 65535
6041	Status word	Read only		16	0 to 65535
6060	Servo mode selection	Read and write		8	0 to 10

Chapter 7 Operation Running

6061	Running mode display	Read only		8	0 to 10
606C	Actual speed	Read only	Instruction unit/s		
6071	Target torque	Read and write	0.1%	16	-3000 to 3000
6074	Torque instruction	Read only	0.1%	16	-3000 to 3000
6077	Actual torque	Read only	0.1%	16	-3000 to 3000
607F	Maximum speed	Read and write	Instruction unit/s	32	0 to 2 ³² -1
60B2	Torque offset	Read and write	0.1%	32	-3000 to 3000
60E0	Forward direction maximum torque limit	Read and write	0.1%	16	0 to 3000
60E1	Reverse direction maximum torque limit	Read and write	0.1%	16	0 to 3000
2002-02	1st speed loop gain	Read and write	0.1Hz	16	1 to 35000
2002-03	1st velocity loop integration time constant	Read and write	0.1ms	16	100 to 65535
2002-0B	Torque feedforward gain	Read and write	0.1%	16	0 to 2000
2002-0C	Torque feedforward filter time constant	Read and write	0.01ms	16	0 to 10000

7.6.3 Recommended configuration

Please refer to the following table for the basic configuration of this mode:

RPDO	TPDO	Remark
6040 (Control word)	6041 (Status word)	Required
6071 (Target torque)	/	Required
/	6064(Position feedback)	Optional
/	606C (Speed feedback)	Optional
/	6077 (torque feedback)	Optional
6060 (Servo mode selection)	6061 (running mode display)	Optional

7.7 Profile Torque Mode (PT)

7.7.1 Control block diagram




Figure 7-13 Profile torque mode control block diagram




Figure 7-14 Input and output objects

7.7.2 Related objects

(1) Control word 6040h

Bit	Name	Description
0	Servo can be started	
1	Connect the main circuit	When all of bit0-bit3 is all 1, it means
2	Quick stop	that it starts running
3	Servo running	
8	Pause	0: Servo settings at bit0-bit3
8	rause	1: The servo is set at 60D5h

(2) Status word 6041h

Bit	Name	Description
10	Target reach	

11	Software internal position exceeds limit	
15	Homing completed	

Index (Hex)	Object dictionary name	Accessibility	Unit	Bit length	Range
603F	Error code	Read only		16	0 to 65535
6040	Control word	Read and write		16	0 to 65535
6041	Status word	Read only		16	0 to 65535
6060	Servo mode selection	Read and write		8	0 to 10
6061	Running mode display	Read only		8	0 to 10
606C	Actual speed	Read only	Instruction unit/s		
6071	Target torque	Read and write	0.1%	16	-3000 to 3000
6072	Maximum torque	Read and write	0.1%	16	-3000 to 3000
6074	Torque instruction	Read only	0.1%	16	-3000 to 3000
6077	Actual torque	Read only	0.1%	16	-3000 to 3000
607F	Maximum speed	Read and write	Instruction unit/s	32	0 to 2 ³² -1
6087	Torque ramp	Read and write	0.1%/s	32	0 to 2 ³² -1
60E0	Forward direction maximum torque limit	Read and write	0.1%	16	0 to 3000
60E1	Reverse direction maximum torque limit	Read and write	0.1%	16	0 to 3000
2002-02	1st speed loop gain	Read and write	0.1Hz	16	1 to 35000
2002-03	1st velocity loop integration time constant	Read and write	0.1ms	16	100 to 65535
2002-0B	Torque feedforward gain	Read and write	0.1%	16	0 to 2000
2002-0C	Torque feedforward filter time constant	Read and write	0.01ms	16	0 to 10000

7.7.3 Recommended configuration

Please refer to the following table for the basic configuration of this mode:

RPDO	TPDO	Remark
6040 (Control word)	6041 (Status word)	Required
6071 (Target torque)	/	Required
/	6064 (Position feedback)	Optional
/	606C (Speed feedback)	Optional
/	6077 (Torque feedback)	Optional

6060 (Servo mode selection)	6061 (Running mode display)	Optional
-----------------------------	-----------------------------	----------

7.8 Homing Mode (HM)

The homing mode is used to find the mechanical origin and locate the positional relationship between the mechanical origin and the mechanical zero.

Mechanical origin: A fixed position on the machine can correspond to a certain origin switch, which can correspond to the Z signal of the motor.


Mechanical origin: Mechanical absolute origin position.


After the origin returns to zero, the stop position of the motor is the mechanical origin. By setting 607Ch, the relationship between the mechanical origin and the mechanical zero can be set:

Mechanical origin = mechanical zero + 607Ch (origin offset)

When 607Ch=0, the mechanical origin is the same with mechanical zero.

7.8.1 Control Block Diagram





7.8.2 Related Objects

(1) Control word 6040h

Bit	Name	Description
0	Servo operation can be started	
1	Turn on the main circuit	When his to his 2 are all 1, it indicates the stort of angustion
2	Quick shutdown	When bit0 to bit3 are all 1, it indicates the start of operation
3	Servo operation	
4	Homing	0 → 1: Start homing
4	Homing	1 → 0: End homing

(2) Status word 6041h

Bit	Name	Description
10	Target arrival	-
12	Slave station following instruction	-
13	Following error	-
15	Origin return completed	-

7.8.3 Introduction of homing Mode


Note: In the figure, "H" stands for 6099: 01h (search for deceleration point signal speed), and "L" stands for 6099: 02h (search for origin signal speed).

(1) 6098H = 1


Mechanical origin: Z signal of motor

Deceleration point: Reverse limit switch (NOT)

1 The deceleration point signal is invalid when starting homing.



NOT=0 when starting homing, start homing in reverse direction at high speed. After the rising edge of NOT, slow down, change running direction and run in forward direction at low speed, and stop at first Z signal when encountering the falling edge of NOT.




NOT=1 when starting homing, run in forward direction immediately at low speed and start homing, and stop at the first Z signal when encountering the falling edge of NOT.

(2)6098H = 2


Mechanical origin: Z signal of motor

Deceleration point: Forward limit switch (POT)

1 The deceleration point signal is invalid when starting homing



POT=0 when starting homing, run at a high speed in the forward direction. After encountering the rising edge of POT, motor will decelerate, run in reverse direction at low speed, and stop at the first Z signal after encountering the falling edge of POT.




POT=1 when starting homing, run at low speed directly in the reverse direction, and stops at the first Z signal after encountering the falling edge of POT.

(3)6098H = 3

Mechanical origin: Z signal of motor

Deceleration point: Origin switch (HW)


1 The deceleration point signal is invalid when starting homing



HW=0 when starting homing, start homing in forward direction at high speed. After encountering rising edge of HW, slow down, run in reverse direction at low speed. After

encountering the falling edge of HW, continue to run, and then stop when encountering the first Z signal.

2 The deceleration point signal is valid when starting homing




HW=1 when starting homing, start homing at low speed in reverse direction directly, and stop at the first Z signal after encountering the falling edge of HW;

(4) 6098H = 4


Mechanical origin: Z signal of motor

Deceleration point: Origin switch (HW)



HW=0 when starting homing, start to homing at low speed in forward directly, and stop at the first Z signal after encountering the rising edge of HW;

2 The deceleration point signal is valid when starting homing




HW=1 when starting homing, start return to zero at high speed in reverse direction, slow down after encountering the falling edge of HW, change running direction and run in forward direction at low speed, and stop at the first Z signal after encountering the rising edge of HW;

(5)6098H = 5

Mechanical origin: Z signal of motor


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing



HW=0 when starting to return to zero, start to return to zero at high speed in reverse direction, slow down after encountering the rising edge of HW, change running direction and run in forward direction at low speed, and stop at the first Z signal after encountering the falling edge of HW;

(2) The deceleration point signal is valid when starting to return to zero




HW=1 when starting to return to zero, start to return to zero at low speed in forward direction directly, and stop at the first Z signal after encountering the falling edge of HW will stop;

(6)6098H = 6


Mechanical origin: Z signal of motor

Deceleration point: Origin switch (HW)



HW=0 when starting homing, start to return to zero at low speed in reverse direction directly, and stop at the first Z signal after encountering the rising edge of HW;

2 The deceleration point signal is valid when starting homing




HW=1 when starting homing, start homing at high speed in forward direction, slow down after encountering the falling edge of HW, change running direction and run in reverse direction at low speed, and stop at the first Z signal after encountering the rising edge of HW;

(7) 6098H = 7

Mechanical origin: Z signal of motor


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing, the forward limit switch is not encountered




HW=0 when starting to return to zero, start homing at high speed in forward direction. If the limit switch is not encountered, after encountering the rising edge of HW, slow down, change running direction and run in reverse direction at low speed, and stop at the first Z signal after encountering the falling edge of HW;

2 The deceleration point signal is invalid when starting homing, the forward limit switch is encountered



HW=0 when starting to return to zero, start homing at high speed in forward direction. If the limit switch is encountered, automatically change running direction and run in reverse direction at high speed. After encountering HW rising edge, slow down and continue to run at low speed in reverse direction, stop at the first Z signal after encountering the falling edge of HW;




HW=1 when starting to return to zero, start to return to zero at low speed in reverse direction directly, and stop at the first Z signal after encountering the falling edge of HW;

(8) 6098H = 8

Mechanical origin: Z signal of motor


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting to return to zero, the forward limit switch is not encountered




HM-0 when starting homing, start homing at high speed in forward direction. If the limit switch is not encountered, after encountering the rising edge of HW, slow down and change running direction and run in reverse direction at low speed. After encountering the falling edge of HW, change the running direction and run in forward direction at low speed, and stop at the first Z signal after encountering the rising edge of HW;

2 The deceleration point signal is invalid when starting to return to zero, the forward limit switch is encountered



HW=0 when starting homing, start homing at high speed in forward direction. If limit switch is encountered, automatically change running direction and run in reverse direction at high speed, slow down and run in reverse direction at low speed after encountering HW rising edge; change running direction and run in reverse direction at low speed after encountering HW falling edge, and stop at the first Z signal after encountering HW rising edge;




HM=-1 when starting homing, start homing at low speed in reverse direction directly. After encountering the falling edge of HW, change running direction and run in forward direction at low speed, and stop at the first Z signal after encountering the rising edge of HW;

(9)6098H = 9

Mechanical origin: Z signal of motor


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing, the forward limit switch is not encountered




HW=0 when starting homing, start homing at high speed in forward direction. If the limit switch is not encountered, slow down after encountering the rising edge of HW, run at low speed in forward direction; change running direction and run in reverse direction at low speed after encountering the falling edge of HW, and stop at the first Z signal after encountering the rising edge of HW;

2 The deceleration point signal is invalid when starting homing, the forward limit switch is encountered



HW=0 when starting homing, start homing at high speed in forward direction. If the limit switch is encountered, change the running direction automatically and run in reverse direction at high speed; slow down and change the running direction after encountering the rising edge of HW to resume forward operation. Run in forward direction at low speed and change the running direction after encountering the falling edge of HW; stops at first Z signal after encountering the rising edge of HW during running in reverse direction at low speed;




HW=1 when starting homing, start to return to zero directly at low speed in forward direction.

After encountering the falling edge of HW, change the running direction and stop at the first Z signal after encountering the rising edge of HW during running in reverse direction at low speed; (10) 6098H=10

Mechanical origin: Z signal of motor


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing, the forward limit switch is not encountered




HW=0 when starting homing, start homing at high speed in forward direction. If the limit switch is not encountered, slow down and run at low speed in forward direction after encountering the rising edge of HW. After encountering the falling edge of HW, continue to run at low speed in forward, and then stop at the first Z signal encountered;

2 The deceleration point signal is invalid when starting homing, the forward limit switch is encountered



HW=0 when starting homing, start homing at high speed in forward direction. If the limit switch is encountered, change the running direction automatically and run in reverse direction at high speed. After encountering the rising edge of HW, slow down and change the running direction to resume forward operation, and stop at the first Z signal after encountering the falling edge of HW during running in forward direction at low speed;




HW=1 when starting homing, start homing directly in forward direction at low speed, and stop at the first Z signal after encountering the falling edge of HW;

(11) 6098H=11

Mechanical origin: Z signal of motor


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing the reverse limit switch is not encountered




HW=0 when starting homing, start homing at high speed in reverse direction. If the limit switch is not encountered, slow down and change the running direction after encountering the rising edge of HW, and run in forward direction at low speed and stop at the first Z signal after encountering the falling edge of HW;

2 The deceleration point signal is invalid when starting homing, the reverse limit switch is encountered



HW=0 when starting homing, start to homing at high speed in reverse direction. If limit switch is encountered, change the running direction automatically and run in forward direction at high speed. After encountering HW rising edge, slow down and continue to run in forward direction at low speed. Stop at the first Z signal after encountering HW falling edge;




HW=1 when starting homing, it will start homing directly in forward direction at low speed, and stop at the first Z signal after encountering the falling edge of HW;

(12) 6098H=12

Mechanical origin: Z signal of motor


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing, the reverse limit switch is not encountered




HW=0 when starting homing, start homing in reverse direction at high speed; if limit switch is not encountered; slow down and change the running direction after encountering HW rising edge, run in forward direction at low speed; after encountering HW falling edge, change the running direction and run in reverse direction at low speed and stop at the first Z signal after encountering HW rising edge;

2 The deceleration point signal is invalid when starting homing, the reverse limit switch is encountered



HW=0 when starting to return to zero, start to return to zero in reverse direction at high speed, change the running direction automatically when encountering limit switch and run in forward direction at high speed; slow down after encountering HW rising edge and run in forward direction at low speed; change the running direction after encountering HW falling edge, and run in reverse direction at low speed and stop at the first Z signal after encountering HW rising edge;




HW=1 when starting homing, start homing in forward direction at low speed. After encountering the falling edge of HW, change the running direction and run in reverse direction at low speed, and stop at the first Z signal after encountering the rising edge of HW;

(13) 6098H=13

Mechanical origin: Z signal of motor


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing, the reverse limit switch is not encountered



HW=0 when starting homing, start homing in reverse direction at high speed. If the limit switch is not encountered, slow down and run in reverse direction at low speed after encountering the rising edge of HW. After encountering the falling edge of HW, change the running direction and run in forward direction at low speed, and stop at the first Z signal after encountering the rising edge of HW;


2 The deceleration point signal is invalid when starting homing, the reverse limit switch is encountered



HW=0 when starting homing, start homing in reverse direction at high speed, change the running direction automatically and run in forward direction at high speed when encountering

limit switch, slow down and change the running direction after encountering HW rising edge; run in reverse direction at low speed and change the running direction after encountering HW falling edge; stop at the first Z signal after encountering HW rising edge during running in forward direction at low speed;

3 The deceleration point signal is valid when starting homing




HW=1 when starting homing, start homing directly in reverse direction at low speed. After encountering the falling edge of HW, change the running direction; stop at the first Z signal after encountering the rising edge of HW during running in forward direction at low speed;

(14) 6098H=14

Mechanical origin: Z signal of motor


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting to return to zero, the reverse limit switch is not encountered




HW=0 when starting homing, start to return to zero in reverse direction at high speed; if limit switch is not encountered; slow down and run in reverse direction at low speed after encountering HW rising edge; after encountering HW falling edge, continue to run in reverse direction at low speed, and then stop at the first Z signal encountered;

2 The deceleration point signal is invalid when starting homing, the reverse limit switch is encountered



HW=0 when starting homing, start homing in reverse direction at high speed; change the running direction automatically and run in forward direction at high speed when encountering limit switch; slow down and change the running direction when encountering HW rising edge, and stop at the first Z signal after encountering HW falling edge during running in reverse direction at low speed;

3 The deceleration point signal is valid when starting homing




HW=1 when starting homing, start homing in reverse direction at low speed directly, and stop at the first Z signal after encountering the falling edge of HW;

(15) 6098H=17


Mechanical origin: reverse overrun switch (NOT)

Deceleration point: Reverse overrun switch (NOT)



NOT=0 when starting homing, start homing in reverse direction at high speed, slow down and change the running direction after encountering the rising edge of NOT, and run in forward direction at low speed, and stop after encountering the falling edge of NOT;

(2) The deceleration point signal is valid when starting homing




NOT = 1 when starting to return to zero, start homing in forward direction at low speed directly, and stop after encountering the falling edge of NOT.

(16) 6098H=18


Mechanical origin: Forward overtravel switch (POT)

Deceleration point: Forward overtravel switch (POT)



POT=0 when starting homing, start homing in forward direction at high speed, slow down and change the running direction after encountering the rising edge of POT, run in reverse direction at low speed, and stop after encountering the falling edge of POT;

2 The deceleration point signal is valid when starting homing




POT=1 when starting homing, start homing in reverse direction at low speed directly, and stop when encountering POT falling edge;

(17) 6098H=19


Mechanical Origin: Origin Switch (HW)

Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing



HW=0 when starting homing, start homing in forward direction at high speed, slow down and change the running direction after encountering the rising edge of HW, and run in reverse direction at low speed, and stop when encountering the falling edge of HW;




HW=1 when starting homing, start homing in reverse direction at low speed directly, and stop when encountering HW falling edge;

(18) 6098H=20

Mechanical Origin: Origin Switch (HW)


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing



HW=0 when starting homing, start homing forward direction at low speed directly, and stop after encountering the rising edge of HW;

2 The deceleration point signal is valid when starting homing




HW=1 when starting homing, start to return to zero in reverse direction at high speed, slow down and change the running direction after encountering HW falling edge, run in forward direction at low speed, and stop when encountering HW rising edge;

(19) 6098H=21

Mechanical Origin: Origin Switch (HW)


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing



HW=0 when starting homing, start homing in reverse direction at high speed, slow down and change the running direction after encountering the rising edge of HW, run in forward direction at low speed, and stop when encountering the falling edge of HW;

The deceleration point signal is valid when starting homing




HW=1 when starting homing, start homing in forward direction at low speed directly, and stop after encountering the falling edge of HW;

(20)6098H=22

Mechanical Origin: Origin Switch (HW)


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting to return to zero



HW=0 when starting homing, start homing in reverse direction at low speed directly and stop when encountering HW rising edge;

2 The deceleration point signal is valid when starting homing




HW=1 when starting to return to zero, start to return to zero in forward direction at high speed, slow down and change the running direction after encountering HW falling edge, run in reverse direction at low speed, and stop when encountering HW rising edge;

(21)6098H=23

Mechanical Origin: Origin Switch (HW)


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing, the forward limit switch is not encountered




HW=0 when starting homing, start homing in forward direction at high speed; limit switch is not encountered; slow down and change the running direction after encountering HW rising edge; run in reverse direction at low speed and stop when encountering HW falling edge;

2 The deceleration point signal is invalid when starting homing, the forward limit switch is encountered



HW=0 when starting to return to zero, start to return to zero in forward direction at high speed, change the running direction automatically when encountering limit switch, run in reverse direction at high speed and slow down when encountering HW rising edge, continue to run in reverse direction at low speed, and stop when encountering HW falling edge;

3 The deceleration point signal is valid when starting homing



HW=0 when starting homing, start homing in forward direction at high speed, change the running direction automatically when encountering limit switch, run in reverse direction at high


speed and slow down when encountering HW rising edge, continue to run in reverse direction at low speed, and stop when encountering HW falling edge;

(22)6098H=24

Mechanical Origin: Origin Switch (HW)


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing, the forward limit switch is not encountered




HW=0 when starting homing, start homing in forward direction at high speed; limit switch is not encountered; slow down and change the running direction after encountering HW rising edge, then run in reverse direction at low speed, and change the running direction when encountering HW falling edge, run in forward direction at low speed and stop when encountering HW rising edge;

2 The deceleration point signal is invalid when starting homing, the forward limit switch is encountered



HW=0 when starting homing, start homing in forward direction at high speed; change the running direction automatically when encountering limit switch, run in reverse direction at high speed and slow down and run in reverse direction at low speed when encountering HW rising edge; change the running direction and run in forward direction at low speed when encountering HW falling edge, and stop when encountering HW rising edge;

3 The deceleration point signal is valid when starting homing




HW=1 when starting homing, start homing in reverse direction at low speed directly; after encountering the falling edge of HW, change the running direction and run in forward direction at low speed, and stop when encountering the rising edge of HW;

(23)6098H=25

Mechanical Origin: Origin Switch (HW)


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing, the forward limit switch is not encountered




HW=0 when starting homing, start homing in forward direction at high speed; limit switch is not encountered; slow down after encountering HW rising edge, run in forward direction at low speed, change the running direction and run in reverse direction at low speed after encountering HW falling edge, and stop when encountering HW rising edge;

2 The deceleration point signal is invalid when starting homing, the forward limit switch is encountered



HW=0 when starting homing, start homing in forward direction at high speed, change the running direction automatically and run in reverse direction at high speed when encountering limit switch; slow down and change the running direction after encountering HW rising edge to resume forward operation; run in forward direction at low speed and change the running direction after encountering HW falling edge; run in reverse direction at low speed and stop when encountering HW rising edge;

3 The deceleration point signal is valid when starting homing




HW=1 when starting homing, when, start homing in the forward direction at low speed directly. After encountering the falling edge of HW, change the running direction and run in verse direction at low speed and stop when encountering the rising edge of HW.

(24) 6098H=26

Mechanical Origin: Origin Switch (HW)


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing, the forward limit switch is not encountered




HW=0 when starting homing, start homing in forward direction at high speed; limit switch is not encountered; slow down after encountering HW rising edge, run in forward direction at low speed, and stop when encountering HW falling edge;

2 The deceleration point signal is invalid when starting homing, the forward limit switch is encountered



HW=0 when starting homing, start homing in forward direction at high speed, change the running direction automatically and run in reverse direction at high speed when encountering limit switch; slow down and change the running direction when encountering HW rising edge to resume forward operation, run in forward direction at low speed and stop when encountering HW falling edge;

3 The deceleration point signal is valid when starting homing




HW=1 when starting to return to zero, start homing in forward direction at low speed directly, and stop when encountering HW falling edge;

(25) 6098H=27

Mechanical Origin: Origin Switch (HW)


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing, the reverse limit switch is not encountered




HW=0 when starting homing, start homing in reverse direction at high speed; limit switch is not encountered; slow down and change the running direction after encountering rising edge of HW, run in forward direction at low speed and stop when encountering HW falling edge;

2 The deceleration point signal is invalid when starting homing, the reverse limit switch is encountered



HW=0 when starting homing, start homing in reverse direction at high speed, change the running direction automatically when encountering limit switch and run in forward direction at high speed; slow down when encountering HW rising edge, continue to run in forward direction at low speed and stop when encountering HW falling edge;

3 The deceleration point signal is valid when starting homing




HW=1 when starting homing, start homing in forward direction at low speed directly, and stop when encountering HW falling edge;

(26) 6098H=28

Mechanical Origin: Origin Switch (HW)


Deceleration point: Origin switch (HW)

① The deceleration point signal is invalid when starting homing, the reverse limit switch is not encountered




HW=0 when starting homing, start homing in reverse direction at high speed; limit switch is not encountered; slow down and change the running direction after encountering HW rising edge, run in forward direction at low speed; change the running direction after encountering HW falling edge, run in reverse direction at low speed and stop when encountering HW rising edge;

2) The deceleration point signal is invalid when starting homing, the reverse limit switch is encountered



HW=0 when starting homing, start homing in reverse direction at high speed, change the running direction automatically when encountering limit switch and run in forward direction at high speed; slow down and run in forward direction at low speed when encountering HW rising edge; change the running direction and run in reverse direction at low speed when encountering HW falling edge, and stop when encountering HW rising edge;

3 The deceleration point signal is valid when starting homing




HW=1 when starting homing, start homing in forward direction at low speed directly. After encountering the falling edge of HW, change the running direction and run in reverse direction at low speed and stop when encountering the rising edge of HW;

(27) 6098H=29

Mechanical Origin: Origin Switch (HW)


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing, the reverse limit switch is not encountered




HW=0 when starting homing, start homing in reverse direction at high speed directly; limit switch is not encountered; slow down after encountering HW rising edge, run in reverse direction at low speed; change the running direction after encountering HW falling edge and run in forward direction at low speed and stop when encountering HW rising edge;

2 The deceleration point signal is invalid when starting homing, the reverse limit switch is encountered



HW=0 when starting homing, start homing in reverse direction at high speed, change the running direction automatically when encountering limit switch and run in forward direction at high speed; slow down and change the running direction when encountering HW rising edge; run in reverse direction at low speed; change the running direction after encountering the falling edge of HW, then run in forward direction at low speed and stop when encountering HW rising edge;

3 The deceleration point signal is valid when starting homing



HW=1 when starting homing, start to return to zero in reverse direction at low speed directly.


After encountering the falling edge of HW, change the running direction; stop when encountering the rising edge of HW during running in forward direction at low speed.

(28) 6098H=30

Mechanical Origin: Origin Switch (HW)


Deceleration point: Origin switch (HW)

1 The deceleration point signal is invalid when starting homing, the reverse limit switch is not encountered




HW=0 when starting homing, start to return to zero in reverse direction at high speed; limit switch is not encountered; slow down after encountering HW rising edge, run in reverse direction at low speed, and stop when encountering HW falling edge;

2 The deceleration point signal is invalid when starting homing, the reverse limit switch is encountered



HW=0 when starting homing, start homing in reverse direction at high speed, change the running direction automatically when encountering limit switch and run in forward direction at high speed; slow down and change the running direction when encountering HW rising edge, and stop when encountering HW falling edge during running in reverse direction at low speed;

3 The deceleration point signal is valid when starting homing



HW=1 when starting homing, start to return to zero in reverse direction at low speed directly, and stop when encountering HW falling edge;


(29) 6098H=33 and 34

Mechanical origin: Z signal

Deceleration point: None

Zero return mode 33: running in reverse direction at low speed, stop at the first Z signal encountered

Zero return mode 34: running in forward direction at low speed, stop at the first Z signal encountered



(30) 6098h=35

Zero returning mode 35: take the current position as the mechanical origin, and after triggering the origin to return to zero (6040 control word: $0xOF \rightarrow 0x1F$). After the zero return is completed, the position feedback 6064h is set to the origin offset 607Ch.

7.9 Accessibility Function

7.9.1 Touch Probe

The probe function refers to the function of the servo drive recording the current position information (command unit) and storing it in the specified register when the DI signal or motor Z signal specified by the external device changes. Please pay attention to the following when using it:

- ① In the case of the same probe, try to avoid using the rising edge and the falling edge at the same time;
- 2 When using the Z signal, only the rising edge can be used, not the falling edge;
- ③ For single-trigger probes, if you need to trigger again, please clear 60B8h to 0 before setting the value. The VD3E bus servo drive supports 2 types of probe functions, then DI5 is probe 1 and DI6 is probe 2.

Probe 1 enable 0	
1: Enable probe 1 Probe 1 trigger mode. 1: Probe 1 rising edge latch. 1: Continuous trigger Probe 1 trigger signal selection. Probe 1 falling edge latch. 2: Probe 1 falling edge latch not executed probe 1 trigger signal selection. Probe 1 falling edge latch. Probe 1 falling edge latch not executed probe 1: Probe 1 falling edge latch not executed probe 1: Probe 1 falling edge latch not executed probe 1: Probe 1 falling edge latch executed probe 1: Probe 1 falling edge latch executed probe 1 rising edge latch. Reserve Probe 1 rising edge latch. Probe 1 rising edge latch. Reserve	
Probe 1 trigger mode. 1 0: Single trigger 1: Continuous trigger 1: Probe 1 rising edge latch not executed Probe 1 trigger signal selection. Probe 1 falling edge latch. 2 0: DI5 trigger 0: Probe 1 falling edge latch not executed 1: Z signal trigger 1: Probe 1 falling edge latch not executed 1: Z signal trigger Reserve Probe 1 rising edge latch. Reserve Probe 1 rising edge latch. Reserve Probe 1 rising edge latch. Reserve	
1 0: Single trigger 0: Probe 1 rising edge latch not executed 1: Continuous trigger 1: Probe 1 rising edge latch executed Probe 1 trigger signal selection. Probe 1 falling edge latch. 2 0: DI5 trigger 0: Probe 1 falling edge latch not executed 1: Z signal trigger 1: Probe 1 falling edge latch executed Reserve Reserve Probe 1 rising edge latch. 4 0: Do not use probe 1 rising edge latch Reserve	
1: Continuous trigger 1: Probe 1 rising edge latch executed Probe 1 trigger signal selection. Probe 1 falling edge latch. 0: Probe 1 falling edge latch not execut 1: Z signal trigger 1: Probe 1 falling edge latch executed Reserve Probe 1 rising edge latch. O: Do not use probe 1 rising edge latch Reserve	
Probe 1 trigger signal selection. Probe 1 falling edge latch. Probe 1 falling edge latch not executed 1: Z signal trigger Reserve Probe 1 rising edge latch. Reserve Probe 1 rising edge latch. Reserve Reserve	d
2 0: DI5 trigger 0: Probe 1 falling edge latch not executed 1: Z signal trigger 1: Probe 1 falling edge latch executed 3 Reserve Reserve Probe 1 rising edge latch. 4 0: Do not use probe 1 rising edge latch Reserve	
1: Z signal trigger 1: Probe 1 falling edge latch executed Reserve Probe 1 rising edge latch. 4 0: Do not use probe 1 rising edge latch Reserve	
3 Reserve Reserve Probe 1 rising edge latch. 4 0: Do not use probe 1 rising edge latch Reserve	∍d
Probe 1 rising edge latch. 4 0: Do not use probe 1 rising edge latch Reserve	
4 0: Do not use probe 1 rising edge latch Reserve	
1: Use probe 1 rising edge latch	
Probe 1 falling edge latch.	
5 0: Do not use probe 1 falling edge latch Reserve	
1: Use probe 1 falling edge latch	
Probe 1 trigger signal selection.	
Reserve 6 0: DI5 trigger	

Chapter 7 Operation Running

	Chapter 7 Operation Running					
		1: Z signal trigger				
7	Reserve	Probe 1 triggers DI signal selection. 0: DI5 is low level 1: DI5 is high level				
	Probe 2 enable	Probe 2 enable				
8	0: Disable probe 2	0: Disable probe 2				
	1: Enable probe 2	1: Enable probe 2				
	Probe 2 trigger mode.	Probe 2 rising edge latch.				
9	0: Single trigger	0: Probe 2 rising edge latch not executed				
	1: Continuous trigger	1: Probe 2 rising edge latch executed				
	Probe 2 trigger signal selection.	Probe 2 falling edge latch.				
10	0: DI6 trigger	0: Probe 2 falling edge latch not executed				
	1: Z signal trigger	1: Probe 2 falling edge latch executed				
11	Reserved	Reserved				
12	Probe 2 rising edge latch. 0: Do not use probe 2 rising edge latch 1: Use probe 2 rising edge latch	Reserve				
13	Probe 2 falling edge latch. 0: Do not use probe 2 falling edge latch 1: Use probe 2 falling edge latch	Reserve				
14	Reserve	Probe 2 trigger signal selection. 0: DI6 trigger 1: Z signal trigger				
15	Reserve	Probe 2 triggers DI signal selection. 0: DI6 is low level 1: DI6 is high level				

1. Set the probe to trigger the DI signal: The DI functions corresponding to probe 1 and probe 2 are DI5 and DI6 by default.

Note: ◆ If other functions such as command inversion are set for P6-14 and P6-17, the use of the probe function will not be affected. That is, when DI5 or DI6 is started, the probe function and the corresponding function code function will take effect together and will not affect each other.

Servo Parameter	Description
P6-14	The default setting of DI5
P0-14	terminal function is probe 1
P6-17	The default setting of DI6
P0-17	terminal function is probe 2
	DI5 logic selection.
P6-15	0: Low level is valid
	1: High level is valid
	DI6 logic selection.
P6-18	0: Low level is valid
	1: High level is valid

2. Set the probe function (60B8h) and probe status word (60B9h). The meaning of each bit is shown in the following table. For example, if you use the rising and falling edges of probe 1 and probe 2, and DI single trigger, set 60B8h=3131h (12593 in decimal). When DI5 and DI6 signals are rising, probe 1 and probe 2 will latch at 60 BAh and 60BCh respectively; when DI5 and DI6 signals are falling, probe 1 and probe 2 will latch at 60 BBh and 60BDh respectively. If you want to perform single trigger again, you need to set 60B8h=0, 60B8h=3131h.

Index (Hex)	Object dictionary	R/O	Unit	Bits	Setting range
60B8	Touch probe function	Read and write	-	16	0~65535
60B9	Touch probe status word	Read only	-	16	0~65535
60BA	Probe 1 rising edge position	Read only	Instruction unit	32	-2147483648~2147483647
60BB	Probe 1 falling edge position	Read only	Instruction unit	32	-2147483648~2147483647
60BC	Probe 2 rising edge position	Read only	Instruction unit	32	-2147483648~2147483647
60BD	Probe 2 falling edge position	Read only	Instruction unit	32	-2147483648~2147483647

8.1 Overview of Object Dictionaries

8.1.1 Object Dictionary Area Allocation

The object dictionary of CoE (CANopen over EtherCAT) specified in CIA 402 and the object dictionary of VD3E series are composed as follows:

Index	Content
0000h~ 0FFFh	Data type region
1000h~ 1FFFh	Communication subprotocol area
2000h~ 5FFFh	Vendor customized area
6000h~ 9FFFh	Standard equipment subprotocol area
A000h~ FFFFh	Reserved

8.1.2 Explanation of Related Terms in Object Dictionary

★Index: The position of objects of the same class in the object dictionary, expressed in hexadecimal.

★Sub-index: Under the same index, there are multiple objects, and each object is biased under the same index.

*****Accessibility: See the following table for details:

Accessibility	Description
RW	Read and write
RO	Read only
WR_PREOP	Writable in preop mode

★Can you map: See the following table for details:

Accessibility	Description
NO	Unmappable
RPDO	Can be used as RPDO
TPDO	Can be used as TPDO

★Set to take effect: See the following table for details:

Chapter 8 Object Dictionary

	<u>'</u> _		
Set conditions	Description	Set conditions	Description
Shutdown setting	It can be set in the shutdown state	Valid immediately	The set value will take effect immediately after the parameter is modified and downloaded
Operation setting	Can be set in any state	Power-on again	After the parameters are modified and downloaded, the servo drive needs to be powered down and then powered up, and the set value can take effect

★Data display range: upper and lower limits of parameters.

★Default value: The factory setting value of the parameter.

★Data type: The type of data, as shown in the following table:

-128 ~ 127 0 ~ 255 -32768 ~ 32767
-32768 ~ 32767
0~65535
-21247483648 ~ 21247483647
0~4294967295
ASCII

★Related modes: See the following table for specific contents:

Accessibility	Description
ALL	This parameter is related to all modes
CSP/CSV/HM	This parameter is only related to the corresponding mode
-	This parameter is independent of the control mode

8.2 Communication Sub-protocol Area (1000h to 1FFFh)

1000	Parameter name	Accessibility	Data mapping	Data type	Data display range	Default	Correlation mode	
	Device Type (Device Type)	RO	No	UDINT	-	-	-	
Used to describe the CoE device subprotocol type.								

1001	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode		
	Error register (Error register)	RO	No	USINT	-	0x00	-		
Used to describe error records.									

1008	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
	Device name (Device name)	RO	No	STRING	-	-	-
Used to	describe the device name.		,				

	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode		
1009	Manufacturer hardware version								
	(Manufacturer Hardware Version)	RO	No	STRING	-	-	-		
Used to describe the manufacturer hardware version									

	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
100A	Manufacturer software version (Manufacturer Software Version)	RO	No	STRING	-	-	-
Used to	describe the Manufacturer software	version					

1018	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode				
	ID Object (ID Object)	-	-	-	-	-	-				
Used to	Used to describe device information.										
01h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode				
	Vendor ID (Vendor ID)	RO	No	UDINT	-	0x00000EFF	-				

02h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
	Product Code (Product Code)	RO	No	UDINT	-	0x10003101	-
Used to	describe the encoding inside the d	rive.					
03h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
0311	Revision Number (Revision Number)	RO		UDINT	-	0x0000001	-
Upgrade	e record number used to describe the	ne drive.					
04h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
	Serial Number (Serial Number)	RO	No	UDINT	-	0x00001419	-

1600	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
	RxPDO	-	-	-	-	-	-
Mappin	g object for setting RxPDO.						,
01h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
0111	First mapping object (RxPDO_SI1)	RW	RPDO	UDINT	-	0x60400010	-
Mappin	g object for setting RxPDO1.						
02h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
0211	Second mapping object (RxPDO_SI2)	RW	RPDO	UDINT	-	0x607A0020	-
Mappin	g object for setting RxPDO2.	1				1	
03h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
0311	Third mapping object (RxPDO_SI3)	RW	RPDO	UDINT	-	0x60B80010	-
Mappin	g object for setting RxPDO3.	1				1	I
04h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
0411	Fourth mapping object (RxPDO_SI3)	RW	RPDO	UDINT	-	0x60600008	-
Mappin	g object for setting RxPDO4.				<u> </u>	1	<u> </u>

1701	Parameter name	Accessibility	Data	Data	Data display	Default	Correlation	
------	----------------	---------------	------	------	--------------	---------	-------------	--

			mapping	structure	range		mode
	RxPDO	-	-	-	-	-	-
Mapping	object for setting RxPDO.						
01h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
	First mapping object (RxPDO_SI1)	RW	RPDO	UDINT	-	0x60400010	-
Mapping	object for setting RxPDO1.						
02h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
02 11	Second mapping object (RxPDO_SI2)	RW	RPDO	UDINT	-	0x607A0020	-
Mapping	object for setting RxPDO2.	-	1				
03h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
	Third mapping object (RxPDO_SI3)	RW	RPDO	UDINT	-	0x60B80010	-
Mapping	object for setting RxPDO3.	1	I			l	I
04h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
U4I1 _	The fourth mapping object (RxPDO_SI4)	RW	RPDO	UDINT	-	0x60600008	-
Mapping	object for setting RxPDO4.					<u> </u>	

1702	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
	RxPDO	-	-	-	-	-	-
Mappin	g object for setting RxPDO.		1				
01h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
V 2	First mapping object (RxPDO_SI1)	RW	RPDO	UDINT	-	0x60400010	-
Mappin	g object for setting RxPDO1.						
02h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
02	Second mapping object (RxPDO_SI2)	RW	RPDO	UDINT	-	0x607A0020	-
Mapping	g object for setting RxPDO2.						
03h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
33	Third mapping object (RxPDO_SI3)	RW	RPDO	UDINT	-	0x60FF0020	-

04h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
0411	The fourth mapping object (RxPDO_SI4)	RW	RPDO	UDINT	-	0x60710008	-
Mappin	g object for setting RxPDO4.						
05h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
0311	The fifth mapping object (RxPDO_SI5)	RW	RPDO	UDINT	-	0x60600008	-
Mappin	g object for setting RxPDO5.	-	1	1			
06h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
0011	Sixth mapping object (RxPDO_SI6)	RW	RPDO	UDINT	-	0x60B80010	-
Mappin	g object for setting RxPDO6.		<u> </u>				<u> </u>
07h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
3711	The seventh mapping object (RxPDO_SI7)	RW	RPDO	UDINT	-	0x607F0020	-

1A00	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
	TxPDO	-	-	-	-	-	-
Mappin	g object for setting TxPDO.						
01h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
0211	First mapping object (TxPDO_SI1)	RW	TPDO	UDINT	-	0x60410010	-
Mappin	g object for setting TxPDO1.						
02h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
0211	Second mapping object (TxPDO_SI2)	RW	TPDO	UDINT	-	0x60640020	-
Mappin	g object for setting TxPDO2.						
03h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
0311	Third mapping object (TxPDO_SI3)	RW	TPDO	UDINT	-	0x60B90010	-
Mappin	g object for setting TxPDO3.	1	1	1		1	1
04h	Parameter name	Accessibility	Data	Data	Data display	Default	Correlation

			mapping	structure	range		mode
	The fourth mapping object (TxPDO_SI4)	RW	TPDO	UDINT	-	0x60BA0020	-
Mappin	g object for setting TxPDO4.						
05h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
0311	The fifth mapping object (TxPDO_SI5)	RW	TPDO	UDINT	-	0x60BC0020	-
Mappin	g object for setting TxPDO5.	1	ı	1		I	ı
06h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
0011	Sixth mapping object (TxPDO_SI6)	RW	TPDO	UDINT	-	0x603F0010	-
Mappin	g object for setting TxPDO6.	1					
07h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
	The seventh mapping object (TxPDO_SI7)	RW	TPDO	UDINT	-	0x60610008	-
Mappin	g object for setting TxPDO7.		<u> </u>			1	

1B01	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
	TxPDO	-	-	-	-	-	-
Mappin	g object for setting TxPDO.						
01h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
02	First mapping object (TxPDO_SI1)	RW	TPDO	UDINT	-	0x603F0010	-
Mappin	g object for setting TxPDO1.						
02h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
02	Second mapping object (TxPDO_SI2)	RW	TPDO	UDINT	-	0x60410010	-
Mappin	g object for setting TxPDO2.			,			
03h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
oon .	Third mapping object (TxPDO_SI3)	RW	TPDO	UDINT	-	0x60640020	-
Mappin	g object for setting TxPDO3.	•	1				
04h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
	The fourth mapping object	RW	TPDO	UDINT	-	0x60770010	-

	(TxPDO_SI4)						
Mappin	g object for setting TxPDO4.	-1					
05h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
03.1	The fifth mapping object (TxPDO_SI5)	RW	TPDO	UDINT	-	0x60F40020	-
Mappin	g object for setting TxPDO5.		1	1		1	
06h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
UOII	Sixth mapping object (TxPDO_SI6)	RW	TPDO	UDINT	-	0x606100108	-
Mappin	g object for setting TxPDO6.		1	<u> </u>	1		

1C12	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
	RxPDO assign	-	-	-	-	-	-
Used to	set up RPDO assignments.						
	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
01h	Index of objects allocated by RPDO	RW	No	ARR	-	0x1701	-
	(RPDO Index)						

1C13	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode					
	TxPDO assign	-	-	-	-	-	-					
Used to	Used to set TPDO assignments.											
	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode					
01h	Index of objects assigned by TPDO (TPDO Index)	RW	No	ARR	-	0x0001	-					
The inde	The index of the allocation object used to set TPDO.											

	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
1C32	Synchronize management of output parameters	-	-	-	-	-	-
	(SM output parameter)						

Ised to	describe synchronization i	manageme	nt ou	tput paran	neters.					
	Parameter name	e	Acc	essibility	Da map		Data structure	Data display range	Default	Correlation mode
01h	Synchronization type (Synchronization Type)			RW	N	o	UINT	-	0x0001	-
lsed to	set the synchronization ty	pe.								1
02h	Parameter name	Accessib	ility Dat mapp					Data display range	Default	Correlation mode
UZN -	Synchronization type (Synchronization Type)	RW	No			UINT		-	0x0001	-
Ised to s	set the synchronization ty	pe.					l	I_		
	Parameter name	Parameter name A		essibility	Da map		Data structure	Data display range	, Default	Correlation mode
04h	Synchronization Types (Synchronization Types			RO	N	o	UDINT	-	0x8007	-
oisplays	the type of distributed clo	ock.								
	Parameter name Acc		Acc	Accessibility		ta ping	Data structure	Data display range	Default	Correlation mode
05h	Minimum cycle time (Minimum Cycle Time)		RO		N	0	UINT	-	0x0001E848	-

4633	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
1C33	SM input parameter (SM input parameter)	-	-	-	-	-	-
Used to	describe synchronization managem	ent input paran	neters.				
	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
01h	Synchronization type	RW	No	UINT	-	0x0022	-
Used to	(Synchronization Type) set the synchronization type.						
	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode
04h	Synchronization Types support	RO	No	UDINT	-	0x8007	-
	(Synchronization Types support)						
Displays	the type of distributed clock.						
05h	Parameter name	Accessibility	Data mapping	Data structure	Data display range	Default	Correlation mode

	Minimum cycle time (Minimum Cycle Time)	RO	No	UINT	-	0x0001E848	-				
Display	Displays the minimum synchronization period supported by the slave station in ns.										


8.3 Vendor Customized Area (2000h to 2FFFh)

Group 2000h: Basic Settings

P00-04	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2000-04	Rotatation direction		Effective immediately		0 to 1	Basic	
	RotationDir	Stop setting		0		settings	-

Set the positive direction of the motor rotation when viewed from the motor axis.

Setting value	Rotation direction	Remark
0	Take CW as the forward direction	Viewed from the motor axis, the motor rotates clockwise
1	Take CCW as the forward direction	Viewed from the motor axis, the motor rotates counterclockwise



P00-09	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2000-09	Braking resistor setting ExtResSel	Operation setting	Effective immediately	0	0 to 3	Basic settings	-

Used to set the mode of absorbing and releasing braking energy.

Setting value	Brake resistance setting	Remark
0	Use built-in braking resistor	
1	Use external braking resistor and natural cooling	Please refer to "7.1.5 Braking Resistance" to select the
2	Use external braking resistor and forced air cooling (not settable)	appropriate braking mode
3	No braking resistors are used, and all are absorbed by capacitance	

P00-10	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit	
--------	----------------	-------------------	------------	---------	-----------	----------------------	------	--

2000-0A	External braking resistor resistance value	Operation setting	Valid immediately	50	0 to 65535	Basic settings	Ω
	ExtResVal						

Used to set the power of external braking resistor of servo drive. When the maximum braking energy calculated value is greater than the maximum braking energy absorbed by capacitor, and the braking power calculated value is greater than the built-in braking resistor power, use external braking resistor.

If the value of P00-10 is too large, Er.25 (too large braking resistor value) or Er.22 (main power supply is over voltage) will occur.

When external braking resistor is connected, please disconnect the short tab between C and D and connect the external braking resistor between P + and C. Please refer to "2.1.2 Composition of servo drive" for specific operation.

PC	00-11	Parameter name	Setting method	Valid time	Default	Set range	Applicatio n category	Unit
20	00-0B	External braking resistor power ExtResPwr	Operation setting	Effctive immediately	100	0~65535	Basic settings	w

Used to set the power of the external braking resistor of the servo drive.

External braking resistor power "P00-11" is not allowed to be less than the calculated value of braking resistor power!

P00-23	Parameter name	Setting method	Effective time	Default	Set range	Application category	Unit
2000-17	Z pulse output OZ polarity PulseOutPcPolarity	Operation setting	Power-on again	0	0 to 1	Basic settings	-

Used to set the logic level of Z pulse.

Setting value	Function
0	Z pulse is active at high level
1	Z pulse is active at low level

P00-24	Parameter name	Setting method	Effective time	Default	Set range	Application category	Unit
2000-18	Z pulse output width PulseOutZWidth	Operation setting	Power on again	3	1~200	Basic settings	ms

Set the width of Z pulse output.

Setting value	Function
1	Pulse width 1ms
2	Pulse width 2ms
•••	
200	Pulse width 200ms

	Parameter name	Setting method	Valid time	Default	Set range	Applicatio n category	Unit
P00-30 2000-1E	Shield multi-turn absolute encoder battery fault EncBatErrMask	Operation setting	Power-on again	0	0 to 1	Basic settings	-

Used to set the battery fault alarm setting function of multi-turn absolute value encoder.

Setting value	Function	Remark
0	Unshielded	Detect battery undervoltage and battery low voltage faults of multi-turn absolute value encoder
1	Shielded	Shield multi-turn absolute encoder battery under voltage and battery low-voltage fault. This would cause mechanical failure, please use with caution.

P00-31	Parameter name	Setting method	Effective time	Defaul t	Set rang e	Applicatio n category	Uni t
2000-1 F	Encoder read-write verification exception threshold setting EncCommWarmThreshol d	Operatio n setting	Effective immediatel y	20	0 to 100	Basic settings	-

Encoder read-write verification exception is too frequent. Alarm threshold setting.

0: no alarm;

Others: When this setting value is exceeded, report A-93.

P00-32	Parameter name	Setting	Effective	Default	Set	Application	Unit	
								1

Chapter 8 Object Dictionary

2000-20		method	time		range	category	
	Encoder read-write verification exception threshold setting ECAT pdo TimeOut	Operation setting	Effective immediately	2	2 to 14	Basic settings	-

When main station and drive is exchanging data periodically, it can be used to set the tolerance for PDO receive event loss. When the amount of error exceeded the set threshold, it will report ER.09.

Group 2001h: Control Parameters

	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
P01-09 2001-09	Speed limit source In torque mode Torque Mode Speed Source	Stop setting	Effective immediatel y	0	0~2	Protection and restriction	-

Used to set the limit value of the maximum speed in torque mode.

Setting value	Function	Remark
0	Internal forward and reverse restriction	Forward speed limit through P1-17 torque mode and reverse speed limit torque P1-18 torque mode
1	AI_2 analog input	Not support yet!
2	the set EtherCAT communication	Set the limit of in torque mode through the corresponding EtherCAT communication

P01-10	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2001-0A	Maximum speed threshold MaxSpeedLimit	Operation setting	Valid immediatel Y	3600	0~8000	Protection and restriction	rpm

Used to set the maximum speed limit value. If the actual speed of motor exceeds this value, Er.32 would occur (Exceed the maximum speed of motor).

P01-11	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2001-0B	Warning speed threshold WarmSpeedTh	Operation setting	Valid immediatel Y	3300	0 ~8000	Protection and restriction	rpm

Used to set the limit value of maximum speed. If the actual speed of motor exceeds this value, A-81 would occur (Exceed the maximum speed of motor).

P01-12	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2001-0 C	Forward speed threshold PosSpeedTh	Operation setting	Valid immediatel y	3000	0~6000	Protection and restriction	rpm
Used to set t	he limit value of forward	speed.	I		1		

P01-13	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit

2001-0D	NegSpeedTh NegSpeedTh	Operation setting	Valid immediatel y	3000	0~6000	Protection and restriction	rpm
Used to set t	the limit value of reverse	speed					

P01-14	Parameter name	Setting method	Effective time	Default	Set range	Application category	Unit
2001-0E	Torque limit source ToqLimitSrc	Shutdown setting	Effective immediately	0	0 to 2	Protection and restriction	-

Used to set the torque limit source.

Setting value	Restricted source	Remarks
0	Internal	Internal torque limit.
1	Reserved	Reserved
2	EtherCAT	External torque limit, controlled by object dictionaries 6072, 60E0 and 60E1 through EtherCAT communication.

P01-15	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2001-0F	Forward torque limit FToqLim	Operation setting	Valid immediatel Y	3000	0~3000	Protection and restriction	0.1%

When P01-14 is set to 0 (internal), the set value of this function code is used as the limit value of positive torque.

If the value of P01-15 and P01-16 is set too small, the servo motor may be insufficient torque phenomenon when performing acceleration and deceleration movements. Please refer to "6.4.3 Torque command limit".

P01-16	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit			
2001-10	Reverse torque limit RToqLim	Operation setting	Effective immediatel y	3000	0 to 3000	Protection and restriction	0.1%			
When P01-14 is set to 0 (internal), the setting value of this function code is reverse torque limit value										

	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit											
P01-17 2001-11	Froward speed limit in torque mode Torque Mode PSpd Limit	Operation setting	Effective immediatel y	3000	0 to 6000	Protection and restriction	rpm											
When P01-0	9 is set to 0 (internal), the	e setting value o	of this function	code is forward	speed limit.		When P01-09 is set to 0 (internal), the setting value of this function code is forward speed limit.											

P01-18	Parameter name	Setting	Valid time	Default	Set range	Application	Unit
--------	----------------	---------	------------	---------	-----------	-------------	------

2001-12		method				category	
	Reverse speed limit in torque mode Torque Mode NSpd Limit	Operation setting	Effective immediatel y	3000	0 to 6000	Protection and restriction	rpm

When P01-09 is set to 0 (internal), the setting value of this function code is reverse speed limit.

P01-19	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2001-13	Torque Limit Time	Operation	Valid immediatel	1000	0~65525	Protection	
	ToqLimTime	setting	у	1000	0~65535	and restriction	ms

When torque is limited by the setting value of P01-15 or P01-16, and exceeds the setting time, drive would report fault "abnormal torque saturation".

Note: When the value of this function code is set to 0, the torque saturation timeout fault detection is not done, and this fault is ignored.

P01-20	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit			
2001-14	Software overcurrent detection	Operation	Valid immediatel	8	0~65535	Protection and	ms			
	SoftOverCurrentDt	setting	у			restriction				
Software overcurrent detection window (set to 0 to block software overcurrent alarm)										

	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
P01-30 2001-1E	Delay from brake output ON to instruction reception BK_ONtoCmdEnaDela Y	Operation setting	Valid immediatel Y	250	0~500	-	ms

Used to set the braking (BRK-OFF) output ON, until the servo drive allows the start of receiving the input command. When the brake output (BRK-OFF) is not allocated, this function code has no effect.

	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
P01-31 2001-1F	In the static state, delay from the brake output is OFF to the motor is not energized. BK_OFFtoPwmOFFDelay	Operation setting	Valid immediatel Y	150	1~1000	-	ms

When the motor is in a static state, set the delay time from the brake (BRK-OFF) output is OFF to the servo drive is in the non-powered state. When the brake output (BRK-OFF) is not allocated, this function code has no effect.

	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
P01-32 2001-20	Rotation status, when the brake output OFF, the speed threshold. BK_OFFSpdTh	Operation setting	Valid immediatel Y	30	0~3000	-	rpm

When the motor is rotating, the motor speed threshold that is allowed when the brake (BRK-OFF) output is OFF. When the brake output (BRK-OFF) is not allocated, this function code has no effect.

	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
P01-33 2001-21	Rotation status, Delay from servo enable OFF to brake output OFF BK_OFFSinceSofDelay	Operation setting	Valid immediatel Y	500	1~2000	-	ms

When the motor rotates, the delay time from the servo enable (S-ON) OFF to the brake (BRK-OFF) output OFF is allowed. When the brake output (BRK-OFF) is not allocated, this function code has no effect.

P01-37	Parameter name	Setting method	Effective time	Default	Set range	Application category	Unit
2001-25	JOG acceleration time SpdRefJOGAccTime	Operation setting	Effective immediately	500	1 to 5000	-	ms
The time for	The time for JOG instruction to accelerate from 0 to 1000rpm.						

he time for JOG instruction to accelerate from 0 to 1000rpr

P01-38	Parameter name	Setting method	Effective time	Default	Set range	Application category	Unit
2001-26	JOG deceleration time SpdRefJOGDecTime	Operation setting	Effective immediately	500	1 to 5000	-	ms
The time for	The time for JOG instruction to decelerate from 1000rpm to 0.						

Group 2002h: Gain Adjustment

P02-01	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-01	1st position loop gain	Operation	Effective	450	0~6200	Gain	0.1Hz
	PosLoop1stGain	setting	immediately	450	0 6200	control	0.1H2

It is used for setting the proportional gain of the first position loop to determine the responsiveness of the position control system.

P02-02	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-02	first speed loop gain	Operation	Effective			Gain	
	SpdLoop1stGain	setting	immediately	250	0~35000	control	0.1Hz

It is used for setting the proportional gain of the first position loop to determine the responsiveness of the position control system.

P02-03	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-03	First speed loop integral time constant SpdLoop1stIntgTime	Operation setting	Effective immediately	230	10~65535	Gain control	0.1ms

Used to set the integral constant of the first speed loop. The smaller the set value, the stronger the integral effect.

P02-04	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-04	Second position loop gain PosLoop2stGain AS	Operation setting	Effective immediately	300	0 to 6200	Gain control	0.1Hz

Used to set the integral constant of the first speed loop. The smaller the set value, the stronger the integral effect.

P02-05	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-05	Second speed loop gain	Operation	Effective	160	0.35000	Gain	0.111-
	SpdLoop2stGain	setting	immediately	160	0-35000	control	0.1Hz

Used to set the integral constant of the first speed loop. The smaller the set value, the stronger the integral effect.

P02-06	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit	
2002-06	Second speed loop integral time constant SpdLoop2stIntgTime	Operation setting	Effective immediately	350	10~65535	Gain control	0.1ms	
Used to set	Used to set the integral constant of the first speed loop. The smaller the set value, the stronger the integral effect.							

	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
P02-07 2002-07	Second gain switch mode Second Gain Switch Mode	Operation setting	Effective immediately	0	0 to 1	Gain control	-

Used to set second gain swtich mode

Setting value	Functions
	Fix the first gain. Use DI function 10(GAIN-SEI, gain switch) to switch
0	DI logic invalid: PI control
	DI logic valid: P control
1	Switch the first gain and the second gain through the set value of P02-08

P02-08	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-08	speed loop 1st integral time Second Gain Fun Select	Operation setting	Valid immediately	0	0 to 10	Gain control	0.1ms

Used to set the integral constant of the first speed loop. The smaller the set value, the stronger the integral effect.

Setting value	Gain switch condition	Functions
0	First gain fixed	Fix the first gain.
1	Use DI terminal to switch	Use DI function 10 (GAIN-SEI, gain switch) DI logic invalid: First gain(P02-01-P02-03) DI logic valid: Second gain (P02-04-P02-06)
2	When torque instruction is larger	In the previous first gain, when the absolute value of the torque instruction exceeds (level + hysteresis), it switches to the second gain; In the previous second gain, when the absolute value of the torque instruction is less than (level - hysteresis) for a period of delay time, it returns to the first gain.
3	When actual torque is larger	In the previous first gain, when the absolute value of the actual torque exceeds (level + hysteresis), it switches to the second gain; In the previous second gain, when the state where the absolute value of the actual torque is less than (level - hysteresis) continues for the delay time, it returns to the first gain.
4	When speed instruction is larger	In the previous first gain, when the absolute value of the speed instruction exceeds (level + hysteresis), it switches to the second gain; In the previous second gain, when the absolute value of the speed instruction is less than (level - hysteresis) for a period of time, it returns to the first gain.
5	When actual speed is larger	In the previous first gain, when the absolute value of the actual speed exceeds (level + hysteresis), it switches to the second gain; in the previous second gain, when the state where the absolute value of the actual speed is less than (level - hysteresis) continues during the delay time, it returns to the first gain.
6	Change ratio of	In the previous first gain, when the absolute value of the speed command change rate exceeds

	speed instruction is larger	(level + hysteresis), switch to the second gain; in the previous second gain, when the absolute value of the speed command change rate is less than (level - hysteresis) for a period of delay time, return to the first gain.
7	When position offset is larger	In the previous first gain, when the absolute value of the position deviation exceeds (level + hysteresis), it switches to the second gain; in the previous second gain, when the absolute value of the position deviation is less than (level - hysteresis) for a period of time, it returns to the first gain.
8	Position instruction	In the previous first gain, if the position command is not 0, switch to the second gain; In the previous second gain, if the position command is 0 during the delay time, return to the first gain.
9	Positioning completed	If positioning is not completed in the previous first gain, switch to the second gain; If positioning is not completed during the delay time in the previous second gain, return to the first gain.
10	Position instruction + actual velocity	In the previous first gain, if the position command is not 0, switch to the second gain; In the previous second gain, if the position command is 0 during the delay time, keep the second gain; When the delay time is reached, if the absolute value of the current actual speed does not reach (level), the speed integral time constant is fixed at the second integral time constant, and the others return to the first gain. If the absolute value of the actual speed does not reach (level-hysteresis), all return to the first gain.

P02-09	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-09	Speed feedforward gain SpdFeedForwardGain	Operation setting	Valid immediatel Y	0	0~1000	Gain control	0.1%

It is used for setting the proportional gain of the second position loop to determine the responsiveness of the position control system.

P02-10	Parameter name	Setting method	Effective time	Default	Set range	Application category	Unit
2002-0A	Speed feed forward filter constant SpdFeedForwardFilter	Operation setting	Effective immediately	3	0 to 500	Gain control	1ms

Used to set the time constant of the one power delay filter associated with the speed feedforward input.

P02-11	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit			
2002-0B	Torque feedforward gain ToqFeedForwardGain	Operation setting	Effective immediatel y	0	0 to 2000	Gain control	0.1%			
Used to set t	Used to set the torque feedforward gain.									


P02-12	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-0C	Torque feedforward filter time constant	Operation setting	Effective immediatel	50	0 to 10000	Gain control	0.01 ms

|--|

Used to set the time constant of the primary delay filter associated with the torque feedforward input.

P02-13	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-0D	Torque feedforward filter time constant	Operation	Effective	50	0~10000	Gain control	0.01ms
	ToqFeedForwardFilter	setting	immediatel y		0 2000		U.O


The duration of the switching condition required for the second gain to switch back to the first gain.




Note: This parameter is only valid when the second gain is switched back to the first gain.


P02-14	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-0E	Torque feedforward filter time constant ToqFeedForwardFilter	Operation setting	Effective immediatel y	50	0~20000	Gain control	0.01ms

Set the grade of the gain condition. The generation of the actual switching action is affected by the two conditions of grade and hysteresis.



P02-15	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-0F	Torque feedforward filter time constant ToqFeedForwardFilter	Operation setting	Effective immediatel y	50	0~20000	Gain control	0.01ms





P02-16	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-10	Torque feedforward filter time constant ToqFeedForwardFilter	Operation setting	Effective immediatel y	50	0~10000	Gain control	0.01ms

Used to set the time constant of the first-order delay filter associated with the torque feedforward input.

P02-20	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-14	Torque feedforward filter time constant ToqFeedForwardFilter	Operation setting	Effective immediatel y	50	0~10000	Gain control	0.01ms

Used to set the time constant of the primary delay filter associated with the torque feedforward input.

P02-21	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-15	Torque feedforward filter time constant	Operation	Effective				
	ToqFeedForwardFilter	setting	immediatel Y	50	0~10000	Gain control	0.01ms
Used to set t	the time constant of the pri	mary dalay filta	r accordated wit	th the termin fo	odforward input		

Used to set the time constant of the primary delay filter associated with the torque feedforward input.

P02-22	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-16	Torque feedforward filter time constant	Operation setting	Effective immediatel	50	0~10000	Gain control	0.01ms

ToqFeedForwardFilter	У				
----------------------	---	--	--	--	--

Used to set the time constant of the primary delay filter associated with the torque feedforward input.

P02-23	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-17	Torque feedforward filter time constant ToqFeedForwardFilter	Operation setting	Effective immediatel y	50	0~10000	Gain control	0.01ms

Used to set the time constant of the primary delay filter associated with the torque feedforward input.

P02-24	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-18	Torque feedforward filter time constant	Operation setting	Effective immediatel	50	0~10000	Gain control	0.01ms
	ToqFeedForwardFilter	setting	у				

Used to set the time constant of the primary delay filter associated with the torque feedforward input.

P02-25	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2002-19	Torque feedforward filter time constant ToqFeedForwardFilter	Operation setting	Effective immediatel y	50	0~10000	Gain control	0.01ms

Used to set the time constant of the primary delay filter associated with the torque feedforward input.

Group 2003h: Self-adjusting Parameters

P03-01	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2003-01	Load inertia ratio LoadInerRatio	Operation setting	Effective immediatel y	300	100~10000	Automatic parameter tuning	0.01

Used to set the load inertia ratio, 1.00 $^{\sim}$ 100.00 times.

P03-02	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit				
2003-02	Load rigidity selection RigiditySel	Operation setting	Effective immediatel y	14*	0~31	Automatic parameter tuning	-				
Used to set	Used to set the load inertia ratio, 1.00 ~ 100.00 times.										

P03-03 Paramet	er name Setting method	er name Salid time	Default	Set range	Application category	Unit
----------------	------------------------	----------------------	---------	-----------	----------------------	------

2003-03	Self-adjusting mode selection	Operation	Effective	0	0 to 2	Automatic parameter	-
	SelfAdjustMode	setting	immediately			tuning	

Used for setting different gain adjustment modes, the related gain parameters can be set manually or automatically according to the rigidity grade table.

Setting value	Function	Description
0	Self-adjusting mode.	Position loop gain, speed loop gain, speed loop integral time constant, torque filter parameter settings are automatically adjusted according to the rigidity grade setting.
1	Manual setting	The user manually sets the position loop gain, speed loop gain, speed loop integral time constant and torque filter parameter settings.
2	Online automatic self-adjusting mode	Not yet realized.

	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
P03-04 2003-04	Online inertia identification sensitivity InerldOnline	Operation setting	Effective immediatel Y	0	0 to 2	Automatic parameter tuning	-
Not realized	l yet.	1	1				ı

P03-05	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit			
2003-05	Number of cycles of inertia identification InerIdCircle	Shutdown setting	Effective immediatel y	2	1 to 20	Automatic parameter tuning	Circle			
Used to set	Used to set the load inertia identification process and set the number of rotations of the motor.									

P03-06	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2003-06	Maximum speed of inertia identification	Shutdown setting	Effective immediatel	1000	300 to 2000	Automatic parameter	rpm
	InerldMaxSpd		y			tuning	

Used to set the maximum allowable motor speed command in offline inertia identification mode. The faster the speed during inertia identification, the more accurate the identification result will be. Generally, keep the default value.

P03-07	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2003-07	Parameter identification rotation direction	Shutdown setting	Effective immediately	0	0 to 2	Automatic parameter tuning	-

IneridRollMode												
Used to set parameters identificat	Used to set parameters identification rotation direction.											
	Setting value	Rota	tion direction									
	0	Forward and reverse reciprocating rotation										
	1	Forward one-way rotation										
	2	Reverse	one-way rotat	ion								

	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
P03-08 2003-08	Parameter identification waiting time InerIdWaitTime	Shutdown setting	Effective immediatel y	1000	300 to 10000	Automatic parameter tuning	ms

During offline inertia identification, the time interval between two consecutive speed instructions

Group 2004h: Vibration Suppression


P04-01	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2004-01	Pulse instruction filtering method PulseFilterType	Shutdown setting	Effective immediately	0	0 to 1	Position mode	-

Used for setting different gain adjustment modes, the related gain parameters can be set manually or automatically according to the rigidity grade table.


Setting value	Filtering method
0	First-order low-pass filtering method
1	Mean filtering method

	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
P04-02 2004-02	first-order low-pass	Shutdown setting	Effective immediately	0	0~1000	Position mode	ms

It is used to set the filtering time constant of the first-order low-pass filtering mode.



	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
P04-03 2004-03	position command average filter time constant AveragingFilterTime	Shutdown setting	Effective immediately	0	0 to 128	Position mode	ms



P04-04	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2004-04	Torque filter time constant TogFiltertTime	Operation setting	Effective immediately	50	10~2500	Vibration suppression	0.01ms

Used to set torque filtering time constant. When the function code P03-03(Self-adjustment mode selection) is set to 0, the parameter is automatically set by servo.

	P04-05	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2	2004-05	1st notch filter frequency	Operation	Effective	200	250 to	Vibration	Hz
	2004-03	NotchFilter1_Freq	setting	immediately	300	5000	suppression	П

Use to set the center frequency of the 1st notch filter. When the function code is set to 5000, the function of the notch filter is invalid.

P04-06	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2004-06	1st notch filter depth NotchFilter1_Deep	Operation setting	Effective immediately	100	0 to 100	Vibration suppression	-

It is use to set the notch filter depth grade (the ratio between input and output at the center frequency of the notch filter). The larger the set value of this function code is, the smaller the notch filter depth is, and the weaker the suppression effect of mechanical vibration is. However, setting too large could cause system instability.

P04-07	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2004-07	1st notch filter width NotchFilter1_Band	Operation setting	Effective immediately	4	0 to 12	Vibration suppression	-

Use to set the notch filter width grade (the ratio between input and output at the center frequency of the notch filter)

P04-08	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2004-08	2nd notch filter frequency NotchFilter2_Freq	Operation setting	Effective immediately	500	250 to 5000	Vibration suppression	Hz

Use to set the center frequency of the 2nd notch filter. When the function code is set to 5000, the function of the notch filter is invalid.

P04-09	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2004-09	2nd notch filter depth NotchFilter2_Deep	Operation setting	Effective immediately	100	0 to 100	Vibration suppression	-

P04-10	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2004-0A	2nd notch filter width NotchFilter2_Band	Operation setting	Effective immediately	4	0 to 12	Vibration suppression	-

P04-18	Parameter name	Setting method	Effective time	Default	Set range	Application category	Unit
2004-12	Speed feedback filter time SpdFdbFilterTime	Operation setting	Effective immediately	10	1 to 1000	Vibration suppression	0.01ms

Group 2005h: Signal Input and Output

P05-16	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2005-10	Rotation detection speed threshold RotateSpdDtTh	Operation setting	Effective immediately	20	0~1000	Speed mode	rpm

Set the speed threshold that triggers the motor rotation signal. The motor rotation signal (TGON) is used to confirm that the motor has rotated.

P05-19	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2005-13	Zero speed output signal threshold SpdZeroOutTh	Operation setting	Effective immediately	10	0~6000	Speed mode	rpm

Use to set the speed threshold that triggers the motor rotation signal. Motor output zero speed signal (ZSP) means that the actual speed of the motor is close to stationary.

	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
P05-23 2005-17	Probe filter 1 time parameters TouchprobeFilter1Tim e	Operation setting	Effective immediatel y	200	0 to 500	-	10ns

Set the filter time of probe 1; 0-10us.

	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit	
P05-24 2005-18	Probe filter 2 time parameters TouchprobeFilter2Tim e	Operatio n setting	Effective immediatel Y	200	0 to 500	-	10ns	
Set the filte	Set the filter time of probe 2; 0-10us.							

Setting **Application** Valid time Default Unit Parameter name Set range method category P05-25 **Effective** 2005-19 TouchprobeDiOn Operation -10000 to immediatel 500 10ns $\\Compensation \\Time$ setting 10000 The compensation probe action time when it is turned on, set to positive to move in the direction of motion.

	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit	
P05-26 2005-1A	TouchprobeDiOn CompensationTime	Operation setting	Effective immediatel y	500	-10000 to	-	10 ns	
The compen	The compensation probe action time when it is turned off, set to positive to move in the direction of motion.							

Group 2006h: DIDO Configuration

P06-02	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-02	DI_1 channel function selection Di1FunSel	Operation setting	Power-on again	0	0~32	DI/DO	-

Set DI functions corresponding to hardware DI_1. Refer to the following table for the functions corresponding to the set value:

Setting value	DI channel function
0	OFF (not used)
1	SON (servo enabled)
2	A-CLR (Fault and warning clear)
3	POT (Forward drive prohibition)
4	NOT (Reverse drive prohibition)
6	CL (deviation counter cleared)

Setting value	DI channel function
8	E-STOP (Emergency stop)
18	Probe 1
19	Probe 2
26	HOMEORG (origin signal)
Other	None

If P06-02 is set to a value other than that in the preceding table, the DI port function is not require

The same DI channel function could not be allocated to multiple DI ports, otherwise servo drive will occur A-89 (duplicate DI port configuration)

P06-03	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-03	DI_1 channel logic selection Di1LogSel	Operation setting	Effective immediately	0	0 to 1	DI/DO	-

DI port input logic validity function selection

Setting value	Content	Specification
0	Normally open input. Active low level (switch on);	high level >3ms high level valid
1	Normally closed input. Active high level (switch off);	high level valid >3ms

P06-04	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-04	DI_1 input source selection Di1SrcSel	Operation setting	Effective immediately	0	0 to 1	DI/DO	-

Select the enabled DI_1 port type

Setting value	Port category
0	Hardware DI_1 input terminal
1	Virtual VDI_1 input terminal

P06-05	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-05	DI_2 channel function selection Di2FunSel	Operation setting	Power-on again	2	0~32	DI/DO	-

P06-06	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-06	DI_2 channel logic selection Di2LogSel	Operation setting	Effective immediately	0	0 to 1	DI/DO	-

P06-07	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-07	DI_2 input source selection Di2SrcSel	Operation setting	Effective immediately	0	0 to 1	DI/DO	-

P06-08	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-08	DI_3 channel function selection Di3FunSel	Operation setting	Power-on again	3	0~32	DI/DO	-

P06-09	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-09	DI_3 channel logic selection Di3LogSel	Operation setting	Effective immediately	0	0 to 1	DI/DO	-

P06-10	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-0A	DI_3 input source selection Di3SrcSel	Operation setting	Effective immediately	0	0 to 1	DI/DO	-

P06-1	Parameter name	Setting	Valid time	Default	Set range	Application	Unit	
-------	----------------	---------	------------	---------	-----------	-------------	------	--

		С	hapter 8 Object [Dictionary			
2006-0B		method				category	
	DI_4 channel function selection Di4FunSel	Operation setting	Power-on again	4	0~32	DI/DO	-
P06-12	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-0C	DI_4 channel logic selection Di4LogSel	Operation setting	Effective immediately	0	0 to 1	DI/DO	-
P06-13	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-0D	DI_4 input source selection Di4SrcSel	Operation setting	Effective immediately	0	0 to 1	DI/DO	-
		1	1		1		
P06-14	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-0E	DI_5 channel function selection Di5FunSel	Operation setting	Power-on again	0	0~32	DI/DO	-
P06-15	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-0F	DI_5 channel logic selection Di5LogSel	Operation setting	Effective immediately	0	0 to 1	DI/DO	-
P06-16	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-10	DI_5 input source selection Di5SrcSel	Operation setting	Effective immediately	0	0 to 1	DI/DO	-
		1			I	1	
DOC 47	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
P06-17 2006-11	DI_6 channel function selection	Operation	Power-on	0	0~32	DI/DO	
	Di6FunSel	setting	again	0	U 32	DI/DO	-
P06-18	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-12	DI_6 channel logic	Operation	Effective	0	0 to 1	DI/DO	-

selection	setting	immediately		
Di6LogSel				

P06-19	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-13	DI_6 input source selection Di6SrcSel	Operation setting	Effective immediately	0	0 to 1	DI/DO	-

P06-26	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-1A	DO_1 channel function selection Do1FunSel	Operation setting	Effective immediately	132	128 ~ 148	DI/DO	-

Use to set DO functions corresponding to hardware DO_1. Refer to the following table for the functions corresponding to the set value:

Setting value	DI channel function
128	OFF (not used)
129	RDY (Servo ready)
130	ALM (Fault signal)
131	WARN (warning signal)
132	TGON (rotation detection)
133	ZSP (zero speed signal)
134	P-COIN (positioning
	completed)
137	V-NEAR (speed approach)
138	T-COIN (torque arrival)

Setting value	DI channel function
139	T-LIMIT (Torque limit)
140	V-LIMIT (speed limited)
141	BRK-OFF (brake output)
142	SRV-ST (Servo on state output)
445	COM_VDO1 (communication
145	VDO1 output)
146	COM_VDO1 (communication
146	VDO1 output)
147	COM_VDO1 (communication
147	VDO1 output)
Others	None

If P06-26 is set to a value other than that in the preceding table, the DO port function is not required

The same DO channel function could not be allocated to multiple DO ports, otherwise servo drive will occur A-90 (duplicate DO port configuration)

P06-27	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-1B	DO_1 channel logic selection Do1LogSel	Operation setting	Effective immediately	0	0 to 1	DI/DO	-

DO Port input logic validity function selection.

Setting value	Content
0	Output transistor is on when the output is valid, and output transistoris off when the output is invalid.
1	Output transistor is off when the output is valid, and output transistor is on when the output is invalid.

P06-28	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-1C	DO_2 channel function selection Do2FunSel	Operation setting	Effective immediately	130	128 to 148	DI/DO	-

P06-29	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-1D	DO_2 channel logic selection Do2LogSel	Operation setting	Effective immediately	0	0 to 1	DI/DO	-

P06-30	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-1E	DO_3 channel function selection Do3FunSel	Operation setting	Effective immediately	129	128 to 148	DI/DO	-

P06-31	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-1F	DO_3 channel logic selection Do3LogSel	Operation setting	Effective immediately	0	0 to 1	DI/DO	-

P06-34	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
2006-20	ECAT forces DO to output state CompDoOutputStatu	Operation setting	Effective immediately	0	0 to 1	Auxiliary function	-

When the master station changes from online to offline, the DO output state changes (when the DO forced output enable of 60FE-02h is not turned on, it is not affected by this function code)

0: Keep the current state;

1: Initialize state

Group 200Ah: Auxiliary Function

P10-01	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
200A-01	JOG speed SpdRefJOG	Operation setting	Effective immediately	100	0~3000	Auxiliary function	rpm
Used to set J	OG speed						

P10-02	Parameter name	Setti meth	•	Valid time	Default	Set range	Application category	Unit
200A-02	Factory value resettir RstFuncFac	Shutd setti	-	Effective immediately	0	0 to 1	Auxiliary function	-
Used to resto	ore function code param	eters to facto	ory valu	es.		I.		
		Setting value		Operationa	l meaning			
		0		No ope	ration			

P10-03	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
200A-03	Fault clearing ServoErrClear	Operation setting	Effective immediately	0	0 to 1	Auxiliary function	-

Restore factory setting value

1

Fault reset operation selection

Setting value	Function	Remark
0	No operation	-
1	Fault clearing	For clearable faults, after the cause of fault is removed, and write 1 to the function code, the drive will stop the fault display and enter the Rdy (or RUN) state again.

Note: If the servo S-ON is valid, when the fault is removed and cleared, the servo will directly enter the Run state. When performing fault clearing actions, be sure to stop sending control instructions such as pulses to ensure personal safety.

P10-04	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
200A-04	Motor overload protection time factor MotOLProtect_Coef	Operation setting	Effective immediately	100	0 to 800	Accessibility	%

Set the time for code A-82 (Motor overload warning) and Er.34 (Motor overload protection fault) through this function code.

According to the heating condition of the motor, modifying this value can make the overload protection time

fluctuate up and down the reference value, 50 corresponds to 50%, that is, the time is reduced by half; 300 corresponds to 300%, that is, the time is extended to 3 times. When it is set to 0, the overload protection fault detection function will be shielded, so please use it carefully!

P10-05	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
200A-05	Motor type	Operation	Power on	0	0 to 65535	Auxiliary	
	MotorTypeSel	setting	again			function	

The motor model is used together with P10-7 to manually set the motor code. When P10-7 is set to 1, the motor code uses the value set by P10-5. When P10-7 is set to 0, the current motor model code, please query U0-53.

P10-06	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
200A-06	Multi-turn absolute encoder reset AbsEncRst	Stop setting	Effective immediately	0	0 to 65535	Auxiliary function	-

Used to clear the rotation number of multi-turn absolute encoder (U0-55), current position (U0-56) or clear the encoder fault alarms

Setting value	Function
0	No operation
1	Clear multi-turn data, encoder current position and encoder fault alarms
2	retain
3	Only clear the fault alarm of multi-turn absolute encoder
-	Other values are invalid

Note: After reset (P10-06 is set to 1), the absolute position of the encoder will change suddenly, and the mechanical origin return operation is required.

P10-07	Parameter name	Setting method	Effective time	Default	Set range	Application category	Unit
200A-07	Manual setting motor code ManualSetMotoCode	Operation setting	Power-on again	0	0 to 1	Auxiliary function	-

Used to modify the Motor Code of the servo drive. When it is set to 0, Motor Code is read from motor. When it is set to 1, Motor code is read from P10-5 motor model.

Note: Do not modify it casually, otherwise it will cause motor damage.

P10-11	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
--------	----------------	-------------------	------------	---------	-----------	----------------------	------

Enable Enable

Used to turn on and off motor

Setting value	Function
0	Enable motor stall overtemperature detection. When the motor stalls, the driver reports [ER.45] motor stall overtemperature protection;
1	Shielded motor stall overtemperature detection. (After stall detection, the torque is automatically reduced to 70.7% of the rated value)

Note: After reset (P10-06 is set to 1), the absolute position of the encoder will change suddenly, and the mechanical origin return operation is required.

Group 200Dh Communication Input and Output Terminal

P13-01	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit			
200D-01	Virtual VDI_1 input value CommVdi_1	Operation setting	Valid immediately	0	0 to 1	DI/DO	-			
When P06-04 is set to 1, DI_1 channel logic is controlled by this function code.										
	Setting VDI_1 input level value									
		0	Low level							
		1	High I	evel						

P13-02	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit		
200D-02	Virtual VDI_2 input value CommVdi_2	Operation setting	Effective immediately	0	0 to 1	DI/DO	-		
When P06-07 is set to 1, DI_2 channel logic is controlled by this function code.									

P13-03	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit		
200D-03	Virtual VDI_3 input value CommVdi_3	Operation setting	Effective immediately	0	0 to 1	DI/DO	-		
When P06-10 is set to 1, DI_3 channel logic is control by this function code.									

P13-04 Parai	meter name Setting	Valid time	Default	Set range	Application	Unit
--------------	--------------------	------------	---------	-----------	-------------	------

	200D-04		method				category		
		Virtual VDI_4 input value	Operation	Effective	0	0 to 1	DI/DO	_	
		CommVdi_4	setting	immediately	· ·	0.01	<i>D</i> 1700		
Г	When P06-13 is set to 1, DI_4 channel logic is control by this function code.								

P13-05	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit		
200D-05	Virtual VDI_5 input value CommVdi_5	Operation setting	Effective immediately	0	0 to 1	DI/DO	•		
When P06-16 is set to 1, DI_5 channel logic is control by this function code.									

P13-06	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit		
200D-06	Virtual VDI_6 input value CommVdi_6	Operation setting	Effective immediately	0	0 to 1	DI/DO	-		
When P06-19 is set to 1, DI_6 channel logic is control by this function code.									

P13-11	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit				
200D-0B	Virtual VDO_1 output value CommVdo_1	Operation setting	Effective immediately	0	0 to 1	DI/DO	-				
Used to set t	Used to set the input level logic when the DO function selected by VDO_1 is active.										
		Setting value	VDO_:	1 input level							
		0	L	ow level							

P13-12	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
200D-0C	Virtual VDO_2 output value CommVdo_2	Operation setting	Effective immediately	0	0 to 1	DI/DO	-

1

High level

P13-13	Parameter name	Setting method	Valid time	Default	Set range	Application category	Unit
200D-0D	Virtual VDO_3 output value	Operation setting	Effective immediately	0	0 to 1	DI/DO	-

	1	
CommVdo 3		

Group 201Eh Universal Monitoring


U0-01	Monitoring name	Range	Category	Panel display	Unit	Data type
201E-01	Servo status	0~8	Universal	Decimal	-	16 Bit
2011 01	SrvStatus		oversur	Jesima.		20 5%

Display the status of servo drive.

Display value	Status	Display value	Status
0	Power-on	5	Servo operation
1	Initialization	6	Quick shutdown
2	Failure-free (nF)	7	Malfunction shutdown
3	Servo ready (Ry)	8	Fault
4	Wait for servo enabled		

U0-02	Monitoring name	Range	Category	Panel display	Unit	Data type
201E-02	Servo motor speed SpeedDis	-6000~6000	Universal	Decimal	rpm	16 Bit
D: 1 1	tl	•	• 4 = 1			

Display the actual speed of servo drive. The accuracy is 1 rpm. The display of servo drive panel is as below.




	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-03 201E-03	Input speed instruction SpdCmd	-6000~6000	Universal	Decimal	rpm	16 Bit
Display serv	o input speed instructi	on. The accuracy	is 1 rpm. The dis	olay of servo driv	e panel is as belo	w.
	300	Orpm display		-3000rpm displa	у	

3000rpm display	-3000rpm display
3000	-][[[

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-04	Corresponding					
201E-04	speed of position command	-5000~5000	Universal	Decimal	rpm	16 Bit
	PosCmdToSpd					

Display the current speed instruction value of servo drive in position mode. The accuracy is 1 rpm. The display of servo drive panel is as below.



U0-05	Monitoring name	Range	Category	Panel display	Unit	Data type			
201E-05	Pulse deviation	-2 ³¹ ~2 ³¹	Universal	Decimal	Equivalent pulse	32 Bit			
201L-03	PulsErr		oversur	Decima.	deviation	32 Sit			
Display puls	e deviation. If U0-05 is	32768, the displa	y of the servo dr	ive panel is:					
	Shift								
			Ŷ						
	Shift Shift								
	lower 4 bits page1		middle 4 bits page 2		high 4 bits page 3	i			

	Monitoring name	Range	Category	Panel display	Unit	Data type	
U0-09 201E-09	Input instruction pulse number PulsTotal	-2 ³¹ ~2 ³¹	Universal	Decimal	Instruction unit	32 Bit	
Display instruction pulse number that input the servo drive. If U0-09 is set to -2147483646, the panel of servo drive is							
displayed as below.							
			Shift				
		Shift		Shift			
	lower 4 bits page1		middle 4 bits page 2		high 2 bi page 3		

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-13	Encoder cumulative position					
201E-0D	(Low 32 bits) EncTotal LowWord	-2 ³¹ ~2 ³¹	Universal	Decimal	Encoder unit	32 Bit

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-15 201E-0F	Encoder cumulative position (High 32 bits) EncTotal_HighWord	-2 ³¹ ~2 ³¹	Universal	Decimal	Encoder unit	32 Bit


Display the cumulative data of encoder position. It is used with U0-13 cooperatively.

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-17	DI input signal	00000000~				
201E-11	status	11111111	Universal	Binary	Encoder unit	16 Bit
	DiData1	11111111				

Displays the current level status of 6 DI terminals.

Display mode: The upper part of the digital tube of the servo drive panel is bright to indicate high level (represented by "1"); The lower light indicates low level (denoted by "0").

Take the DI1^DI4 terminal as the high level and DI5^DI6 as the low level as the example: the corresponding binary code is "001111", and Wecon servo control device debugging platform U0-17 displays the 0b0000 1111. The panel of servo drive is displayed as below:




	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-19 201E-13	DO output signal status	00000000~	Universal	Binary	Encoder unit	16 Bit
	DoData1	00001111				

Displays the current level status of 3 DO terminals.

Display mode: The upper part of the digital tube of the servo drive panel is bright to indicate high level (represented by "1"); The lower light indicates low level (denoted by "0").

Take the DO1, DO2 and DO3 terminals as the high level and DO2 as the low level as an example. The corresponding binary code is "101", and Wecon servo upper computer debugging platform U0-17 displays the current binary value is 0b0000 0101. The panel of servo drive is displayed as below.



	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-20 201E-14	Real-time load inertia ratio	-	Universal	Decimal	%	16 Bit
	InerRatioReal					

Displays the current load inertia ratio. If the load inertia ratio is 3 times (300%), the panel of servo drive is displayed as below.



U0-23	Monitoring name	Range	Category	Panel display	Unit	Data type
201E-17	Vibration Frequency DisVibFreq	-	Universal	Decimal	Hz	16 Bit
	Disvibried					

U0-24	Monitoring name	Range	Category	Panel display	Unit	Data type
201E-18	Vibration Amplitude DisVibMag	-	Universal	Decimal	rpm	16 Bit

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-25 201E-19	Forward torque limit value	0~300	Universal	Decimal	%	16 Bit
	PToqLimitDis					

Display the set value of P01-15 (forward torque limit) of servo drive. If U0-25 is 288%, the panel of servo drive is displayed as below.



U0-26	Monitoring name	Range	Category	Panel display	Unit	Data type
201E-1A	Reverse torque limit	-300~0	Universal	Decimal	%	16 Bit

	value			
	NToqLimitDis			

Display the set value of P01-16 (reverse torque limit) of servo drive. If U0-26 is 300%, the panel of servo drive is displayed as below.



	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-27	Forward speed limit					
201E-1B	value	0~6000	Universal	Decimal	rpm	16 Bit
	PSpdLimitDis					

Display the set value of P01-12 (forward speed threshold) of servo drive. If P01-12 is set to 2000, the panel of servo drive is displayed as below.



	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-28	Reverse speed limit					
201E-1C	value	-6000~0	Universal	Decimal	rpm	16 Bit
	NSpdLimitDis					

Display the set value of P01-13 (reverse speed threshold) of servo drive. If P01-13 is set to 3000, the panel of servo drive is displayed as below.



U0-29	Monitoring name	Range	Category	Panel display	Unit	Data type
201E-1D	Mechanical angle MachineAngle	0~359	Universal	Decimal	o	16 Bit

Display current mechanical angle of motor. 0 corresponds to a mechanical angle of 0 degree.

U0-30	Monitoring name	Range	Category	Panel display	Unit	Data type
201E-1E	Electrical angle	0~359	Universal	Decimal	•	16 Bit
2011 11	ElecAngle	0 333	- Cimversur	200111101		10 510

Display current electrical angle of motor. The accuracy is 1°. When the motor rotates, the electrical angle range is 360° .

When the motor is 4 poles, every time the motor is rotated one turn, it undergoes a change process of 0° to 359° for four times.

U0-31	Monitoring name	Range	Category	Panel display	Unit	Data type
dain201E -1F	Bus voltage DcBusVoltDisp	-	Universal	Decimal	V	16 Bit

Display the DC bus voltage of the main circuit input voltage of servo drive after rectification.

If the bus voltage is 310.9, the panel of servo drive is displayed as below.



	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-32 201E-20	Radiator temperature	-	Universal	Decimal	°C	16 Bit
	Temperature_IPM					

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-33 201E-21	Instantaneous output power	-	Universal	Decimal	w	16 Bit
	OutputPowerInst					

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-34	Average output power					
201E-22	OutputPowerAverag e	-	Universal	Decimal	W	16 Bit

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-35	Total operation time					
201E-23	(hour)	-	Universal	Decimal	h	16 Bit
	HourTotalRun					

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-37	Total operation time					
201E-25	(minute)	-	Universal	Decimal	min	16 Bit
	MinTotalRun					

	Monitoring name	Range	Category	Panel display	Unit	Data type	Ī
U0-38 201E-26	Total operation time (second)	-	Universal	Decimal	s	16 Bit	
	SecTotalRun						

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-39	Load torque					
201E-27	percentage	-	Universal	Decimal	%	16 Bit
	ToqOutRate					

Display current load torque percentage. If the current load torque percentage is 10.3%, the panel of servo drive is displayed as below.



	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-40 201E-28	Current operation time (hour)	-	Universal	Decimal	h	16 Bit
	HourCurrentRun					

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-42	Current operation time					
201E-2A	(minute)	-	Universal	Decimal	min	16 Bit
	MinCurrentRun					

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-43	Current operation					
201E-2B	time (second)	-	Universal	Decimal	s	16 Bit
	SecCurrentRun					

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-44 201E-2C	Instantaneous braking resistor power DisPwrInst	-	Universal	Decimal	w	16 Bit

U0-46	Monitoring name	Range	Category	Panel display	Unit	Data type
201E-2E	Average braking	-	Universal	Decimal	W	16 Bit

resistor power			
DisPwrAvg			

U0-48	Monitoring name	Range	Category	Panel display	Unit	Data type
201E-30	Power-on times	-	Universal	Decimal	Times	16 Bit
	PwrUpCount					

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-49	Overload times					
201E-31	MotorOverLoadCoun t	-	Universal	Decimal	0.01%	16 Bit

	Monitoring name	Range	Category	Panel display	Unit	Data type			
U0-50	Motor cumulative number of circles								
201E-32	(Low 32 bits)	0~ (2 ³² -1)	Universal	Decimal	Circle	32 Bit			
	MotoTotal_LowWord								
Displays the cumulative number of revolutions of the motor. It is used with U0-13 cooperatively.									

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-51 201E-33	Motor cumulative number of circles (High 32 bits)	0~ (2³²-1)	Universal	Decimal	Circle	32 Bit
	MotoTotal_HighWord					

U0-52	Monitoring name	Range	Category	Panel display	Unit	Data type
201E-34	Encoder bits	17 to 23	Universal	Decimal	Bit	16 Bit
	EncoderBit	17 10 23	Oniversal	Decimal	Bit	10 Dit

U0-53	Monitoring name	Range	Category	Panel display	Unit	Data type
201E-35	Motor model code MotoModel	-	Universal	Hexadecima I	-	16 Bit

Displays the Motor Code of the current servo drive connected motor. Taking WD80M-07530S-A1F (A026) as an example, the description panel is displayed as below:



	Monitoring name	Range	Category	Panel display	Unit	Data type		
U0-54	Absolute encoder							
201E-36	position in 1 lap	0~(2 ³² -1)	Universal	Decimal	Encoder unit	32 Bit		
	AbsEncIn1Cycle							
Display the si	Display the single turn position feedback value of absolute encoder							

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-55	Absolute encoder					
201E-37	number of circles	0 to 65535	Universal	Decimal	Circle	32 Bit
	AbsEncMultiTurn					
Circle number	rs of multi-turn absolute	encoder	1			

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-56 201E-38	Current position of the multi-turn absolute encoder (Low 32 bits) EncTotal_CmdUnit	-2 ³¹ ~2 ³¹	Universal	Decimal	Instruction unit	32-bit

Display the absolute position of the current motor (Instruction unit). It is only valid in multi-turn absolute encoder motor.

	Monitoring name	Range	Category	Panel display	Unit	Data type
U0-57 201E-39	Current position of the multi-turn absolute encoder (High 32 bits) EncTotal_CmdUnit	-2 ³¹ ~2 ³¹	Universal	Decimal	Instruction unit	32-bit

Display the absolute position of the current motor (Instruction unit). It is only valid in multi-turn absolute encoder motor.

Group 201Fh: Warning Monitoring

U1-01	Monitoring name	Range	Category	Panel display	Unit	Data type
201F-01	Current error code NowErrorCode	-	Warning	-	-	16 Bit

If there is fault in servo drive, it would display the corresponding fault. If not, the panel displays "---", Taking the failure of "encoder disconnection" as an example, the panel of servo drive is displayed as below.

Servo drive has a fault "encoder disconnection"	Servo drive has no fault
	0 0 0

U1-02	Monitoring name	Range	Category	Panel display	Unit	Data type
201F-02	Current warning code	-	Warning	-	-	16 Bit
	NowWarmCode					

If there is warning in servo drive, it would display the corresponding warning. If not, the panel displays "---". Taking the warning of "duplicate DI port configuration" as an example, the panel is displayed as below.

Servo drive has a warning "duplicate DI port configuration"	Servo drive has no warning
	0 0 0 0

	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-03 201F-03	U phase current when faults occur	_	Warning	Decimal	Α	16 Bit
2011-03	luWarmOccur	-	wariing	Decimal	7	10 510

	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-04	V phase current when					
201F-04	faults occurmalfunction	-	Warning	Decimal	Α	16 Bit
	lvWarmOccur					

	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-05 201F-05	Bus voltage when faults occur	-	Warning	Decimal	v	16 Bit
	UdcWarmOccur				-	

		Chapt	er 8 Object Dicti	onary		
	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-06 201F-06	IGBT temperature when faults occur T_IPMWarmOccur	-	Warning	Decimal	°C	16 Bit
	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-07 201F-07	Torque component when faults occur	-	Warning	Decimal	%	16 Bit
	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-08 201F-08	Excitation component when faults occur	-	Warning	Decimal	%	16 Bit
	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-09 201F-09	Position deviation when faults occur PosErrWarmOccur	-	Warning	Decimal	Encoder unit	32 Bit
114.40	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-10 201F-0 A	Speed value when faults occur SpdWarmOccur	-	Warning	Decimal	rpm	16 Bit
	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-11 201F-0B	Time when the fault occurred Time 1WarmOccur	-	Warning	Decimal	S	16 Bit
			l	I		
	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-12	Number of faults during					
201F-0C	current operation ErrCntCurRun	-	Warning	Decimal	-	16 Bit
U1-13	Monitoring name	Range	Category	Panel display	Unit	Data type

		Chapt	er 8 Object Diction	onary		
	operation WarmCntCurRun					
	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-14		Kange	Category	1 and display	Oilit	Data type
201F-0E	Total number of historical faults ErrorTotalCnt	-	Warning	Decimal	-	16 Bit
	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-15	Total number of					
201F-0F	historical warnings WarmTotalCnt	-	Warning	Decimal	-	16 Bit
	Trainingtal City					
	Monitoring	Days	Catagama	Danel display	Unit	Data turna
U1-16	Monitoring name	Range	Category	Panel display	Unit	Data type
201F-10	Latest 1st fault code ErrCodeLast1st	-	Warning	-	-	16 Bit
Display the	1st fault code of the most	recent of servo d	rive			
U1-17	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-17 201F-11	Monitoring name Latest 2nd fault code ErrCodeLast2nd	Range -	Category Warning	Panel display	Unit -	Data type 16 Bit
	Latest 2nd fault code					
201F-11	Latest 2nd fault code					
	Latest 2nd fault code ErrCodeLast2nd Monitoring name Latest 3rd fault code	-	Warning	-	-	16 Bit
201F-11 U1-18	Latest 2nd fault code ErrCodeLast2nd Monitoring name	-	Warning	-	-	16 Bit Data type
201F-11 U1-18	Latest 2nd fault code ErrCodeLast2nd Monitoring name Latest 3rd fault code ErrCodeLast 3rd	-	Warning	Panel display	-	16 Bit Data type
201F-11 U1-18 201F-12	Latest 2nd fault code ErrCodeLast2nd Monitoring name Latest 3rd fault code	-	Warning	-	-	16 Bit Data type
U1-18 201F-12 U1-19	Latest 2nd fault code ErrCodeLast2nd Monitoring name Latest 3rd fault code ErrCodeLast 3rd	- Range	Warning Category Warning Category	Panel display	- Unit - Unit	Data type 16 Bit Data type
201F-11 U1-18 201F-12	Latest 2nd fault code ErrCodeLast2nd Monitoring name Latest 3rd fault code ErrCodeLast 3rd Monitoring name	- Range	Warning Category Warning	Panel display	- Unit	16 Bit Data type 16 Bit
U1-18 201F-12 U1-19	Latest 2nd fault code ErrCodeLast2nd Monitoring name Latest 3rd fault code ErrCodeLast 3rd Monitoring name Latest 4th fault code	- Range	Warning Category Warning Category	Panel display	- Unit - Unit	Data type 16 Bit Data type
U1-18 201F-12 U1-19	Latest 2nd fault code ErrCodeLast2nd Monitoring name Latest 3rd fault code ErrCodeLast 3rd Monitoring name Latest 4th fault code	- Range	Warning Category Warning Category	Panel display	- Unit - Unit	Data type 16 Bit Data type
U1-18 201F-12 U1-19 201F-13	Latest 2nd fault code ErrCodeLast2nd Monitoring name Latest 3rd fault code ErrCodeLast 3rd Monitoring name Latest 4th fault code ErrCodeLast 4th	Range - Range -	Warning Category Warning Category Warning	Panel display - Panel display -	Unit Unit	Data type 16 Bit Data type 16 Bit Data type 16 Bit
201F-11 U1-18 201F-12 U1-19 201F-13	Latest 2nd fault code ErrCodeLast2nd Monitoring name Latest 3rd fault code ErrCodeLast 3rd Monitoring name Latest 4th fault code ErrCodeLast 4th Monitoring name	Range - Range -	Warning Category Warning Category Warning	Panel display - Panel display - Panel display	- Unit Unit Unit	16 Bit Data type 16 Bit Data type 16 Bit
U1-18 201F-12 U1-19 201F-13	Latest 2nd fault code ErrCodeLast2nd Monitoring name Latest 3rd fault code ErrCodeLast 3rd Monitoring name Latest 4th fault code ErrCodeLast 4th Monitoring name Latest 5th fault code	Range - Range -	Warning Category Warning Category Warning	Panel display - Panel display - Panel display	- Unit Unit Unit	Data type 16 Bit Data type 16 Bit Data type 16 Bit

	201F-15	Latest 1st warning code WarmCodeLast1st	-	Warning	-	-	16 Bit
Ī	Display the	1st warning code of the r	most recent of serv	vo drive			

	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-22	Latest 2nd warning					
201F-16	code	-	Warning	-	-	16 Bit
	WarmCodeLast 2 nd					

	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-23	Latest 3rd warning					
201F-17	code	-	Warning	-	-	16 Bit
	WarmCodeLast 3 rd					

	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-24	Latest 4th warning					
201F-18	code	-	Warning	-	-	16 Bit
	WarmCodeLast 4 th					

	Monitoring name	Range	Category	Panel display	Unit	Data type
U1-25	Latest 5th warning					
201F-19	code	-	Warning	-	-	16 Bit
	WarmCodeLast 5 th					

Group 2020h: Device Monitoring


U2-01	Monitoring name	Range	Category	Panel display	Unit	Data type
2020-01	Product series		Device	Hexadecimal	_	16 Bit
	ProductSer	-	Device	пехацесина	-	10 Bit

Display the product series code of servo drive.

The VD3E servo drive code is 0x3345. The panel is displayed as below:



U2-0	Monitoring name	Range	Category	Panel display	Unit	Data type	•
2020-	Model Model1	-	Device	Hexadecimal	-	16 Bit	
Displa	y the servo drive model.						
	U2-01 display		U2-02	2 display	Mod	del	
					VD3E-00	3SA1G	
					VD3E-01	.0SA1G	
					VD3E-01	4SA1G	
		15		501	VD3E-01	.6SA1G	
					VD3E-01	.9SA1G	
					VD3E-02	21SA1G	
					VD3E-02	:5SA1G	



U2-03	Monitoring name	Range	Category	Panel display	Unit	Data type
2020-03	Model		Davisa	Have de sime		4.C Dit
	Model2	-	Device	Hexadecimal	-	16 Bit

U2-04	Monitoring name	Range	Category	Panel display	Unit	Data type
2020-04	Firmware version	-	Device	Decimal	-	16 Bit
	FirewareVer					

Display the firmware version.

Display format: X.YY. For example, 1.02. The panel is displayed as below.



U2-05	Monitoring name	Range	Category	Panel display	Unit	Data type
2020-05	cm firmware version CM FireWave	-	Device	Decimal	-	16 Bit

Display the Servo Hardware (FPGA) version.

Display format: X. YY, 2 decimal places. For example 1.00, the servo drive panel is displayed as follows:



U2-06 Monitoring name Range Category Panel display Unit Data t
--

2020-0	Firmware time (year)					
	ExFactoryYear	-	Device	Decimal	Year	16 Bit

U2-07	Monitoring name	Range	Category	Panel display	Unit	Data type
2020-07	Firmware time (month) ExFactoryMonth	-	Device	Decimal	Month	16 Bit

U2-08	Monitoring name	Range	Category	Panel display	Unit	Data type
2020-08	Firmware Date (Day)		Device	Decimal	Day	16 Bit
	ExFactoryDay	-	Device	Decimal	Day	10 Bit

Display the production date of display firmware.

Taking the "VD3E-014SA1G_V1. 03 firmware production date is January 10, 2022" as an example, the drive panel is displayed as below:

U2-06	U2-07	U2-08

U2-09	Monitoring name	Range	Category	Panel display	Unit	Data type
2020-09	Device serial number 1		_			
	DeviceSerNum1	-	Device	Decimal	-	16 Bit

U2-10	Monitoring name	Range	Category	Panel display	Unit	Data type
2020-0A	Device serial number 2	-	Device	Decimal	-	16 Bit
	DeviceSerNum2					

U2-11	Monitoring name	Range	Category	Panel display	Unit	Data type
2020-0B	Device serial number 3		B	De atau al		46 84
	DeviceSerNum3	-	Device	Decimal	-	16 Bit

U2-12	Monitoring name	Range	Category	Panel display	Unit	Data type
2020-0C	EtherCAT XML	-	Device	Decimal	-	16 Bit

16 Bit

	Version number					
U2-13	Monitoring name	Range	Category	Panel display	Unit	Data type

Device

Decimal

2020-0D

Chip model (high byte)

U2-14	Monitoring name	Range	Category	Panel display	Unit	Data type
2020-0E	Chip model (low byte)	-	Device	Decimal	-	16 Bit

U2-15	Monitoring name	Range	Category	Panel display	Unit	Data type
2020-0F	CPU ID (high byte)	-	Device	Decimal	-	16 Bit

U2-16	Monitoring name	Range	Category	Panel display	Unit	Data type
2020-10	CPU ID (low byte)	-	Device	Decimal	-	16 Bit

8.4 Standard Equipment Sub-protocol Area (6000h to 6FFFh)

603F	Parameter name	Accessibility	Mapped or not	Setting in force	Range	Default value	Correlation mode	Data type	Unit
	Error Code	RO	TPDO	-	0 to 65535	-	ALL	16-bit	-

When a drive fault alarm occurs, 603F represents the corresponding servo internal fault alarm code. For example: When the drive has an encoder disconnection fault, 603F is 27.

	Parameter name	Accessibility	Mapped or not	Setting in force	Range	Default value	Correlation pattern	Data Type	Unit
6040	Control Word	RW	RPDO	Run setting stop takes effect	0 to 65535	0	ALL 16 bits		-

Used to set control instructions. It is meaningless to assign each bit of a control word separately, and it must be combined with other bits to form a certain control instruction.

bit0 ~ bit3 have the same meaning in each control mode of servo drive, and commands must be sent in sequence before the servo drive can be switched according to CiA402 state machine.

Bit	Name	Description
0	Servo operation can be started	0: Invalid
	, , , , , , , , , , , , , , , , , , , ,	1: Valid
1	Connect the main circuit	0: Invalid
_		1: Valid
2	Quick stop	0: Valid
-	Quick Stop	1: Invalid
3	Servo running	0: Invalid
3	Servo running	1: Valid
4 to 6	Operation mode	It is related to the operation mode of servo driver
		Used to clear resettable faults. The rising edge of bit7 is valid;
7	Fault reset	bit7 is kept as1, and other control instructions are invalid.
8	Pause	Please query the Object Dictionary for the pause mode in each
		mode 605D
9	Reserved	Undefined
10	Reserved	Undefined
11~15	Manufacturer customized	Manufacturer customized

6041	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
	Status Word (Status Word)	RO	TPDO	-	0 ~65535	0	ALL	16 bit	-

Used to display servo drive status.

Bit	Name	Description
0	Servo ready	0: Invalid
U	Servo ready	1: Valid
1	Servo operation can be started	0: Invalid
_	Servo operation can be started	1: Valid
2	Servo operation	0: Invalid
	Servo operation	1: Valid
3	fault	0: Invalid
,	lauit	1: Valid
4	Electrical connection of main	0: Invalid
7	circuit	1: Valid
5	Quick shutdown	0: Invalid
3	Quick shutdown	1: Valid
6	Servo is not operational	0: Invalid
0	Servo is not operational	1: Valid
7	Warning	0: Invalid
,	warning	1: Valid
8	-	-
9	Remote control	0: Invalid
3	Remote control	1: Valid
10	Target arrival	0: Invalid
10	Target arrival	1: Valid

Bit 0 to bit 9 have the same meaning in all control modes of servo drive. After the control word 6040h sends commands in sequence, the servo feeds back the determined state.

Setting value (binary number)	Description
xxxx xxxx x0xx 0000	Servo is not ready
xxxx xxxx x1xx 0000	Startup failure
xxxx xxxx x01x 0001	Servo ready
xxxx xxxx x01x 0011	Start up
xxxx xxxx x01x 0111	Servo enable
xxxx xxxx x00x 0111	Malfunction shutdown valid
xxxx xxxx x0xx 1111	Fault response valid
xxxx xxxx x0xx 1000	Fault

605A	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
	Quick stop option selection	RW	NO	-	0 to 7	2	ALL	16 bit	-
Used to	Used to set the quick stop mode.								

60 5B	Parameter name	Accessibility	Mapped or not	Setting in force	Range	Default value	Correlation mode	Data type	Unit

Stop Option Code	RW	NO	-	0 to 1	0	ALL	16-bit	-

When the servo state machine executes the Shutdown instruction from the Operational state, the servo stops according to the stop mode defined by 605Bh.

Setting value	Name
0	Drive enter OFF Status, drive is free stop. The motor axis remains free.
1	With6084 After decelerating and stopping, The motor axis remains free.

	Parameter name	Accessibility	Mapped or not	Setting in force	Range	Default value	Correlatio n mode	Data type	Unit
605	Servo OFF shutdown mode selection (Disable Operation Option Code)	RW	NO	-	0 to 1	0	ALL	16-bit	-

Used to set the shutdown mode after shutdown is enabled.

Setting value	Name
0	Drive enter OFF Status, drive is free stop. The motor axis remains free.
1	With6084 After decelerating and stopping, The motor axis remains free.

605	Parameter name	Accessibility	Mapped or not	Setting in force	Range	Default value	Correlatio n mode	Data type	Unit		
D	Pause shutdown mode selection (Halt option code)		NO	-	1 to 3	1	ALL	16-bit	-		
Used to s	Used to set the shutdown mode for pause.										

	Parameter name	Accessibility	Mapped or not	Setting in force	Range	Default value	Correlati on mode	Data type	Unit
605E	Fault shutdown mode selection (Fault ReactionOption Code	RW	NO	-	0 to 3	0	ALL	16-bit	-

Used to set the shutdown mode in case of failure.

Setting value	Name
0	Category 3 failed drive free stop. The motor axis remains free.
1	The motor axis remains free after the machine is stopped at 6084 deceleration for category 3 faults.
2	The motor axis remains free after the machine is stopped at 6085 deceleration for category 3 faults.

The motor axis remains free after shutdown with emergency shutdown torque reduction for category 3 faults.

Note: VD3E'sClass 1/2 fault stop mode only supports free stop.

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
6060	Servo mode selection (Modes of operation)	RW	RPDO	Set value takes effect at the time of shutdown	0~10	0	ALL	8 bit	-

Used to set the operation mode of servo drive.

Setting value	Name	Remarks			
1	Contour position control mode	-			
3	Contour speed control mode	-			
4	Contour torque control mode	Please refer to "7.7 Profile torque Mode" for details			
6	Origin return mode	Please refer to "7.8 Homing Mode" for details			
7	Interpolation mode	-			
8	Cyclic Synchronous Position mode	Please refer to "7.4 Cyclic Synchronous Position mode (CSP)" for details			
9	Periodic synchronous speed mode	Please refer to "7.5 Cyclic Synchronous Velocity mode (CSV)" for details			
10	Periodic synchronous torque mode	Please refer to "7.6 Cyclic Synchronous Torque mode (CST)" for details			

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
6061	Run mode display (Mode	RO	TPDO	-	0~10	0	ALL	8 bit	-
	operation)								

Used to display the current operation mode of servo drive.

Setting value	Name	Remarks			
1	Contour position control				
_	mode	-			
3	Contour speed control				
	mode	-			
4	Contour torque control	Please refer to "7.7 Profile Torque mode" for details			
4	mode				

6	Origin return mode	Please refer to "7.8 Homing Mode" for details
7	Interpolation mode	-
8	Cyclic Synchronous Position mode	Please refer to "7.4 Cyclic Synchronous Position mode (CSP)" for details
9	Periodic synchronous speed mode	Please refer to "7.5 Cyclic Synchronous Velocity mode (CSV)" for details
10	Periodic synchronous torque mode	Please refer to "7.6 Cyclic Synchronous Torque mode (CST)" for details

coca	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
6062	position command (Position demand value)	RO	TPDO	-	-	0	CSP HM PP	32 bit	Instruction unit

It is used to reflect the position command (command unit) that has been input by the servo in the enabled state.

6063	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
	Position feedback (Position actual value)	RO	TPDO	-	-	0	ALL	32 bit	Instruction unit
Used to reflect the absolute position of motor.									

6064	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
6064	Position feedback (Position actual value)	RO	TPDO	-	-	0	ALL	32 bit	Instruction unit

Used to reflect real-time absolute position.

"Position Feedback 6064h" * "Gear Ratio 6091h" = "Position Feedback 6063h"

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
6065	Threshold of excessive position deviation (Following error window)	RW	RPDO	Set value takes effect at	0 ~ (2 ³¹ -1)	524288	CSP HM PP	32 bit	Instruction unit

		the time			
		of			
		shutdown			

Used to set the position deviation excess threshold.

When the position deviation exceeds the set value of 6065h, Er.36 (excessive position deviation) will occur in servo.

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode
6067	Position arrival threshold (Position window)	RW	RPDO	Set value takes effect at the time of shutdown	0 ~ (2 ³² -1)	1000	СЅР НМ РР

Used to set the threshold value for position arrival.

When the position deviation is within the set value of ±6067h, the position is determined to have arrived.

In position mode, bit10=1 for status word 6041

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
6068	Position window time (Position window time)	RW	RPDO	Set value takes effect at the time of shutdown	0 ~65535	100	PP HM CSP	16 bit	Ms

Used to set the position window time of the servo drive under the position mode.

cocc	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
606C	Actual velocity								
	(Velocity actual value)	RO	TPDO	-	-	-	ALL	32 bit	Instruction unit/s

Used to display the actual rotating speed of the servo drive.

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
606D	Velocity arrival threshold (Velocity window)	RW	RPDO	Set value takes effect at the time of shutdown	0 ~65535	30	PV	16 bit	Instruction unit/s
Used to	set the velocity arriva	al threshold of s	ervo drive u	inder the velo	ocity mode.				

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
606E	Velocity window time (Velocity window time)	RW	RPDO	Set value takes effect at the time of shutdown	0 ~65535	10	PV	16 bit	ms

Used to set the velocity window time of servo drive under the velocity mode.

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
6071	Target torque (Target torque)	RW	RPDO	Set value takes effect at the time of shutdown	-3000~3000	0	PT CST	16 bit	0.1%
Used to	set the target torq	ue of servo driv	e under the	torque mode					

	Parameter name	Accessibility	Data mapping	Setting in force	Data display range	Default value	Correlation mode	Data type	Unit
6072	Maximum torque Instruction (Max torque)	RW	RPDO	Operation setting Effective immediately	0~3000	3000	ALL	16-bit	0.1%

Used to set the maximum torque instruction of the servo drive in PT/CST mode.

6077	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
6077	Actual torque (Torque actual value)	RO	TPDO	-	-3000~3000	0	PT CST	16 bit	0.1%
Used to	display the actual tor	que value of se	rvo drive un	der the torque	mode.				

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
607A	Target location (target position)	RW	RPDO	Set value takes effect at the time of shutdown	(-2 ³¹) ~ (2 ³¹ -1)	0	CSP HM PP	32 bit	Instruction unit

Used to set the servo target position of the servo drive in the periodic synchronous mode (CSP).

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
607C	Home offset (Home offset)	RW	RPDO	Set value takes effect at the time of shutdown	(-2 ³¹) ~ (2 ³¹ -1)	0	нм	32 bit	Instruction unit

Used to set the physical position of the mechanical Origin return mode from the motor origin in home return mode. This object dictionary only takes effect when the servo is powered on, the origin return operation is completed, and the status word 6041 is bit15=1.

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
607F	Maximum profile velocity (Max profile velocity)	RW	RPDO	Set value takes effect at the time of shutdown	0~(2 ³¹ -1)	0	ALL	32 bit	Instruction unit/s

Set the maximum operating speed of user.

The set value takes effect when the velocity instruction of slave station changes.

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
6081	Profile velocity (Profile velocity)	RW	RPDO	Set value takes effect at the time of shutdown	0 ~ (2 ³¹ -1)	218453	РР	32 bit	Instruction unit/s

Set the constant operating speed of the shift instruction under the profile position mode.

The set value takes effect after the salve station receives the shift instruction.

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
6083	Profile acceleration (Profile acceleration)	RW	RPDO	Set value takes effect at the time of shutdown	0 ~ (2 ³² -1)	13107200	PP PV	32 bit	Instruction unit/s²

Set the acceleration under the profile position mode and profile velocity mode.

Under the profile position mode, the set value takes effect after the position command is triggered. The minimum value of the periodic position command increment of each position loop is 1.

Under the profile velocity mode, the operation takes effect.

If the parameter value is set to be 0, it will be converted to 1 compulsorily.

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
6084	Profile deceleration (Profile deceleration)	RW	RPDO	Set value takes effect at the time of shutdown	0 ~ (2 ³¹ -1)	13107200	PP PV CSP CSV	32 bit	Instruction unit/s²

Set the deceleration under the profile position mode and profile velocity mode.

Under the profile position mode, the set value takes effect after the position command is triggered.

Under the profile velocity mode, the operation takes effect.

Under PP CSV PV mode, the quick-stop option code (605A) is equal to 1 or 5, the deceleration of slope shutdown takes effect when the quick-stop command is valid;

Under PP CSV PV mode, the halt option code (605D) is equal to 1, the deceleration of slope shutdown takes effect when halt command is valid.

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
608	Quick stop deceleration (Quick stop deceleration)	RW	RPDO	Set value takes effect at the time of shutdown	0 ~ (2 ³¹ -1)	100	PP PV HM CSP CSV	32 bit	Instruction unit/s ²

Under PP CSV PV HM mode, the quick-stop option code (605A) is equal to 2 or 6, the deceleration of slope shutdown takes effect when the quick-stop command is valid.

Under PP CSV PV HM mode, the halt option code (605D) is equal to 2, the deceleration of slope shutdown takes effect when the halt command is valid.

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
6086	Motion profile type (Motion profile type)	RW	RPDO	Set value takes effect at the time of shutdown	2 ^{15~} (2 ¹⁵ -1)	0	-	16 bit	-

Set the profile type of the motor position command or velocity command.

0: linear

For now, only "0" is supported.

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data tyoe	Unit
6087	Torque slope (Torque slope)	RW	RPDO	Set value takes effect at the time of shutdown	0 ~ (231-1)	100	PT CST	32 bit	0.1%/s

Set the torque command acceleration under the profile torque mode, which means the torque command increment per second.

-			Cha	pter 8 Object D	ictionary				
6091	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
0031	Gear Ratio	-	-	-	-	-	CSP HM PP PV CSV	-	-
Set ran	ge of electronic gear ra	tio: "0.001* en	coder resolu	ition/10000, 40	00* encode	r resolutio	n/10000"		
Beyond this set range, Er.35 (electronic gear ratio overrun) will occur in servo drive.									
	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Dtaa type	Unit
01h	Electronic gear ratio numerator (Motor revolutions)	RW	RPDO	Set value takes effect at the time of shutdown	1 ~ (2 ³² -1)	1	-	32 bit	-
Used to	set the motor resolut	ion.							
	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
02h	Electronic gear			Set value takes effect	1~				

	set the load	ahaft	
usea to	set the load	i snart resc	Jiuuon.

ratio denominator

(Shaft revision)

RW

RPDO

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
6098	Zero return mode (Homing method)	RW	RPDO	Set value takes effect at the time of shutdown	1~35	1	нм	8 bit	-

at the time

of

shutdown

32 bit

1

 $(2^{32}-1)$

Used to select homing method.

method	Deceleration point	Origin
1	Reverse overtravel switch	Motor Z signal
2	Forward overtravel switch	Motor Z signal
3	Origin switch	Motor Z signal
4	Origin switch	Motor Z signal
5	Origin switch	Motor Z signal
6	Origin switch	Motor Z signal
7	Origin switch	Motor Z signal
8	Origin switch	Motor Z signal
9	Origin switch	Motor Z signal
10	Origin switch	Motor Z signal
11	Origin switch	Motor Z signal
12	Origin switch	Motor Z signal
13	Origin switch	Motor Z signal
14	Origin switch	Motor Z signal
17	Reverse overtravel switch	Reverse overtravel switch
18	Forward overtravel switch	Forward overtravel switch

Origin switch	Origin switch
Origin switch Origin switch Origin switch Origin switch	Origin switch Origin switch Origin switch Origin switch
Origin switch Origin switch Origin switch	Origin switch Origin switch Origin switch
Origin switch Origin switch	Origin switch Origin switch
Origin switch	Origin switch
	_
Origin switch	Origin switch
Origin switch	Origin switch
None	Motor Z signal
None	Motor Z signal
-	Current position
	Origin switch None

6099	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
	Homing speed (Homing speeds)	-	-	-	-	-	нм	-	-

Used to set two speed values in homing mode

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
01	Speed during search for switch (Speed during search for switch)	RW	RPDO	Set value takes effect at the time of shutdown	0 ~ (2 ³² -1)	100	нм	32 bit	Instruction unit/s

Used to set the speed of searching deceleration point signal. It is recommended to set the speed to a higher value to prevent Er.44 (back-to-original timeout fault) caused by too long zero return time

•													
02	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit				
-	Speed during search for zero (Speed during	RW	RPDO	Set value takes effect at the time	10 ~ (2 ³² -1)	100	нм	32 bit	Instcution unit/s				

search for zero)		of			
,		shutdown			

Used to set the speed of searching origin signal. It is recommended to be set to a lower value to prevent overshoot caused by high-speed stop.

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
609A	Home acceleration (Home acceleration)	RW	RPDO	Set value takes effect at the time of shutdown	0 ~ (2 ³² -1)	655360	нм	32 bit	Instruction unit/s

Used to set the acceleration in homing mode. When the origin zero return operation is started, the set value takes effect. Home acceleration refers to the increment of position command (command unit) per second.

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
60B0	Position offset (Position offset)	RW	RPDO	Set value takes effect at the time of shutdown	(-2 ³¹) ~ (2 ³¹ -1)	0	CSP	32 bit	Instruction unit

Used to set the servo position command offset amount in the Cyclic Synchronous Position mode (CSP).

After offset, servo target position = 607A (target position) + 60B0 (position offset).

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
60B2	Torque offset (Torque offset)	RW	RPDO	Set value takes effect at the time of shutdown	(-2 ³¹) ~ (2 ³¹ -1)	0	сѕт	32 bit	0.1%

Used to set the servo torque command offset in the cycle synchronous torque mode (CST).

The actual target torque command of the servo after offset = 6071 (target torque) + 60B2 (torque offset).

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit			
60B8	Touch probe function (Touch probe function)	RW	RPDO	Set value takes effect at the time of shutdown	0~65535	0	-	16 bit	-			
Used to	Used to set the function of probe 1 and probe 2.											

CORO	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit			
60B9	Touch probe status (Touch probe status)	RO	TPDO	-	0~65535	0	-	16 bit	-			
Used to	Used to read the status of probe 1 and probe 2.											

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit		
60BA	Probe 1 rising edge position value (Touch Probe Pos1 Pos Value)	RO	TPDO	-	(-2 ³¹) ~ (2 ³¹ -1)	0	-	32 bit	Instruction unit		
Used to display the rising edge and position value of probe 1 signal (instruction unit).											

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit			
60BB	Probe 1 falling edge position value (Touch Probe Pos1 Neg Value)	RO	TPDO	-	(-2 ³¹) ~ (2 ³¹ -1)	0	-	32 bit	Instruction unit			
Used to	Used to display the falling edge and position value of probe 1 signal (command unit).											

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
60BC	Probe 2 rising edge position value (Touch Probe Pos2 Pos Value)	RO	TPDO	-	(-2 ³¹) ~ (2 ³¹ -1)	0	-	32 bit	Insturction unit
Used to	Used to display the rising edge and position value of probe 2 signal (Instruction unit).								

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
60BD	Probe 2 falling edge position value (Touch Probe Pos2 Neg Value)	RO	TPDO	-	(-2 ³¹) ~ (2 ³¹ -1)	0	-	32 bti	Instruction unit
Used to	Used to display the falling edge and position value of probe 2 signal (command unit).								

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
60C5	Maximum acceleration (Max profile	RO	TPDO	-	0 ~ (2 ³¹ -1)	0	ALL	32 bti	Instruction unit/s²

	accelaration)								
Set the	maximum acceleration	n allowed in the	acceleratio	n segment	in the profile	position m	ode and profil	e velocity i	node.

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
60C6	Maximum deceleration (Max profile decelaration)	RO	TPDO	-	0 ~ (2 ³¹ -1)	0	ALL	32 bti	Instruction/s ²

Set the maximum acceleration allowed in the deceleration segment in the profile position mode and profile velocity mode

	Parameter name	Accessibility	Data mapping	Setting in force	Data display range	Default value	Correlation mode	Data type	Unit
60E0	Forward direction maximum torque limit	RW	RPDO	Operation setting Effective immediately	0 to 3000	3000	ALL	16-bit	0.1%

Set the positive maximum torque limit of the servo.

Note: It takes effect when the parameter P1-14=2.

	Parameter name	Accessibility	Data mapping	Setting in force	Data display range	Default value	Correlation mode	Data type	Unit
60E1	Reverse direction maximum torque limit	RW	RPDO	Operation setting Effective immediately	0 to 3000	3000	ALL	16-bit	0.1%

Set the negative maximum torque limit of the servo.

Note: It takes effect when the parameter P1-14=2.

60F4	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
6UF4	Position deviation (Following error actual value)	RO	TPDO	-	-	-	PP HM CSP	32 bit	Instruction unit
Used to display following error actual value (command unit).									

	Parameter name	Accessibility	Mapped or not	Setting in force	Range	Default value	Correlation mode	Data type	Unit
60FC	Position instruction (Position demand	RO	TPDO	-	-	-	PP HM CSP	32-bit	Encoder
	value)								unit

Used to display the position demand value (encoder unit).

When the servo is enabled, if there is no warning, the relationship between the position demand value (encoder unit) and position demand value (command unit) is shown as follows:

Position demand value 60FCh (encoder unit) = position demand value 6062h (command unit) * gear ratio (6091h).

60FD	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
	DI status (Digital Input)	RO	TPDO	-	-	-	ALL	32-bit	-

(Digital Input) Used to reflect the current DI terminal logic of drive:

method	Deceleration point	Origin
	Reverse overrun	0: Invalid
0	switch	1: Valid
1	Forward overrun	0: Invalid
1	switch	1: Valid
	Hamilton and hab	0: Invalid
2	Homing switch	1: Valid
2.45	NI A	0: Invalid
3-15	NA	1: Valid
16	DIA	0: Invalid
16	DI1	1: Valid
47	DIS	0: Invalid
17	DI2	1: Valid
10	CIO	0: Invalid
18	SI3	1: Valid

method	Deceleration point	Origin
10	D14	0: Invalid
19	DI4	1: Valid
		0: Invalid
20	DI5	1: Valid
•		0: Invalid
21	DI6	1: Valid
		0: Invalid
22	NA	1: Valid
	510	0: Invalid
23	DI8	1: Valid
		0: Invalid
24	DI9	1: Valid
25-31		0: Invalid
	NA	1: Valid

	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode
60FE	Digital Output Dictionary DigitalDoOutput	RW	RPDO	Operation setting Effective immediatel Y	0~ 65535	0	ALL

	60EF-01	
bit	name	description
0-15	retain	-
16	6 DO_1	0: Forced output OFF
	30_2	1: Forced output ON
17	DO_2	0: Forced output OFF
	30_1	1: Forced output ON
18	DO_3	0: Forced output OFF
10 00_3	20_3	1: Forced output ON
19-31	retain	-

60EF-02						
bit	name	description				
0-15	retain	-				
16	DO_1	0: Forced output OFF				
10	50_1	1: Forced output ON				
17	DO_2	0: Forced output OFF				
17	50_2	1: Forced output ON				
18	DO_3	0: Forced output OFF				
18	50_3	1: Forced output ON				
19-31	retain	-				

60F4	Parameter name	Accessibility	Data mapping	Set to take effect	Data display range	Default	Correlation mode	Data type	Unit
	Profile velocity	RW	RPDO	-	(-2 ³¹) ~ (2 ³¹ -1)	0	PP CSV	32 bit	unit/s
Set the	user speed command in th	ne profile speed	mode and cy	cle synchi	ronous spe	ed mode.			

	Parameter name	Accessibility	Mapped or not	Setting in force	Range	Default value	Correlation mode	Data type	Unit
6502	Support servo operation mode	RO	TPDO	-	-	-	-	32-bit	-
	(Supported drive modes)								

Reflect the servo operation mode supported by the drive.

		Support or not
Bit	Description	0-Not supported
		1-Support
0	Profile Position Mode (PP)	1
1	NA	0
2	Profile Velocity Mode (PV)	1
3	Profile Torque Mode (PT)	1
4	NA	0
5	Homing mode (HM)	1
6	Interpolation mode	0
7	Periodic Synchronous Position Pattern (CSP)	1
8	Cycle Synchronous Speed Mode (CSV)	1
9	Periodic Synchronous Torque mode (CST)	1
10~31	Manufacturer customized	Reserved

Chapter 9 Adjustments

9.1 Overview

The servo drive needs to make the motor work without delay as much as possible in accordance with the instructions issued by the host controller. In order to make the motor run based on command as much as possible and maximize the mechanical performance, it is necessary to adjust the gain. The flow of gain adjustment is as shown in Figure 9-1.




Figure 9-1 Gain adjustment process

The servo gain is composed of multiple sets of parameters such as position loop, speed loop, filter, load inertia ratio, etc., and they affect each other. In the process of setting the servo gain, the balance between the setting values of each parameter must be considered.



The gain adjustment process description is shown in Table 9-1.

Table 9-1 Gain adjustment process description

	Gain adjustment	t process	Function	Detailed chapter
1	Inertia identification Automatic gain adjustment		Automatic load inertia ratio identification is carried out by using the upper computer debugging platform software matched with the drive.	9.2
2			On the premise of setting the inertia ratio correctly, the drive automatically adjusts a set of matching gain parameters.	9.3.1
3	Basic gain Manual gain adjustment Feedforward gain		On the basis of automatic gain adjustment, if the expected effect is not achieved, manually fine-tune the gain to optimize the effect.	9.3.2
			The feedforward function is enabled to improve the followability.	9.3.3
4	Vibration suppression	Mechanical resonance	The notch filter function is enabled to suppress mechanical resonance.	9.4.1

9.2 Inertia identification

Load inertia ratio "2003-01" refers to:

Load inertia ratio =
$$\frac{\text{Total moment of inertia of mechanical load}}{\text{Moment of inertia of the motor}}$$

Load inertia ratio is an important parameter of servo system. Correct setting of load inertia ratio is helpful to complete debugging quickly.



Before performing online load inertia identification, the following conditions should be met:

The maximum speed of the motor should be greater than 300rpm;

The actual load inertia ratio is 0.00~Between 100.00;

The load torque is relatively stable, and the load cannot change drastically during the measurement process;

The backlash of the load transmission mechanism is within a certain range;

The motor's movable stroke should meet following two requirements:

There is a movable stroke of more than 1 circle in both forward and reverse directions between the mechanical limit switches. Before performing online inertia identification, please make sure that the limit switch has been installed on the machine, and the motor has a movable stroke of more than 1 circle respectively in the forward and reverse directions to prevent overtravel during the inertia identification process, which may cause accidents.

Meet the requirements of inertia identification turns [2003-05]; make sure that the motor's movable stroke at the stop position is greater than the set value of the number of inertia identification circles [2003-05], otherwise the maximum speed of inertia identification [2003-06] should be appropriately reduced.

During the automatic load inertia identification process, if vibration occurs, the load inertia identification should be stopped immediately.

Related function codes are shown in Table 9-2.

Table 9-2 Details of inertia identification related parameters

Function code	Name	Setting method	valid time	Default	Range	Definition	Unit
2003-01	Load inertia ratio	OperationSetting	valid immediately	300	100~10000	Set load inertia ratio, 0.00~100.00 times	0.01
2003-05	Inertia identificationcircles	Shutdown Setting	valid immediately	2	1~20	Offline load inertia identification process, motor rotation number setting	Circle
2003-06	Maximum speed of inertia identification	Shutdown Setting	valid immediately	1000	300~2000	Set the allowable maximum motor speed instruction in offline inertia identification mode. The faster the speed during inertia identification is, the more	rpm

Chapter 9 Adjustments

						accurate the identification result will be. Generally, keep the default value.
2003-07	Parameter identification of rotation direction	Shutdown Setting	valid immediately	0	0 to 2	0: Forward and reverse reciprocating rotation 1: Forward one-way rotation 2: Reverse one-way rotation

9.3 Gain Adjustment

In order to optimize the responsiveness of the servo drive, the gain set in the servo drive needs to be adjusted. Servo gain needs to set multiple parameter combinations, which will affect each other. Therefore, the adjustment of servo gain must consider the relationship between each parameter.

Under normal circumstances, high-rigidity machinery can improve the response performance by increasing the servo gain. But for machines with lower rigidity, when the servo gain is increased, vibration may occur, which will affect the increase in gain. Therefore, selecting appropriate servo gain parameters can achieve higher response and stable performance.

The servo supports automatic gain adjustment and manual gain adjustment. It is recommended to use automatic gain adjustment first.

9.3.1 Automatic Gain Adjustment

Automatic gain adjustment means that through the rigidity level selection function [2003-02], the servo drive will automatically generate a set of matching gain parameters to meet the requirements of rapidity and stability.

The rigidity of the servo refers to the ability of the motor rotor to resist load inertia, that is, the self-locking ability of the motor rotor. The stronger the servo rigidity is, the greater the corresponding position loop gain and speed loop gain can achieve, and the faster the response speed of the system will be.



Before adjusting the rigidity grade, set the appropriate load inertia ratio correctly [2003-01].

The value range of rigidity grade is between 0~ 31. The value range of the rigidity grade is between 0 and 31. Grade 0 corresponds to the weakest rigidity and minimum gain, and grade 31 corresponds to the strongest rigidity and maximum gain. According to different load types, Table 9-3 Empirical values can be used for reference.

Table 9-3 Experience reference of rigidity grade

Rigidity grade	Load mechanism type
Grade 4 to 8	Some large machinery
Grade 8 to 15	Low rigidity applications such as belts
Grade 15 to 20	High rigidity applications such as ball screw and direct connection

When the function code [2003-03] is set to 0, the gain parameters are stored in the first gain by modifying the rigidity grade.

When debugging with the upper computer debugging software, automatic rigidity level measurement can be carried out, which is used to select a set of appropriate rigidity grades as operating parameters. The operation steps are as follows:

Step 1 Confirm that the servo is in the ready state, the panel displays "ry", and the communication line is connected;

Step 2 Open the servo drive debugging software, enter the trial run interface, set the corresponding parameters, and click "Servo on";

Step 3 Click the "forward" or "reverse" button to confirm the travel range of the servo operation; Step 4 After the "Start Identification" of inertia identification lights up, click "Start Identification" to start inertia identification to measure the load inertia.

Step 5 After the inertia identification test is completed, click "Save inertia value";

Step 6 Click "Next" at the bottom right to go to the parameter adjustment interface, click "Parameter Measurement" to start parameter measurement.

Step 7 After the parameter measurement is completed, the servo drive debugging software will pop up a confirmation window for parameter writing and saving.

There may be a short mechanical whistling sound during the test. Generally, the servo will automatically stop the test. If it does not stop automatically or in other abnormal situations, you can click the "Servo Off" button on the interface to turn off the servo, or power off the machine! For the detailed operation of the upper computer debugging software, please refer to "Wecon SCTool Software User Manual".

Table 9-4 Self-tuning mode selection parameter details

Index code	Name	Setting method	Valid time	Default	Range	Definition	Unit
2003-03	Self-adjusting mode selection	OperationSetting	Valid immediately	0	0 to 2	O: Rigidity grade self-adjusting mode. Position loop gain, speed loop integral time constant, torque filter parameter settings are automatically adjusted according to the rigidity grade setting. 1: Manual setting. Users need to manually set the position loop gain, speed loop gain, speed loop integral time constant, and torque filter parameter setting 2: Online automatic parameter self-adjusting mode (Not implemented yet)	-

9.3.2 Manual Gain Adjustment

When the servo automatic gain adjustment fails to achieve the desired result, you can manually fine-tune the gain to achieve better results.

The servo system consists of three control loops, from the outside to the inside are the position loop, the speed loop and the current loop. The basic control block diagram is shown as below.




Figure 9-2 Basic block diagram of servo loop gain

The more the inner loop is, the higher the responsiveness is required. Failure to comply with this principle may lead to system instability!

The default current loop gain of the servo drive has ensured sufficient responsiveness, generally no adjustment is required, only the position loop gain, speed loop gain and other auxiliary gains need to be adjusted.

(1) Speed loop gain

The speed loop gain determines the highest frequency of the changing speed command that the speed loop can follow.

In the case of no vibration or noise in the mechanical system, the larger the speed loop gain setting value is, the better the response of servo system and the better the speed followability can achieve. When noise occurs in the system, reduce the speed loop gain. Related function codes are shown in Table 9-5.

				•			
Index	Name	Setting	Valid	Default	Range	ze Definition	
code		method	time			Definition	Unit
2002-02	1st speed loop gain	OperationSetting	Valid immediately	65	0~35000	Set the speed loop proportional gain to determine the responsiveness of the speed loop.	0.1Hz

Table 9-5 Details of speed loop gain parameters




Figure 9-3 Gain Effect Schematic Diagram of Velocity Loop

(2) Speed loop integral time constant

The speed loop integral time constant is used to eliminate the speed loop deviation. Decreasing the integral time constant of the speed loop can increase the speed of the speed following. If the set value is too small, is will easily cause speed overshoot or vibration. When the setting value of time constant is too large, the integral action will be weakened, resulting in a deviation of the speed loop. Related function codes are shown in Table 9-6.

Table 9-6 Details of speed loop integral time constant parameters

Setting Valid

Index code	Name	Setting method	Valid time	Default	Range	Definition	Unit
2002-03	speed loop 1st integral time	OperationSetting	Valid immediately	1000	100~65535	Set the speed loop integral constant. The smaller the set value is, the stronger the integral effect will be.	0.1ms




Figure 9-4 Sketch for the effect of integrating time constant of velocity loop

(3) Position loop gain

Determine the highest frequency of the position command that the position loop can follow the change. Increasing this parameter can speed up the positioning time and improve the ability of the motor to resist external disturbances when the motor is stationary. However, if the setting value is too large, the system may be unstable and disrupted. Related function codes are shown in Table 9-7.

Table 9-7 Details of position loop gain parameters

Index	Name	Setting	Valid	Default	Range	Definition	Unit	
code		method	time					

Chapter 9 Adjustments

2002-01	1st position loop gain	OperationSetting	Valid immediately	400	0~6200	Set the position loop proportional gain to determine the responsiveness of the position control system.	0.1Hz
			Increase 2002-01	⇒ /		Real speed Position instruction	

Figure 9-5 Gain effect schematic diagram of position loop

(4) Torque instruction filter time

Selecting an appropriate torque filter time constant could suppress mechanical resonance. The larger the value of this parameter, the stronger the suppression ability. If the setting value is too large, it will decrease the current loop response frequency and cause needle movement. Related function codes are shown in Table 9-8.

Table 9-8 Details of torque filter time constant parameters

Index code	Name	Setting method	Valid time	Default	Range	Definition	Unit
2004-04	Torque filtering time constant	Operation Setting	Valid immediately	50	10~2500	This parameter is automatically set when "Self-adusting Mode Selection" is selected as 0	0.01ms




Figure 9-6 Time Constant Effect Schematic Diagram of Torque Filtering

9.3.3 Feedforward Gain

Speed feedforward could be used in position control mode and full closed-loop function. It could improve the response to the speed instruction and reduce the position deviation with fixed speed. Speed feedforward parameters are shown in Table 9-9. See Table 9-10 for details of torque feedforward parameters.



Figure 9-7 Effect schematic of speed feedforward parameters

Table 9-9 Speed feedforward parameters

Index code	Name	Adjustment description				
2002-09	Speed feedforward gain	When the speed feedforward filter is set to 50 (0.5 ms), gradually increase speed feedforward gain, and the speed feedforward will take effect. position deviation during operation at a constant speed becomes sm				
2002-0A	Speed feedforward filtering	according to the value of the speed feedforward gain as shown in the following formula.				
2002 07	time constant	Position deviation (pulse instruction) = instruction speed [instruction unit/s] position loop gain [1/s] × (100—speed feedforward gain [%]) ÷100				

Torque feedforward can improve torque command response and reduce position deviation during fixed acceleration and deceleration.

Table 9-10 Torque feedforward parameters

Index code	Name	Adjustment description			
2002-0B	Torque feedforward gain	Increase the torque feedforward gain, because the position deviation during certain acceleration and deceleration can be close to 0, so under the idea condition that the torque does not act when the external disturbance occurs			
2002-0C	Torque feedforward filter time constant	when driving under the trapezoidal speed model, the position deviation can be made in the entire action range close to 0. In fact, there must be external disturbance torque, so the position deviation cannot be 0. In addition, like the speed feedforward, the larger the constant of the torque feedforward filter is, the smaller the action will be, with greater positional deviation of the acceleration change point.			

9.3.4 Model tracking control function

Model tracking control is suitable for position control mode. A model loop is added in addition to the three loops. In the model loop, new control quantities such as position instruction, speed feedforward and torque feedforward are generated according to the user's response requirements to the system and the ideal motor control model. Applying these control variables to the actual control loop can significantly improve the response performance and positioning performance of position control. The design block diagram is as follows.




Figure 9-8 Block diagram of model tracking control design

Use methods and conditions of model tracking control:

- ① Correctly set the inertia ratio P3-1 of the system, which can be obtained by monitoring the real-time load inertia ratio U0-20;
- ② Set the load rigidity level P3-2 and set an appropriate value. There is no need to set a high rigidity level (the recommended value with rigid load is 17-21);
 - 3 Set P2-20=1 to turn on the function of model tracking control;
- 4 Adjust the tracking control gain of P2-21 model from small to large, which can be gradually increased according to the step amount of 1000 until the responsiveness of the system meets the actual demand. The responsiveness of the system is mainly determined by this parameter;
- **5** After the responsiveness meets the requirements, appropriate adjustments can be made to improve the load rigidity level P3-2.

Note: Model tracing control is only available in position mode and not available in other modes.

Index code	Name	Setting method	Effective time	Default	Range	Definition	Unit
2002-14	Model tracking control enabled	Stop settings	Immediately	0 0 to 1		Set 1 to enable model tracking control features	
2002-15	Model tracking control gain	Stop	Immediately	1000	200 to 20000	Increasing the model tracking control gain	0.1/s

Chapter 9 Adjustments

			Chapter 3 Aujus				
		settings				can improve the	
						position response	
						performance of the	
						model loop. Too high	
						gain may cause	
						overshoot behavior.	
	Model tracking	Ston	Imamo di atalu			Gain compensation	
2002-16	control gain	Stop	Immediately	1000	500 to	affects the damping	0.10%
	compensation	settings			2000	ratio of the model	
	,					loop, and the damping	
						ratio becomes larger	
						with the increase of	
						gain compensation.	
	Model tracking	Operation	Immediately				
2002-17	control forward	Operation	iiiiiiculately	1000	0 to	Magnitude of torque	0.10%
	direction offset	settings			10000	feedforward in	
						forward and reverse	
	Model tracking	Operation	Immediately		0 to	directions in model	
2002-18	control reverse			1000	10000	tracking control	0.10%
	direction offset	settings					
	Model tracking						
2002-19	control speed	Operation	Immediately		0 to	Velocity feedforward	
	feedforward	settings		1000	10000	magnitude under	0.10%
	compensation	settings				model tracking control	

Please refer to the following table for examples of steps for adjusting servo gain.

Step	Content
1	Please try to set the correct load inertia ratio parameter P3-1.
	If the automatic adjustment mode is adopted (P3-3 is set to 0), please set the basic rigidity level parameter P3-2;
2	If the mode is adjusted manually (P3-3 is set to 1), please set the gain related to the position loop and the speed loop P2-1~P2-3 and torque filtering time constant P4-4. The setting principle is mainly non-vibration and overshoot.
3	Turn on the model tracking function P2-20 and set it to 1.
4	In the range where overshoot and vibration do not occur, improve the model tracking gain P2-21.
5	If the rigidity level of step 2 is relatively low, the rigidity level P3-2 can be appropriately increased.
6	When overshoot occurs, or when the responses of forward and reverse are different, fine-tuning is performed by model tracking control forward direction offset P2-23, model tracking control reverse direction offset P2-24, and model tracking control speed feedforward compensation P2-25.

9.3.5 Gain switching

Gain switching function:

- 1 It can be switched to a lower gain when the motor is stationary (servo enabled) to suppress vibration;
- 2 It can be switched to higher gain when the motor is stationary to shorten the positioning time;
- 3 It can be switched to higher gain in the running state of the motor to obtain better instruction tracking performance;
- 4 Different gain settings can be switched through external signals according to load equipment conditions, etc.

(1) Gain switching parameter setting

1 When P02-07=0

Fixed to the first gain (i.e. using P02-01 to P02-03), P/PI (proportional/proportional integral) control switching can be realized through DI function 10 (GAIN-SEL, gain switching).




Figure 9-9 Gain switching flowchart when P02-07=0

(2) When P02-07=1

Achieve the first gain (P02-01 to P02-03) and second gain (P02-04 to P02-06), the switching condition can be set by parameter P02-08.






Figure 9-10 Flowchart of gain switching when P02-07=1

P02-08	Content	Schematic diagram
0	Fixedly used first gain	
1	Switching with DI	
2	When torque instruction is larger	Actual speed Torque instruction Switch hysteresis Switch level First gain Second gain First gain Second gain First gain



P02-08	Content	Schematic diagram
10	With position instruction+actual speed	The description is made with reference to figure 7-10. In the previous first gain, if the position Instruction is not 0, switching to the second gain; In the previous second gain, if the status in which the position instruction is 0 continues during the delay time, keeping the second gain; When the delay time reaches, if the absolute value of the current actual speed is less than (level), the speed integration time constant is fixed at the second integration time constant, and the rest are returned to the first gain. If the absolute value of the actual speed is less than (level-hysteresis), all are returned to the first gain.



(2) Description of relevant parameters

2002-07	Parameter name	Setting method	Effective time	Default	Range	Application category	Unit
	2nd gain switching mode	Operation setting	Effective immediately	1	0 to 1	Gain control	

The switching mode of the second gain is set.

Setting value	Function
0	First gain fixed Use DI function 10 (GAIN-SEL, gain switching) to switch. DI logic invalid: PI control; DI logic valid: P Control.
1	The first gain and the second gain are switched by the set value of P02-08.

Chapter 9 Adjustments

2002-08	Parameter name	Setting method	Effective time	Default	Range	Application category	Unit
	Gain switching condition selection	Operation setting	Effective immediately	0	0 to 10	Gain control	


Set the conditions for gain switching.

Setting value	Gain switching condition	Details
0	First gain fixed	First gain fixed
1	Switch by DI terminal	Use DI function 10 (GAIN-SEL, gain switching). DI logic invalid: First gain (P02-01-P02-03); DI logic valid: Second gain (P02-04-P02-06).
2	Larger torque instruction	In the previous first gain, when the absolute value of the torque instruction exceeds (level+hysteresis), switching to the second gain; In the previous second gain, when a status in which the absolute value of the torque instruction is less than (level-hysteresis) continues during the delay time, the second gain is returned to the first gain.
3	When actual torque is larger	In the previous first gain, when the absolute value of the actual torque exceeds (level+hysteresis), switching to the second gain; In the second gain of the previous time, when a state in which the absolute value of the actual torque is less than (level-hysteresis) continue during the delay time, the second gain is returned to the first gain.
4	When speed instruction is larger.	In the previous first gain, when the absolute value of the speed command exceeds (level+hysteresis), switching to the second gain; When the state where the absolute value of the speed instruction is less than (level-hysteresis) in the previous second gain continues during the delay time, the gain returns to the first gain.
5	When actual speed is larger	In the previous first gain, when the absolute value of the actual speed exceeds (level+hysteresis), switching to the second gain; In the second gain of the previous time, when a status in which the absolute value of the actual speed is less than (level-hysteresis) continues during the delay time, the first gain is returned to the first gain.
6	When speed instruction change rate is larger.	In the previous first gain, when the absolute value of the speed command change rate exceeds (level+hysteresis), switching to the second gain; In the previous second gain, when a status in which the absolute value of the speed command change rate is less than (level-hysteresis) continues during the delay time, the gain is returned to the first gain.
7	When position deviation is larger	In the previous first gain, when the absolute value of the position deviation exceeds (level+hysteresis), switching to the second gain; In the previous second gain, when a status in which the absolute value of the position deviation is less than (level-hysteresis) continues during the delay time, the gain is returned to the first gain.
8	There is a position instruction	In the previous first gain, if the position Instruction is not 0, switching to the second gain;

		If the state where the position instruction is 0 continues during the delay time in the previous second gain, the gain returns to the first gain.
9	Positioning completed	In the previous first gain, if the positioning is not complete, switching to the second gain; In the second gain of the previous time, if the positioning incomplete status persists during the delay time, the first gain is returned.
10	With position instruction+actual speed	In the previous first gain, if the position Instruction is not 0, switching to the second gain; In the previous second gain, if the state in which the position instruction is 0 continues during the delay time, maintaining the second gain; When the delay time reaches, if the absolute value of the current actual speed is less than (level), the speed integration time constant is fixed at the second integration time constant, and the rest are returned to the first gain. If the absolute value of the actual speed is less than (level-hysteresis), all are returned to the first gain.

2002-0C	Parameter name	Setting method	Effective time	Default	Range	Application category	Unit
_00_00	Gain switching delay time	Operation setting	Effective immediately	20	0 to 10000	Gain control	0.1ms


When the second gain is set to switch back to the first gain, the time switching condition needs to last.



 $\label{eq:Note:This parameter}$ is valid only when the second gain is switched back to the first gain.

	Parameter name	Setting method	Effective time	Default	Range	Application category	Unit
2002-0D	Gain switching level	Operation setting	Effective immediately	50	0 to 20000	Gain control	According to the switching condition

Set the level of the gain condition. The actual switching action is affected by two conditions: level and hysteresis.



	Parameter name	Setting method	Effective time	Default	Range	Application category	Unit
2002-0E	Gain switching hysteresis	Operation setting	Effective immediately	20	0 to 20000	Gain control	According to the switching condition
Set the hyste	eresis that satisfies the gai	n switching con	dition.		,		
	/				P02-15	gain switch hysteresis	
	P02-14 gain switch level				P02-15	i gain switch hysteresis	


2002-10	Parameter name	Setting method	Effective time	Default	Range	Application category	Unit
	Position gain switching time	Operation setting	Effective immediately	30	0 to 10000	Gain control	0.1ms

Second gain

First gain

First gain

The time is set at which the first position loop (P02-01) is switched to the second position loop (P02-04) in the position control mode.



9.4 Mechanical Resonance Suppression

9.4.1 Mechanical Resonance Suppression Methods

When the mechanical rigidity is low, vibration and noise may occur due to resonance caused by shaft twisting, and it may not be possible to increase the gain setting. In this case, by using a notch filter to reduce the gain at a specific frequency, the servo gain can continue to increase after the resonance is validly suppressed. There are 2 methods to suppress mechanical resonance.

(1) Torque instruction filter

By setting the filter time constant, the torque instruction is attenuated in the high frequency range above the cutoff frequency, so as to achieve the expectation of suppressing mechanical resonance. The cut-off frequency of the torque instruction filter could be calculated by the following formula:

Filter cutoff frequency
$$fc(Hz) = \frac{1}{2 \pi * \text{Set parameter value} * 0.001}$$

(2) Notch filter

The notch filter can achieve the expectation of suppressing mechanical resonance by reducing the gain at a specific frequency. When setting the notch filter correctly, the vibration can be validly suppressed. You can try to increase the servo gain. The principle of notch filter is shown in Figure 9-8.

9.4.2 Notch Filter

VD3E Ethernet servo drivehave 2 sets of notch filters, each of which has 3 parameters, namely notch frequency, width grade and depth grade.

(1) Width grade of notch filter

The notch width grade is used to express the ratio of the notch width to the center frequency of the notch:

Notch filter width grade =
$$\frac{f_H - f_L}{f_T}$$
 (9-1)

In formula (9-1), f_T It is the center frequency of notch filter, that is, the mechanical resonance frequency; $f_H - f_L$ is the width of notch filter, which represents the frequency bandwidth with an amplitude attenuation rate of -3dB relative to the center frequency of notch filter.

(2) Depth grade of notch filter

The depth grade of notch filter represents the ratio relationship between input and output at center frequency.

When the depth level of notch filter is 0, the input is completely suppressed at the center frequency; When the notch filter depth level is 100, the input is completely passable at the center frequency. Therefore, the smaller the the notch filter depth grade is set, the deeper the the notch filter depth will be, and the stronger the suppression of mechanical resonance can achieve, but it may lead to system instability, so attention should be paid when using it. Specific relationships are shown in Figure 9-9.




Figure 9-8 Notch characteristics, notch width and notch depth




Figure 9-9 Frequency characteristics of notch filter

Table 9-11 Details of notch filter function code parameters

Index	Name	Setting	Valid	Default	Dance	Definition	Unit
code	Name	method	time	Delault	Range	Definition	Unit

Chapter 9 Adjustments

			•				
2004-05	1st notch filter frequency	Operation Setting	Valid immediately	300	250~5000	Set the center frequency of the 1st notch filter. When the set value is 5000, the function of the notch filter is invalid.	Hz
2004-06	1st notch filter depth	Operation Setting	Valid immediately	100	0~100	0: all truncated 100: All passed	-
2004-07	1st notch filter width	Operation Setting	Valid immediately	4	0~12	0: 0.5 times the bandwidth 4: 1 time the bandwidth 8: 2 times the bandwidth 12: 4 times the bandwidth	-
2004-08	2nd notch filter frequency	Operation Setting	Valid immediately	500	250~5000	Set the center frequency of the 2nd notch filter. When the set value is 5000, the function of the notch filter is invalid.	Hz
2004-09	2nd notch filter depth	Operation Setting	Valid immediately	100	0~100	0: All truncated 100: All passed	-
2004-0A	2nd notch filter width	Operation Setting	Valid immediately	4	0~12	0: 0.5 times the bandwidth 4: 1 time the bandwidth 8: 2 times the bandwidth 12: 4 times the bandwidth	-

Chapter 10 Malfunctions

10.1 Faults and Warnings Handling at Startup

Boot process	Fault phenomenon	Reason	Confirmation method
	① Digital tube is not bright	① The power terminal is disconnected	☆Rewiring
Power supply (L1,	② Not display "ry"	② Servo drive failure	☆ Contact technician for repair
	Panel display "Er.xx"	Refer to"10.2 Faults and warnings h find the cause and t	• • •
	After trou	bleshooting, the servo drive panel shou	ıld display"ry"

10.2 Faults and Warnings Handling During Operation

10.2.1 Overview

The faults and warnings of Wecon VD3E series servo drives are graded according to their severity, which can be divided into four grades: Category 1, Category 2, Category 3, Category 4.

Severity level: Category 1> Category 2> Category 3 > Category 4. The specific types are as follows:

Category 2: non-clearable faults;

Category 2: clearable faults;

Category 3: clearable faults;

Category 4: clearable warning.

Among them, "clearable" means that the panel stops the fault display state by giving a "clear signal". The specific operations are as follows:

- ① Set the parameters 200A-03=1 (fault clearing) or use DI function 02 (02-A-CLR, fault and warning clearing) and set it to logic valid, which can stop the fault display on the panel.
- 2 The clearing method of category 2 and category 3 clearable faults: first turn off the servo enable signal (set S-ON to OFF), then set P10-03=1 or use DI function 2.
- 3 The clearing method of category 4 of clearable warnings: set 200A-03=1 or use DI function

2.



For some faults and warnings, please change the settings to eliminate the causes before they can be cleared, but clearing does not mean that the changes take effect. For the changes that need the device to be re-powered to take effect, the device must be re-powered; for the changes that need to stop the device to take effect, the servo must be disabled. After the changes take effect, the servo drive is running normally.

Associated function code:

Function code	Name	Setting method	Valid time	Default	Range	Definition
200A-03=1	Fault clearing	Operation Setting	Valid immediately	0	0 to 1	1: For clearable faults, after the cause of fault is removed, and write 1 to the function code, the drive will stop the fault display and enter the Rdy (or RUN) state again. Note: If the servo S-ON is valid, when the fault is removed and cleared, the servo will directly enter the Run state. When performing fault clearing actions, be sure to stop sending control instructions such as pulses to ensure personal safety.

Associated function number:

Number	Name	Function name	Function
2	A-CLR	Fault and warning clear	Invalid, does not reset faults and warnings
	-		valid, reset faults and warnings

Wecon VD3E series bus servo drives have a fault recording function, which could record the latest 5 faults and the latest 5 warning names and the status parameters of servo drive when the fault or warning occurs. After the fault or warning is cleared, the fault record will still save the fault and warning.

The current fault code could be viewed through the monitoring parameter U1-01, and the current warning code could be viewed through U1-02. The monitoring U1-16 to U1-25 could display the latest 5 fault codes and warning codes. Please refer to "201Fh Group: warning monitoring".

10.2.2 Fault and Warning Code Table

Category	Fault/warning name	Fault code	Can it be cleared
Category 1	Parameter damage	Er.01	No
Category 1	Parameter storage error	Er.02	No
Category 1	ADC reference source error	Er.03	No
Category 1	AD current sampling conversion error	Er.04	No
Category 1	Abnormal FPGA communication	Er.05	No
Category 1	Wrong FPGA program version	Er.06	No
Category 1	Clock abnormal	Er.07	No
Category 1	ADC conversion undone	Er.60	No
Category 1	Internal software fault	Er.61	No
Category 1	Internal software fault	Er.62	No
Category 1	Internal software fault	Er.63	No
Category 1	Internal software fault	Er.64	No
Category 1	Internal software fault	Er.65	No
Category 1	Wrong motor model	Er.26	No
Category 1	Encoder Z pulse lost	Er.28	No
Category 1	Encoder UVW signal error	Er.30	No
Category 1	Exceeding motor maximum speed	Er.32	No
Category 1	Overcurrent	Er.20	No
Category 1	The braking resistor is turned on abnormally	Er.24	No
Category 1	Encoder disconnected	Er.27	Yes
Category 2	Main power supply overvoltage	Er.22	Yes
Category 2	Power line disconnected	Er.31	Yes

Chapter 10 Malfunctions

	Chapter 10 Manufictions		
Category 2	Abnormal Internet status switching	Er.09	Yes
Category 2	Synchronization loss	Er.10	Yes
Category 2	Unburned XML configuration file	Er.11	Yes
Category 2	Network initialization failed	Er.12	Yes
Category 2	Synchronization period setting error	Er.13	Yes
Category 2	Synchronization period error is too large	Er.14	Yes
Category 3	Main power supply is undervoltage	Er.21	Yes
Category 3	Braking resistor is not connected	Er.23	Yes
Category 3	The resistance of the brake resistor is excessive.	Er.25	Yes
Category 3	Power module is over temperature	Er.33	Yes
Category 3	Motor overload protection	Er.34	Yes
Category 3	Electronic gear ratio exceeds limit	Er.35	Yes
Category 3	Excessive position deviation	Er.36	Yes
Category 3	Abnormal torque saturation	Er.37	Yes
Category 3	Main circuit electrical phase loss	Er.38	Yes
Category 3	Emergency stop	Er.39	Yes
Category 3	Encoder battery failure	Er.40	Yes
Category 3	Motor (encoder) over temperature	Er.41	Yes
Category 3	Encoder write failure	Er.42	Yes
Category 3	Homing timeout fault	Er.44	Yes
Category 3	Drive stall over temperature	Er.45	Yes
Category 4	Over speed alarm	A-81	Yes
Category 4	Overload	A-82	Yes
Category 4	Braking resistor is over temperature or overload	A-83	Yes
Category 4	Parameter modification that needs to be powered on	A-84	Yes
L	1		

Chapter 10 Malfunctions

	again		
Category 4	Main circuit instantaneous power failure	A-88	Yes
Category 4	Duplicate DI port configuration	A-89	Yes
Category 4	Duplicate DO port configuration	A-90	Yes
Category 4	Frequent parameter modification	A-91	Yes
Category 4 Encoder battery voltage low warning		A-92	Yes
Category 4	Frequent encoder read-write verification exception	A-93	Yes

10.2.3 Troubleshooting

Er.01 Parameter damage

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.II	Parameter damage

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
EEPROM could not be read and written	Restore factory setting [200A-02=1] and power on again. If the servo drive still alarms after multiple operations, it is faulty.	■ Contact the manufacturer's technician personnel for maintenance.

Er.02 Parameter storage error

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.IZ	Parameter storage error

Reason: The total number of function codes or content transmission changes. It usually occurs after firmware upgrade.

Reason	Troubleshooting methods	Handling
Firmware upgraded	Check whether the program has been upgraded.	■Repower the servo drive.
Parameter read and write	After a parameter is changed, power it on again and check whether the parameter is saved	■If the parameters are not saved and the problem persists after multiple power-on, contact the manufacturer's technical personnel for repair.
exceptions	• Restore factory setting [200A-02=1] and power on again. If the servo drive still alarms after multiple operations, it is faulty.	■ Contact the manufacturer's technician personnel for maintenance.

Er.03 ADC reference source error

(1) Fault phenomenon

Servo drive panel display	Fault name
	ADC reference source error

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
The internal analog reference source of the drive is not accurate	Restore factory setting [200A-02=1] and power on again. If the servo drive still alarms after multiple operations, it is faulty.	■If servo still have alarm after powering on several times, contact the manufacturer's technicians for maintenance.

Er.04 AD current sampling conversion error

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.IH	AD current sampling conversion error

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Current sampling timeout	Restore factory setting [200A-02=1] and power on again. If the servo drive still	■If servo still have alarm after powering on several times, contact the
Current sensor error	alarms after multiple operations, it is faulty.	manufacturer's technicians for maintenance.

Er.05 Abnormal FPGA communication

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.IS	Abnormal FPGA communication

Reason		Troubleshooting methods	Handling
Abnormal	FPGA	Restore factory setting [200A-02=1] and	■If servo still have alarm after powering
communication		power on again. If the servo drive still	on several times, contact the
		alarms after multiple operations, it is	manufacturer's technicians for

faulty.	maintenance.

Er.06 Wrong FPGA program version

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.IB	Wrong FPGA program version

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
The FPGA program version does not match firmware version	 Check whether the servo drive monitoring quantities 2020-04 (firmware version) and 2020-05 (hardware version) conform to the corresponding relationship. 	■ Contact the manufacturer's technician to upgrade FPGA (hardware version).
Servo drive fault	Restore factory setting [200A-02=1] and power on again. If the servo drive still alarms after multiple operations, it is faulty.	If servo still have alarm after powering on several times, contact the manufacturer's technicians for maintenance.

Er.07 Clock abnormality

(1) Fault phenomenon

Servo drive panel display	Fault name
	Clock abnormality

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
External interference	Check whether there are strong magnetic fields nearby	■ Eliminate the interference of strong magnetic field nearby.
	Check whether there are sources of interference such as power supply inverter equipment nearby	■ Try to separate the strong and weak currents in the wiring, ensure that the motor and the servo drive are well grounded, and keep away from the power cables.
Servo drive fault	• Restore factory setting [200A-02=1] and power on again. If the servo drive still alarms after multiple operations, it is faulty.	■If servo still have alarm after powering on several times, contact the manufacturer's technicians for maintenance.

Er.09 Abnormal network status switching

(1) Fault phenomenon

Servo drive panel display	Fault name
	Abnormal network status switching

(2) Troubleshooting methods

Reaso	n	Troubleshooting methods	Handling
Master station error	operation	• Check whether the master station switches the network status when the servo drive is enabled.	■ Correct the upper computer network switching program.
Communication connection error	cable	Check whether the communication cable is properly connected.	■ Correctly connect the communication cable.

Er.10 Loss of synchronization

(1) Fault phenomenon

Servo drive panel display	Fault name
Er. II	Loss of synchronization

Reason	Troubleshooting methods	Handling
	 Check whether the servo drive network port is damaged. (Displayed by the first digital tube from the left of the servo drive panel) 	■ If damaged, contact the manufacturer's technician for repair.
Communication is disturbed	Check whether the communication cable is damaged.	■ If damaged, replace a reliable communication cable, it is recommended to use twisted-pair shielded cable with shielding function.
	• Check whether the servo drive is well grounded.	■The servo drive is well grounded.
Communication wiring error	Check whether the communication connection follows the sequence of CN5 port in and CN6 port out to connect each slave station.	■ Correctly connect the communication cable.
Master station configuration error	• Cross-verification, using normal PLC for comparative test.	■ If it is determined that the configuration of the master station is wrong, correct the relevant procedures of the master station configuration.

The upper computer is shut down or stuck	• Check whether the upper computer is shut down or stuck.	■Restart the upper computer.
Upper computer synchronization clock is not in effect	Measure the synchronization period by oscilloscope.	■ If the synchronization period is 0, first check whether the communication cable connection mode is correct, and then restart the network. ■ If the synchronization period is not 0, contact the manufacturer's technician.
Servo drive fault	• None of the above methods can solve the fault.	■ If damaged, contact the manufacturer's technician for repair.

Er.11 Unburned XML configuration file

(1) Fault phenomenon

Servo drive panel display	Fault name
	Unburned XML configuration file

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Unburned device configuration file (XML file)	 After the upper computer scans the slave station, check whether the slave station ID is empty. 	Contact the manufacturer's technician to burn the device file.
Servo drive fault	• After burning the configuration file, the fault still not be solved.	■ Contact the manufacturer's technician personnel for maintenance.

Er.12 Network initialization failed

(1) Fault phenomenon

Servo drive panel display	Fault name
Er. IZ	Network initialization failed

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Unburned device configuration file (XML file)	• After the upper computer scans the slave station, check whether the slave station ID is empty.	Contact the manufacturer's technician to burn the device file.
Servo drive fault	• After burning the configuration file, the fault still not be solved.	■Contact the manufacturer's technician personnel for maintenance.

Er.13 Synchronization period setting error

(1) Fault phenomenon

Servo drive panel display		Fault name
	Er. 13	Synchronization period setting error

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
The synchronization period is not an integer multiple of 125us or 250us	Check the setting value of synchronization period.	■ Modify the synchronization period to an integer multiple of 125us or 250us.

Er.14 Synchronization period error is too large

(1) Fault phenomenon

Servo drive panel display	Fault name
Er. 14	Synchronization period error is too large

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Device profile mismatch	Check whether this fault occurs every time, the device profile does not match.	■ Contact the manufacturer technician to update the device configuration file (XML file) inside the servo drive to the latest version.
The synchronization period error of the controller is large	Check whether this fault is accidental.	■Check the upper computer.

Er.19 Software Overcurrent

(1) Phenomenon

Servo drive panel display	Fault name
Er. 13	Software overcurrent

Cause	Troubleshooting	Treatment
UVW phase sequence of motor power cable is incorrect.	•Check whether the phase sequence of the motor power cable on the servo driver side and motor side corresponds to each other.	Connect correctly as per driver side and motor side UVW.
Motor power lines are	•Check whether power line UVW is	Replace the power cable.

short-circuited.	short-circuited to PE	
The motor power line wiring port is poorly contacted.	Check whether the motor power line connection port is connected reliably	Tighten the fixing screw on the wiring port of the motor power wire.
	Wrong wiring using internal brake resistor: Check whether the short connection cap is connected between C and D and whether the contact is normal.	Reliable connect short cap or short wiring between C and D.
	•External braking resistor wiring error: Check whether the external resistor is connected reliably between P+ and C.	The external braking resistor is reliably connected in series between P+ and C.
Braking resistor abnormal	Built-in brake resistor short circuit: Check the built-in brake resistor for short circuit.	Remove the short-circuit cap between C and D, and reliably connect the external braking resistor of equal resistance between P+ and C. Contact the manufacturer to replace the internal brake resistor.
	The resistance of external braking resistor is too small: Test the resistance value of the actually selected external braking resistor, compare it with the recommended braking resistor, and confirm whether the resistance value of the actually selected resistor is too small.	Select the appropriate external brake resistor.
	Check whether the encoder cable port (CN1) connection is reliable.	Tighten the fixing screw for CN1 port.
Encoder wiring error; loose plug	Check whether the servo driveCN1 port jack is deformed.	If deformed, replace the cable or cable port.
	Check whether both ends of the rectangular connector are reliably connected	Ensure that both ends of the rectangular connection port are reliably connected; Replace it with an encoder cable with higher connection reliability.
Improper parameter setting	• Inspect 2003-01load inertia ratio and whether the setting of 2003-02 (load rigidity level) is reasonable.	Set 2003-01 (Load Inertia Ratio) to a reasonable value and adjust 2003-02 (Load Rigidity Rating) settings appropriately.
	Check whether the gain parameters are set properly	Reasonably adjust the gain parameters.
Frequent acceleration and deceleration	Check overload characteristics of motor or servo drive	Appropriately extend the acceleration and deceleration time.
Internal servo drive fault	•Cross-verification. Use the normal motor, encoder cable to connect to the servo drive, only connect the encoder cable. If the servo drive still alarm, it is	Contact the technicians for maintenance.

tailure	
lallule.	

Er.20 Overcurrent

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.ZI	Overcurrent

Reason	Troubleshooting methods	Handling
Motor power cable UVW phase sequence is wrong	 Check whether the phase sequence of the motor power cable on the servo drive side and motor side corresponds to each other. 	■According to the drive side UVW, connect the motor side UVW correctly.
Motor power line short circuit	Check whether power line UVW is short-circuited to PE	■Replace the power cable.
Poor connection of motor power line terminal	•Check whether the motor power line connection port is connected reliably	■ Tighten the fixing screws at the connection port of the motor power wire.
	 Internal brake resistance wiring error: check whether C, D are connected to the shorting cap and the contact is normal 	■Ensure reliable connection between C and D shorting cap or short wiring.
Abnormal braking resistance	• External braking resistor wiring error: Check whether the external resistor is connected reliably between P+ and C.	■ The external braking resistor is reliably connecting between P + and C.
	Short-circuit of the built-in brake resistance: Check whether the built-in brake resistance is short-circuited.	■ Remove the shorting cap between C and D, and connect the external braking resistors with equal resistance between P + and C. ■ Contact the manufacturer's technician to replace the internal braking resistor.
	• The resistance value of the external braking resistor is too small: Test the resistance value of the external braking resistor actually selected and compare it with the recommended braking resistor to confirm whether the resistance value of the actual resistor is too small	■ Select the appropriate external braking resistor.

	• Check whether the cable port (CN2) of the encoder is properly connected	■Tighten the fixing screws for CN2 port.
Encoder wiring error; loose	Check whether the servo drive CN2 port jack is deformed	■ Replace the cable or cable port if deformed.
plug	Check whether both ends of the rectangular connector are reliably connected	rectangular connection port,
Improper parameter setting	•Check whether 2003-02 (load rigidity level) is set properly	■ Appropriately increase the setting value of 2003-02 (load rigidity level).
	• Check whether the gain parameters are set properly, resulting in overshoot	■Reasonably adjust the gain parameters.
Frequent acceleration and deceleration	Check whether frequent acceleration and deceleration are performed and whether the acceleration and deceleration time is too short.	■Appropriately extend the acceleration and deceleration time.
Internal servo drive fault	• Cross-verification. Use the normal motor, encoder cable to connect to the servo drive, only connect the encoder cable. If the servo drive still alarm, it is failure.	■ Contact the manufacturer's technician personnel for maintenance.

Er.21 Main power supply undervoltage

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.Z I	Main power supply is undervoltage

Reason: DC bus voltage is lower than the fault value.

O220V drive: The normal value of DC bus voltage is 310V, and the fault value of DC bus voltage is 200V;

O380V drive: The normal value of DC bus voltage is 540V, and the fault value of DC bus voltage is 420V.

Reason	Troubleshooting methods	Handling
Power-off when VD3E drive is enabled	•Check whether the servo drive is power off when logic is valid and the S-ON function is enabled in the 2006 Group "DIDO Function configuration	■ It is servo internal software logic, and the alarm will be automatically released after the indicator light of servo drive

	parameter".	panel is off.
The power supply is unstable or off	 Observe whether the monitoring quantity 201E-1f (bus voltage) is in the following range: 220V drive: 201E-1F less than 200V; 380V drive: 201E-1F less than 420V. 	■ Run servo after the power supply is stable; ■Increase power capacity.
The voltage drops during operation of the servo drive	• Check whether the servo drive shares the same power supply with other high loads	■ Turn off other loads of the same main circuit power supply; ■ Servo drive uses a separate power supply
Phase loss (three phase power is running on single phase power)	●Check if the main circuit wiring is correct VD3E A: single-phase 220V input connected to L1, L3; VD3E B: single-phase 220V input connected to L1, L3; three-phase 220V input connected to L1, L2, L3.	■ Correctly connect the main circuit wiring.

Er.22 Main power supply overvoltage

(1) Fault phenomenon

Servo drive panel display	Fault name
	Main power supply is overvoltage

Reason: DC bus voltage is higher than the fault value.

O220V drive: The normal value of DC bus voltage is 310V, and the fault value of DC bus voltage is 390V;

O380V drive: The normal value of DC bus voltage is 540V, and the fault value of DC bus voltage is 670V.

Reason	Troubleshooting methods	Handling
The input voltage is too high	 Check that the drive input power specifications meet the specifications: 220V drive: valid value: 198V ~ 242V; 380V drive: valid values: 342V ~ 418V. 	■Change or adjust the power supply.

The power supply is not stable or struck by lightning	•Check whether the input power supply of the servo drive meets the specifications and monitor whether it has been struck by lightning.	 Run servo after the power supply is stable; Connect the surge suppressor, please contact the technical personnel of the manufacturer for the specific connection method.
	• Internal briking resistor wiring error: check whether C, D are connected to the shorting cap and the connection is normal	■ Reliable connection between C and D shorting cap or short wiring.
	• External braking resistor wiring error: Check whether the external resistor is connected reliably between P+ and C.	■ The external braking resistor is reliably connected between P + and C.
Abnormal braking resistance	• Short-circuit of the built-in braking resistor: Check whether the built-in braking resistor suffers from short-circuit.	■Remove the shorting cap between C and D, and reliably connect the external braking resistors with equal resistance between P + and C. ■ Contact the manufacturer's technician to replace the internal braking resistor.
	• The resistance value of the external braking resistor is too large: Check the resistance value of the external braking resistor actually selected and compare it with the recommended braking resistor to confirm whether the resistance value of the actual resistor is too large.	■ Select the appropriate external braking resistor.
The motor is in a state of rapid acceleration and deceleration motion	Monitor the servo drive monitoring quantity 201E-1F (bus voltage) to confirm whether the voltage exceeds the fault value when the motor is in the deceleration section.	■ Ensure that the input voltage is within the specification range and increase the acceleration and deceleration time.
Internal servo drive fault	The servo drive is still faulty after power on again	Servo drive may be damaged, contact the manufacturer's technician for repair.

Er.23 Braking resistor is not connected

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.Z]	Braking resistor is not connected

Reason	Troubleshooting methods	Handling

Internal braking resisto wiring error	Check whether C, D are connected to the shorting cap and the connection is normal	■ When internal braking resistors are used, ensure the shorting caps or short wires are reliably connected between C and D.
External braking resisto wiring error	• Check whether the external resistor is connected reliably between P+ and C.	■ When external braking resistors are used, ensure the external resistors are reliably strung between P + and C.
Internal braking resisto damaged	•The servo drive is powered off. Detect whether the resistance between P+ and D is 50Ω	■ Contact the manufacturer's technician to replace the internal braking resistor. ■ Use the external braking resistor and change the relevant parameters in servo drive 2000 group "basic settings".

Er.24 Braking resistor turns on abnormally

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.ZH	The braking resistor is turned on abnormally

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Internal hardware of servo drive damaged	• The servo drive is still faulty after power on again	■ Contact the manufacturer's technician for maintenance.

Er.25 Braking resistor resistance is too large

(1) Fault phenomenon

Servo drive panel display	Fault name
	Braking resitor resistance is too large

Reason	Troubleshooting methods	Handling
The resistance value of the external braking resistor is large	• Check the resistance value of the external braking resistor actually selected and compare it with the recommended braking resistor to confirm whether the resistance value of the actual resistor is too large.	■ Use an appropriate external braking resistor.
Improper parameter setting	● Check whether the value of servo drive 2000-0A (external brake resistance) is set too high	■ Reasonably set the parameter value of 2000-0A (external braking resistance value).

Er.26 Wrong motor model

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.Z6	Wrong motor model

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
The motor is not supported by the servo drive	Check whether the servo drive model supports the motor	■ Contact the manufacturer's technician to obtain the appropriate servo drive model and motor model.
Wrong motor model	Check whether the Motor Code is consistent with the motor nameplate	■ Contact technician to record the motor Motor Code

Er.27 Encoder disconnection

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.Z7	Encoder is disconnected

Reason	Troubleshooting methods	Handling
Poor contact on CN2 port	• Check whether the cable port (CN2) of the encoder is properly connected	■Tighten the fixing screws for CN2 port.
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	Check whether the servo drive CN2 port jack is deformed	■ Replace the cable or cable port if deformed.
Poor contact on adapter port (Rectangular connection cable)	Check whether both ends of the rectangular connector are reliably connected	■ Ensure reliable connection at both ends of rectangular connection port; ■ Replace with an encoder cable with higher connection reliability.
Wrong encoder cable wiring	Check whether the both ends of the encoder cable are correctly connected	 Adjust the wiring according to the corresponding relationship of pins; Preferably use the standard encoder cable of the manufacturer.

Er.28 Encoder Z pulse lost

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.ZB	Encoder Z pulse is lost

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Wrong motor model	Check whether the servo drive model supports the motor	■ Contact the manufacturer's technician to obtain the appropriate servo drive model and motor model.
	• Check whether there are strong magnetic fields nearby	■ Eliminate the interference of strong magnetic field nearby.
External interference	Check whether there are sources of interference such as power supply inverter equipment nearby	■ Try to separate the strong and weak currents in the wiring, ensure that the motor and the servo drive are well grounded, and keep away from the power cables.
Encoder fault	 Manually rotate the motor shaft counterclockwise or clockwise to observe whether the monitoring quantity U0-30 (electrical angle) changes regularly 	■ If the value of U0-30 (electric angle) changes abruptly or does not change, there may be a problem with the encoder itself. Please replace the motor or encoder.

Er.30 Encoder UVW signal error

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.30	Encoder UVW signal error

Reason	Troubleshooting methods	Handling
External interference	Check that the motor and servo drive are well grounded	■Ensure the motor and servo drive are well grounded.
Encoder cable fault	• Cross-verification. Use the normal motor, encoder cable to connect to the servo drive.	■Replace with an encoder cable with higher connection reliability.
Servo drive fault	• The servo drive is still faulty after power on again	■ Contact the manufacturer's technician for maintenance.

Er.31 Power line disconnection

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.J i	Power line disconnection

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Poor contact of motor power wiring port	Check whether the motor power wiring port is connected reliably	■ Tighten the fixing screws at the wiring port of the motor power wire.
Power line disconnection	•Check whether both ends of the power cable are disconnected	■Replace the power cable and repower
Poor contact on adapter port (rectangular connection cable)	Check whether both ends of the rectangular connector are reliably connected	■ Ensure reliable connection at both ends of rectangular connection port; ■ Replace with a power cable with higher connection reliability.

Er.32 Exceeding motor maximum speed

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.JZ	Exceeding motor maximum speed

Reason	Troubleshooting methods	Handling
Motor power cable UVW phase sequence error	• Check whether the phase sequence of the motor power cable on the servo drive side and motor side corresponds to each other.	■ According to the drive side UVW, the motor side UVW is connected correctly.
2001-0A parameter setting is not proper	 Check that the parameter value of 2001-0A (maximum speed threshold) is less than the maximum speed required for the actual operation of the motor Check whether the motor rotating 	Reset 2001-0A (maximum speed threshold) according to mechanical requirements.
	speed corresponding to the input command exceeds 2001-0A (maximum speed threshold)	
Motor speed overshoot	Check whether the gain parameters	■Reasonably adjust the gain parameters.

	are set properly, resulting in overshoot	
Servo drive fault	• The servo drive is still faulty after power on again	■ Servo drive may be damaged, replace servo drive.

Er.33 Power module over temperature

(1) Fault phenomenon

Servo drive panel display	Fault name
	Power module is over temperature

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Ambient temperature is too high	Measure the ambient temperature.	■Reduce the ambient temperature of the servo drive.
Servo drive fan failure	• Check whether the servo drive fan is blocked or damaged	■ Contact the manufacturer's technician to repair or replace the fan.
The servo drive is mounted in an unreasonable orientation or the spacing between the servo drives is unreasonable	Check whether the servo drive installation is reasonable	■ Contact the manufacturer's technician to obtain the servo drive installation standard.
Servo drive fault	• Fault is still reported when restarting after ten minutes of power cutoff	■ Servo drive may be damaged, contact the manufacturer's technician for repair.

Er.34 Motor overload protection

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.JH	Motor overload protection

Reason	Troubleshooting methods	Handling
Motor power cable, encoder cable wiring error	Check whether the motor power cable and encoder cable wiring are correct.	■ Connect according to the correct connection method; ■ Preferably use the motor power lines and encoder cables standard by manufacturers.
The load is too large	Check overload characteristics of motor or servo drive	■Reduce the load; ■ Contact the manufacturer's technician

		to obtain the drive and motor model with appropriate capacity.
Frequent acceleration and deceleration	Check whether frequent acceleration and deceleration are performed and whether the acceleration and deceleration time is too short.	■ Appropriately extend the acceleration and deceleration time.
Motor model and servo drive do not match	• Check the monitoring quantity 201E-35 (motor model code).	■ Contact the manufacturer's technician to obtain the matching motor model.
	Use Wecon SCTools to obtain the actual torque waveform and observe whether overshoot is obvious	■ Set the appropriate loop gain parameters.
Unreasonable parameters	Observe whether the motor vibrates during operation	■Set the appropriate rigidity level.
	Check whether 200A-04 (motor overload protection time coefficient) parameter is reasonable	■ Increase 200A-04 (motor overload protection time coefficient) under the premise that the motor will not burn out.
The motor is locked	• Check whether the brake output function is enabled by mistake, resulting in the motor locking.	■Disable the brake output function.
Servo drive fault	The servo drive is still faulty after power on again	■ Servo drive may be damaged, contact the manufacturer's technician for repair.

Er.35 Electronic gear ratio exceeds limit

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.35	Electronic gear ratio exceeds limit

$\hbox{(2) Trouble shooting methods}\\$

Reason	Troubleshooting methods	Handling
The electronic gear ratio setting is greater than the settable range	Check whether the ratio of object dictionaries 6091: 01 to 6091: 02 is within the following range: • The upper limit of 17bit absolute value encoder can be set to 52428; • The upper limit of 23bit absolute value encoder can be set to 3355443.	■ After modifying the corresponding function code according to the settable range, set 200A-03 (fault clearing) to 1
The electronic gear ratio setting is less than the settable range	Check whether the ratio of object dictionaries 6091: 01 to 6091: 02 is within the following range: • The lower limit of 17bit absolute	

 value encoder can be set to 0.01;	
• The lower limit of 23bit absolute value encoder can be set to 0.83.	

Er.36 Position deviation is too large

(1) Fault phenomenon

Servo drive panel display	Fault name
	Position deviation is too large

Reason	Troubleshooting methods	Handling
Cable problem	• Check whether the phase sequence of the motor power cable on the servo drive side and motor side corresponds to each other.	■ According to the drive side UVW, connect the motor side UVW correctly.
	Check whether both ends of power cable are disconnected	■Replace the power cable and repower
	• Check whether 2003-02 (load rigidity level) is set properly	■Appropriately increase the setting value of 2003-02 (load rigidity level).
Improper parameter setting	• Check whether the gain parameters are set properly; if not, it may result in overshoot	■Reasonably adjust the gain parameters.
	Check whether 6065 (position deviation threshold) is set properly	■Appropriately increase the setting value of 6065 (excessive position deviation threshold)
	• Use Wecon SCTools to obtain the equivalent speed of the position command and check whether the speed is greater than the motor rotating speed limit	■ Increase the setting values of 2001-0C (forward speed threshold) and 2001-0D (reverse speed threshold) according to mechanical requirements.
Motor is locked	Check whether motor is locked due to mechanical jamming	■ Solve the problem of mechanicam jamming.
Brake is not opened	• Check whether the brake device is opened normally, and check whether the output voltage of the brake is 24V	■ Check the logic of brake power supply or brake output signal.
Position command equivalent speed changes too quickly	Check whether the position command equivalent speed changes too quickly	■ Properly increase the acceleration and deceleration time and reduce the change rate of the rotating speed.

Er.37 Abnormal torque saturation

(1) Fault phenomenon

Servo drive panel display	Fault name
	Abnormal torque saturation

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Motor power cable UVW phase sequence error	• Check whether the phase sequence of the motor power cable on the servo drive side and motor side corresponds to each other.	■ According to the drive side UVW, connect the motor side UVW correctly.
	Check whether 2001-13 (torque saturation timeout) is set properly	■Appropriately increase the setting value of 2001-13 (torque saturation timeout time).
Improper parameter setting	Check whether 2001-0F (forward torque limit) and 2001-10 (reverse torque limit) are set reasonably	■ Appropriately increase the setting values of 2001-0F (positive torque limit) and 2001-10 (reverse torque limit).
	Check whether the gain parameters are set properly	■Reasonably adjust the gain parameters.
	Check whether the acceleration and deceleration time are set properly	■Appropriately increase the acceleration and deceleration time.
The load is too large	Check whether the load is too large	■Reduce the load.
Motor is locked	• Check whether the motor is locked due to mechanical jamming of the load.	■ Solve the problem of mechanical jamming.
Limit switches are mounted beyond the travel	Check whether the limit switch is installed beyond the travel	■ Adjust the installation position of the limit switch.
The brake is not opened	• Check whether the brake device is opened normally, and check whether the output voltage of the brake is 24V	■ Check the logic of brake power supply or brake output signal.

Er.38 Main circuit electrical phase loss

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.JA	Main circuit electrical phase loss

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Cable problem	Check whether the motor power wiring port is connected reliably	■Tighten the fixing screws at the wiring port of the motor power wire.
·	Check whether both ends of the power cable are disconnected	■Replace the power cable and repower
Three-phase specification drives run on single-phase power supplies	Check whether the three-phase drive has a single-phase power supply	■ Re-connect the three-phase power supply according to the power supply specifications.
The power supply is unstable or off	 Check that the drive input power specifications meet the specifications: 220V drive: valid value: 198V ~ 242V; 380V drive: valid value: 342V ~ 418V. 	■Run servo after the power supply is stable.
Servo drive fault	• The servo drive is still faulty after power on again	■ Servo drive may be damaged, contact the manufacturer's technician for repair.

Er.39 Emergency stop

(1) Fault phenomenon

Servo drive panel display	Fault name
	Emergency stop

Reason	Troubleshooting methods	Handling
	Check whether emergency stop protection is triggered manually	■Repower the servo drive.
Servo drive receives emergency stop instructions	 Check whether the servo drive has mistakenly triggered the emergency stop signal. Check whether function 08 (E-STOP) is configured in "DI "port function selection" of the 2006 group "DIDO configuration" function code group and whether the DI port wiring is normal. 	■Reasonably wire the DI port.

Er.40 Encoder battery failure

(1) Fault phenomenon

Servo drive panel display	Fault name
	Encoder battery failure

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Multi-turn absolute encoder is not connected to the battery when the servo drive is power off	Check if the encoder is connected to the battery during the power off of the servo	■Set 200A-03 (fault clearing) to 1.
The voltage of multi-turn absolute encoder battery is low	Measure battery voltage	■ Contact the manufacturer's technician to replace the new encoder battery.

Er.41 Motor (encoder) over temperature

(1) Fault phenomenon

Servo drive panel display	Fault name
Er. Hi	Motor (encoder) over temperature

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
The motor is overloaded	• Check whether the motor is overloaded	■Reduce the load.

Er.42 Encoder write fault

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.42	Encoder write fault

Reason	Troubleshooting methods	Handling
Poor contact on CN1 port	• Check whether the cable port (CN1)	■Tighten the fixing screws for CN2 port.

	of the encoder is properly connected	
	Check whether the servo drive CN1 port jack is deformed	■ Replace the cable or cable port if deformed.
Poor contact on adapter port (rectangular connection cable)	Check whether both ends of the rectangular connector are reliably connected	■ Ensure reliable connection at both ends of rectangular connection port; ■ Replace with an encoder cable with higher connection reliability.
	Check whether there are strong magnetic fields nearby	■ Eliminate the interference of strong magnetic field nearby.
External interference	Check whether there are sources of interference such as power supply inverter equipment nearby	■ Try to separate the strong and weak currents in the wiring, ensure that the motor and the servo drive are well grounded, and keep away from the power cables.
Servo drive fault	The servo drive is still faulty after power on again	■Servo drive may be damaged, contact the manufacturer's technician for repair.

Er.43 Drive overload fault

Fault

Servo drive panel	Fault name
Er.43	Drive overload fault

Troubleshooting

Reason	Troubleshooting	Handling
The average output power of U0-34 exceeds the limit power (110% overload) for more than 20 minutes.	■ Whether the average output power of U0-34 often exceeds the limit (110% overload) Check whether the drive meets the requirements.	■ It can be observed whether the U0-34 is often greater than the servo limit power (110% overload) when servo is running. When ER.43 alarm is found in the process of machine adjustment, please check whether the servo power is suitable. It is recommended to replace the drive model with higher power.
Servo drive fault	■ The servo drive is still fault after power on again	■ Servo drive may be damaged. Please contact the manufacturer's technician for repair.

Servo drive model	Rated power /W	Limited power/W (110% overload)
VD3E-003SA1G	100	110
VD3E-010SA1G	400	440
VD3E-014SA1G	750	825
VD3E-016SA1G	1500	1650
VD3E-019/021 SA1G	2300	2530
VD3E-025/030 SA1G	2600	2860
VD3E-016TA1G	1500	1650
VD3E-019TA1G	2000	2200
VD3E-021TA1G	3000	3300

Er.44 Homing timeout fault

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.HH	Homing timeout fault

Reason	Troubleshooting methods	Handling
Fault of homing switch	Check whether homing is always in a high-speed search instead of a low-speed search. Check whether homing high-speed search has been in the reverse low-speed search process.	■ First confirm whether the DI function 26 is set in group 2006, and then check the connection of the DI terminal. When manually changing the logic of the DI terminal, check whether the servo drive receives the corresponding DI level signal through 201E-11. If not, it means that the DI wiring is wrong, please wire correctly. ■ Manually make DI terminal logic change, if received level signal, indicating the homing operation is wrong, please

		operate correctly.
The speed of searching the home switch signal at high speed is too small	Check whether the 6099: 01h setting value is too small.	■Increase the 6099: 01h setting value.
Hardware switch setting is unreasonable	 Confirm whether the limit switch signals on both sides are valid at the same time. Confirm whether a limit switch signal and the deceleration point signal or origin signal are valid at the same time 	■ Set the hardware switch position reasonably.

Er.45 Drive stall and Overtemperature Protection

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.45	Drive Stall Overtemperature
	Protection

(2) Troubleshooting

Cause	Troubleshooting	Treatment
Controlled by parameter P10-11 motor stall and over-temperature function. When P10-11=0, the motor is stalled, the actual speed of the motor is less than 10rpm, the torque instruction exceeds the rated torque of the motor, and the duration reaches the motor overheating protection time at the corresponding torque, ER.45 fault will be reported and the	Check the waveform of the oscilloscope. The actual speed of the motor is less than 10rpm, and the torque instruction exceeds the rated torque of the motor. Observe whether the mechanical structure is jammed.	View oscilloscope waveforms. The actual speed of the motor is less than 10rpm, and the torque instruction exceeds the rated torque of the motor. Observe whether the motor is stuck by the mechanical structure. A temporary solution. P10-11=1 When the motor is stalled, the torque will become 70% of the rated torque. (Not recommended) Note: The shielded drive stall and over-temperature protection function is likely to cause motor and mechanical failure. Please use it carefully!

machine will be shut	
down immediately.	

Er.60 ADC conversion is not completed

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.50	ADC conversion is not completed

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
	Check whether there are strong magnetic fields nearby	■ Eliminate the interference of strong magnetic field nearby.
External interference	Check whether there are sources of interference such as power supply inverter equipment nearby	■ Try to separate the strong and weak currents in the wiring, ensure that the motor and the servo drive are well grounded, and keep away from the power cables.
Servo drive fault	• Restore factory setting [200A-02=1] and power on again. If the servo drive still alarms after multiple operations, it is faulty.	■ If servo still give alarm after powering on several times, contact the manufacturer's technicians for maintenance.

Er.61 Internal software fault

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.5 i	Internal software fault

Reason	Troubleshooting methods	Handling
Servo drive fault	• Restore factory setting [200A-02=1] and power on again. If the servo drive still alarms after multiple operations, it is faulty.	-

Er.62 Internal software fault

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.52	Internal software fault

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Servo drive fault	 Restore factory setting [200A-02=1] and power on again. If the servo drive still alarms after multiple operations, it is faulty. 	-

Er.63 Internal software fault

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.53	Internal software fault

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Servo drive fault	 Restore factory setting [200A-02=1] and power on again. If the servo drive still alarms after multiple operations, it is faulty. 	-

Er.64 Internal software fault

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.54	Internal software fault

Reason	Troubleshooting methods	Handling
Servo drive fault	• Restore factory setting [200A-02=1] and power on again. If the servo drive still alarms after multiple operations, it	-

is faulty.	maintenance.

Er.65 Internal software fault

(1) Fault phenomenon

Servo drive panel display	Fault name
Er.55	Internal software fault

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Servo drive fault	 Restore factory setting [200A-02=1] and power on again. If the servo drive still alarms after multiple operations, it is faulty. 	

A-80 power limit alarm

(1) Fault

Servo drive panel	Alarm name
	Drive overpower alarming

(2) Troubleshooting

Reason	Troubleshooting	Handling
When the average output power of U0-34 exceeds the limit power of the drive (110% overload) for more than 5 seconds, there is drive overpower alarming.	■ Check whether the average output power of U0-34 exceeds the limit (110% overload) for more than 5 seconds.	■ Check whether the power of U0-34 exceeds 110% of the rated power of the drive. When A80 alarm is reported in the adjustment process, please check whether the servo power is suitable.

A-81 Overspeed alarm

(1) Fault phenomenon

Servo drive panel display	Warning name
	Overspeed alarm

Reason	Troubleshooting methods	Handling
Motor power cable UVW phase sequence error	• Check whether the phase sequence of the motor power cable on the servo drive side and motor side corresponds to each other.	■According to the drive side UVW, connect the motor side UVW correctly.
2001-0B parameter setting is not proper	• Check whether the value of 2001-0B (warning speed threshold) is less than the max speed required for the operation of motor	■ Reset 2001-0B (warning speed threshold) according to mechanical requirements.
Input speed instruction is too high	Check whether the motor speed corresponding to the input command exceeds 2001-0B (warning speed threshold)	■ Reduce the input speed command while ensuring mechanical requirements; ■ Reasonably increase 2001-0B (warning speed threshold).

A-82 Overload

(1) Fault phenomenon

Servo drive panel display	Warning name
	Overload

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Motor power cable, encoder cable wiring error	Check whether the motor power cable and encoder cable wiring are correct.	 Complete wiring according to the correct wiring method; Preferably use the standard motor power lines and encoder cables provided by manufacturers.
The load is too large	Perform inertia identification and check the inertia ratio.	■ Reduce the load; ■ Contact the manufacturer's technician to obtain the drive and motor model with appropriate capacity.
Frequent acceleration and deceleration	Check whether frequent acceleration and deceleration are performed and whether the acceleration and deceleration time is too short.	■ Appropriately extend the acceleration and deceleration time.
Motor model and servo drive do not match	• Check the monitoring quantity 201E-35 (motor model code).	■ Contact the manufacturer's technician to obtain the matching motor model.
Unreasonable parameters	Use Wecon SCTools to obtain the actual torque waveform and observe whether overshoot is obvious	■ Set the appropriate loop gain parameters.
	Observe whether the motor vibrates during operation	■Set the appropriate rigidity level.

A-83 Braking resistor is over temperature or overloaded

(1) Fault phenomenon

Servo drive panel display	Warning name
	Braking resistor is over temperature or overloaded

Reason	Troubleshooting methods	Handling

Chapter 2

Improper wiring of internal braking resistor	Check whether C, D are connected to the shorting cap and the contact is normal	■ When internal braking resistors are used, ensure the shorting caps or short wires are reliably connected between C and D.
Improper wiring of external braking resistor	• Remove the external braking resistor and measure whether the resistance value is "∞"(Infinity).	■ Replace with a new external braking resistor, after ensuring that the resistance value of the resistor is consistent with the nominal value, connect it in series between P+ and C.
The resistance value of the external braking resistor is too large	●Test the actual external braking resistor resistance and compare it with the recommended braking resistor to make sure the actual resistance is not too large.	■ Use an appropriate external braking resistor.
Improper parameter setting	When using an external braking resistor, check the following parameters. Whether the value of 2000-09 (brake setting) is reasonable Whether the value of 2000-10 (resistance value of external braking resistor) is reasonable.	■Reasonably set the parameter value of 2000-09 (brake setting setting): 2000-09=1 (external braking resistor is used, natural cooling) 2000-09=3 (no braking resistor is used, and all are absorbed by capacitance) ■ The parameter value of 2000-0A (external braking resistor) should be the same as the actual external braking resistance.

A-84 Parameter modification that needs device to be powered on again

(1) Fault phenomenon

Servo drive panel display	Warning name
	Parameter modification that needs device to be powered on again

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
	• Check whether the servo drive has modified the valid timing parameter to "power on again".	■Power it on again.

A-88 Main circuit instantaneous power failure

(1) Fault phenomenon

Servo drive panel display	Warning name



Main circuit instantaneous power failure

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
Power failure	 Check that the drive input power specifications meet the specifications: 220V drive: valid value: 198V ~ 242V;; 380V drive: valid values: 342V ~ 418V. 	■ If the mains input has no voltage or is unstable, wait for the power supply to stabilize before use.
Servo drive fault	When the mains power is confirmed to be normal, the servo drive is still faulty after power on again	■ Servo drive may be damaged, please contact the manufacturer's technician.

A-89 Duplicate DI port configuration

(1) Fault phenomenon

Servo drive panel display	Fault name
	Duplicate DI port configuration

(2) Troubleshooting methods

Reason	Troubleshooting methods	Handling
The same non-zero DI function is assigned to multiple DI ports	Check whether the "DI port function selection" of the "DIDO Configuration" function code group of the 2006 group is configured with the same DI function	■ Set different DI functions for different DI port, and repower the servo; ■Configure the function of unnecessary DI port to 0 (off), and repower servo; ■Restore parameters to factory settings through setting 200A-02 as 1, and power it on again.

A-90 Duplicate DO port configuration

(1) Fault phenomenon

Servo drive panel display	Fault name
	Duplicate DO port configuration

Chapter 2

Reason	Troubleshooting methods	Handling
The same non-zero DO function is assigned to multiple DO ports	Check whether the "DO port function selection" of the "DIDO Configuration" function code group of the 2006 group is configured with the same DO function.	■ Set different DO functions for different DO port; ■ Configure the function of unnecessary DO port to 128 (off); ■ Restore parameters to factory settings through setting 200A-02 as 1, and power it on again.

A-91 parameter modification is too frequent.

(1) Fault

Servo drive panel	Fault name				
	Parameter modification is too frequent (Allowable modification frequency of the function code): 150 times/ 4 hours Note: 32-bit function code is recorded as 2 times)				

(2) Troubleshooting

Reason	Troubleshooting	Handling
Parameter modification is too frequent	 Check whether the host computer modifies the writing parameters frequently; (Allowable modification frequency of the function code): 150 times/ 4 hours) Note: 32-bit function code is recorded as 2 times 	 (1) During the adjustment, A91 alarming (150 times/4 hours) caused by frequently manual modification of function codes can be cleared through P10-03. In other cases, please check the PLC program; (2) If A91 alarming appears in the normal working mode of the machine, please check whether the PLC program frequently modifies the function code.

A-92 Low encoder battery voltage warning

(1) Fault

Servo drive panel display	Fault name
H-JI	Low encoder battery voltage warning

(2) Troubleshooting

Reason	Troubleshooting methods	Handling
Encoder battery voltage is less than 3.1V	Measure encoder battery voltage	■ Contact the manufacturer's technician to replace the new encoder battery.

A-93 encoder read-write verification exception is too frequent.

(1) Fault

Servo drive panel	Fault name
	Encoder read-write verification exception is too frequent.

(2) Troubleshooting

Reason	Troubleshooting	Handling
	■ Check for strong magnetic fields nearby	■ Eliminate the interference of strong magnetic field nearby.
External interference	■ Check whether there are sources of interference such as power supply inverter equipment nearby	■ Try to separate the strong and weak currents in the wiring. Make sure the motor and drive are well grounded and keep away from the power cables.
	■ Increase P0-31: Encoder read-write verification exception thr eshold setting	■ Eliminate the A93 alarming by increasing the exception threshold is regarded as a temporary solution. The disadvantage is that the motor may run in an unstable state.
Encoder fault	■Manually rotate the motor axis counterclockwise or clockwise to observe whether the monitoring value 201E-1E (electrical angle) changes regularly	■ If the value of 201E-1E (electric angle) changes abruptly or does not change, there may be a problem with the encoder itself. Please replace the motor or encoder.
Servo drive fault	■ Cross-verification: Use the normal motor and encoder cables to connect to the servo drive. If the servo drive still alarms, it is a servo drive fault.	■ Servo drive may be damaged, please contact the manufacturer's technician.

If P6-14 and P6-17 are set to other functions, such as instruction reversal or other DI functions, the use of touch probe function will not be affected. That is, when DI5 or DI6 is enabled, the touch probe function and the corresponding function code function will take effect together and do not affect each other.

11.1 Object Dictionary List

Object dictionary (Hex)	Name	Accessibility Data mapping Default		Data range	Unit	Data Type	Page number	
1000	Device type	RO	No	0x00020192	-	-	UDINT	112
1001	Error record	RO	No	0x00	-	-	USINT	112
1008	Device name	RO	No	-	-	-	STRING	112
1009	Manufacturer's hardware equipment	RO	No	-	-	-	STRING	112
100A	Manufacturer software version	RO	No	-	-	-	STRING	112
1018: 01	Vendor ID	RO	No	0x00000EFF	-	-	UDINT	112
1018: 02	Product code	RO	No	0x10003101	-	-	UDINT	112
1018: 03	Revision number	RO	No	0x0000001	-	-	UDINT	112
1018: 04	Serial number	RO	No	0x00001419	-	-	UDINT	112
1600: 01	First mapping object	RW	RPDO	0x60400010	-	-	UDINT	113
1600: 02	Second mapping object	RW	RPDO	0x607A0020	-	-	UDINT	113
1600: 03	Third mapping object	RW	RPDO	0x60B80010	-	-	UDINT	113
1600: 04	Fourth mapping object	RW	RPDO	0X60600008			UDINT	113
1701: 01	First mapping object	RW	RPDO	0x60400010	-	-	UDINT	113
1701: 02	Second mapping object	RW	RPDO	0x607A0020	-	-	UDINT	113
1701: 03	Third mapping object	RW	RPDO	0x60B80010	-	-	UDINT	113
1701: 04	Fourth mapping object	RW	RPDO	0x60600008	-	-	UDINT	113
1702: 01	First mapping object	RW	RPDO	0x60400010	-	-	UDINT	114
1702: 02	Second mapping object	RW	RPDO	0x607A0020	-	-	UDINT	114
1702: 03	Third mapping object	RW	RPDO	0x60FF0020	-	-	UDINT	114
1702: 04	Fourth mapping object	RW	RPDO	0x60710010	-	-	UDINT	114
1702: 05	Fifth mapping object	RW	RPDO	0x60600008	-	-	UDINT	114
1702: 06	Sixth mapping object	RW	RPDO	0x60B80010	-	-	UDINT	114
1702: 07	Seventh mapping object	RW	RPDO	0x607F0020	-	-	UDINT	114

			•					
1A00: 01	First mapping object	RW	TPDO	0x60410010	-	-	UDINT	114
1A00: 02	Second mapping object	RW	TPDO	0x60640020	-	-	UDINT	114
1A00: 03	Third mapping object	RW	TPDO	0x60B90010	-	-	UDINT	114
1A00: 04	Fourth mapping object	RW	TPDO	0x60BA0020	-	-	UDINT	114
1A00: 05	Fifth mapping object	RW	TPDO	0x60BC0020	-	-	UDINT	114
1A00: 06	Sixth mapping object	RW	TPDO	0x603F0010	-	-	UDINT	114
1A00: 07	Seventh mapping object	RW	TPDO	0x60610008	-	-	UDINT	114
1B01: 01	First mapping object	RO	TPDO	0x603F0010	-	-	UDINT	115
1B01: 02	Second mapping object	RO	TPDO	0x60410010	-	-	UDINT	115
1B01: 03	Third mapping object	RO	TPDO	0x60640020	-	-	UDINT	115
1B01: 04	Fourth mapping object	RO	TPDO	0x60770010	-	-	UDINT	115
1B01: 05	Fifth mapping object	RO	TPDO	0x60F40020	-	-	UDINT	115
1B01: 06	Sixth mapping object	RO	TPDO	0x60610008	-	-	UDINT	115
1C12: 01	Index of objects allocated by RPDO	RW	RPDO	0x1701	-	-	ARR	115
1C13: 01	Index of objects assigned by TPDO	RW	No	0x0001	-	-	ARR	115
1C32: 01	Synchronization type	RW	No	0x0002	-	-	UINT	116
1C32: 04	Synchronization types supported	RO	No	0x0005	-	-	UDINT	116
1C32: 05	Minimum cycle time	RO	No	0x0001E848	-	-	UINT	116
1C33: 01	Synchronization type	RW	No	0x0002	-	-	UINT	116
1C33: 04	Synchronization types supported	RO	No	0x0005	-	-	UDINT	116
1C33: 05	Minimum cycle time	RO	No	0x0001E848	-	-	UINT	116

Group 2000

Object dictionary (Hex)		Function code	Name Setting Valid time	Default	Range	Unit	Data		
Index	Sub-index	(Dec)		method					type
2000	04	P00-04	Rotation direction	Shutdown setting	Valid immediately	0	0 to 1	-	16 Bit
2000	09	P00-09	Braking resistance setting	Operation setting	Valid immediately	0	0 to 3	-	16 Bit
2000	0A	P00-10	External braking resistor resistance	Operation setting	Valid immediately	50	0~65535	Ω	16 Bit
2000	ОВ	P00-11	External braking resistor power	Operation setting	Valid immediately	100	0~65535	w	16 Bit
2000	1 E	P00-30	Shield multi-turn absolute encoder battery fault	Operation setting	Power-on again	0	0 to 1	-	16 Bit

	t dictionary (Hex)	Function code	Name	Setting method	Valid time	Default	Range	Unit	Data
Index	Sub-index	(Dec)		method					type
2001	0A	P01-10	MaxSpeedLimit	Operation setting	Valid immediately	3600	0~5000	rpm	16 Bit
2001	ОВ	P01-11	WarmSpeedTh	Operation setting	Valid immediately	3300	0~5000	rpm	16 Bit
2001	ОС	P01-12	PosSpeedTh	Operation setting	Valid immediately	3000	0~5000	rpm	16 Bit
2001	0D	P01-13	NegSpeedTh	Operation setting	Valid immediately	3000	0~5000	rpm	16 Bit
2001	0E	P01-14	ToqLimitSrc	Shutdown setting	Valid immediately	0	0 to 1	-	16 Bit
2001	OF	P01-15	PToqLim	Operation setting	Valid immediately	3000	0~3000	0.1%	16 Bit
2001	10	P01-16	NToqLim	Operation setting	Valid immediately	3000	0~3000	0.1%	16 Bit
2001	13	P01-19	ToqLimTime	Operation setting	Valid immediately	1000	0~65535	ms	16 Bit
2001	14	P01-20	SoftOverCurrentDt	Operation setting	Valid immediately	8	0~65535	-	16 Bit

2001	1E	P01-30	Delay from brake output ON to instruction reception	Operation setting	Valid immediately	250	0~500	ms	16 Bit
2001	1F	P01-31	In the static state, delay from the "brake output is OFF to the motor is not energized".	Operation setting	Valid immediately	150	1~1000	ms	16 Bit
2001	20	P01-32	Rotation status, when the brake output is OFF, the speed threshold.	Operation setting	Valid immediately	30	0~3000	rpm	16 Bit
2001	21	P01-33	Rotation status, delay from servo enable OFF to brake output OFF	Operation setting	Valid immediately	500	1~1000	ms	16 Bit

Group 2002

_	t dictionary (Hex)	Functio n code	News	Setting	Validaine	Defaul	Danas	I I with	Data
Inde x	Sub-inde x	(Dec)	Name	method	Valid time	t	Range	Unit	type
2002	01	P02-01	PosLoop1stGain	Operatio n setting	Valid immediatel y	400	0~6200	0.1Hz	16 Bit
2002	02	P02-02	SpdLoop1stGain	Operatio n setting	Valid immediatel y	65	0~35000	0.1Hz	16 Bit
2002	03	P02-03	SpdLoop1stIntgTime	Operatio n setting	Valid immediatel y	1000	100~6553 5	0.1ms	16 Bit
2002	09	P02-09	SpdFeedForwardGain	Operatio n setting	Valid immediatel y	0	0~1000	0.1%	16 Bit
2002	0A	P02-10	SpdFeedForwardFilte r	Operatio n setting	Valid immediatel y	50	0~10000	0.01m s	16 Bit
2002	ОВ	P02-11	ToqFeedForwardGain	Operatio n setting	Valid immediatel y	0	0~2000	0.1%	16 Bit
2002	ос	P02-12	ToqFeedForwardFilter	Operatio n setting	Valid immediatel y	50	0~10000	0.01m s	16 Bit

	t dictionary (Hex)	Function code	Name	Setting	Valid time	Default	Danga	Unit	Data
Index	Sub-index	(Dec)	Name	method	valid time	Default	Range	Unit	type
2003	01	P03-01	Load InerRatio	Operation setting	Valid immediately	300	100~10000	0.01	16 Bit
2003	02	P03-02	RigiditySel	Operation setting	Valid immediately	14	0~31	-	16 Bit
2003	03	P03-03	SelfAdjustMode	Operation setting	Valid immediately	0	0 to 2	-	16 Bit
2003	04	P03-04	InerIdOnline	Operation setting	Valid immediately	0	0 to 2	-	16 Bit
2003	05	P03-05	InerldCircle	Shutdown setting	Valid immediately	2	1 to 20	Circle	16 Bit
2003	06	P03-06	InerldMaxSpd	Shutdown setting	Valid immediately	1000	300 to 2000	rpm	16 Bit
2003	07	P03-07	IneridRollMode	Shutdown setting	Valid immediately	0	0 to 2	-	16 Bit
2003	08	P03-08	InerldWaitTime	Shutdown setting	Valid immediately	1000	300 to 10000	ms	16 Bit

	t dictionary (Hex)	Function code	Name	Setting	Valid time	Default	Range	Unit	Data
Index	Sub-index	(Dec)		method					type
2004	01	P04-01	PulseFilterType	Shutdown setting	Valid immediately	0	0 to 1	-	16 Bit
2004	02	P04-02	LowpassFilterTime	Shutdown setting	Valid immediately	0	0~1000	ms	16 Bit
2004	03	P04-03	AveragingFilterTime	Shutdown setting	Valid immediately	0	0 to 128	ms	16 Bit
2004	04	P04-04	TogFilterTime	Operation setting	Valid immediately	50	10~2500	0.01ms	16 Bit
2004	05	P04-05	NotchFilter1_Freq	Operation setting	Valid immediately	300	250 to 5000	Hz	16 Bit
2004	06	P04-06	NotchFilter1_Deep	Operation setting	valid immediately	100	0 to 100	-	16 Bit
2004	07	P04-07	NotchFilter1_Band	Operation setting	Valid immediately	4	0 to 12	-	16 Bit
2004	08	P04-08	NotchFilter2_Freq	Operation setting	Valid immediately	500	250 to 5000	Hz	16 Bit
2004	09	P04-09	NotchFilter2_Deep	Operation setting	Valid immediately	100	0 to 100	-	16 Bit

2004	0A	P04-10	NorthFilter2_Band	Operation setting	Valid immediately	4	0 to 12	-	16 Bit	
------	----	--------	-------------------	-------------------	----------------------	---	---------	---	-----------	--

Group 2005

_	t dictionary (Hex)	Function code	Name	Setting	Valid time	Default	Range	Unit	Data
Index	Sub-index	(Dec)		method					type
2005	10	P05-16	RotateSpdDtTh	Operation setting	Valid immediately	20	0~1000	rpm	16 Bit
2005	13	P05-19	SpdZeroOutTh	Operation setting	Valid immediately	10	0~6000	rpm	16 Bit
2005	17	P05-23	Probe filter 1 time parameters	Operation setting	Valid immediately	200	0~500	10ns	16 Bit
2005	18	P05-24	Probe filter 2 time parameters	Operation setting	Valid immediately	200	0~500	10ns	16 Bit
2005	19	P05-19	TouchprobeDiOn CompensationTime	Operation setting	Valid immediately	500	-10000 to10000	10ns	16 Bit
2005	1A	P05-25	TouchprobeDiOff CompensationTime	Operation setting	Valid immediately	500	-10000 to10000	10ns	16 Bit

	t dictionary (Hex)	Function code	Name	Setting	Valid time	Default	Range	Unit	Data
Index	Sub-index	(Dec)		method					type
2006	02	P06-02	Di1FunSel	Operation setting	Power-on again	0	0~32	-	16 Bit
2006	03	P06-03	Di1LogSel	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
2006	04	P06-04	Di1SrcSeL	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
2006	05	P06-05	Di2FunSel	Operation setting	Power-on again	2	0~32	-	16 Bit
2006	06	P06-06	Di2LogSel	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
2006	07	P06-07	Di2SrcSel	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
2006	08	P06-08	Di3FunSel	Operation setting	Power-on again	3	0~32	-	16 Bit
2006	09	P06-09	Di3LogSel	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
2006	0A	P06-10	Di3SrcSel	Operation setting	Valid immediately	0	0 to 1	-	16 Bit

				- p to: :					
2006	ОВ	P06-11	Di4FunSel	Operation setting	Power-on again	4	0~32	-	16 Bit
2006	ОС	P06-12	Di4LogSel	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
2006	0D	P06-13	Di4SrcSel	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
2006	0E	P06-14	Di5FunSel	Operation setting	Power-on again	0	0~32	-	16 Bit
2006	OF	P06-15	Di5LogSel	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
2006	10	P06-16	Di5SrcSel	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
2006	11	P06-17	Di6FunSel	Operation setting	Power-on again	0	0~32	-	16 Bit
2006	12	P06-18	Di6LogSel	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
2006	13	P06-19	Di6SrcSel	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
2006	1A	P06-26	Do1FunSel	Operation setting	Valid immediately	132	128 ~ 148	-	16 Bit
2006	1B	P06-27	Do1LogSel	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
2006	1C	P06-28	Do2FunSel	Operation setting	Valid immediately	130	128 ~ 148	-	16 Bit
2006	1D	P06-29	Do2LogSel	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
2006	1E	P06-30	Do3FunSel	Operation setting	Valid immediately	129	128 ~ 148	-	16 Bit
2006	1F	P06-31	Do3LogSel	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
2006	20	P06-34	ECAT forces DO to output state	Operation setting	Valid immediately	0	0 to 1	-	16 Bit

Group 200A

_	t dictionary (Hex)	Function code	Name	Setting	Valid time	Default	Range	Unit	Data
Index	Sub-index	(Dec)		method					type
200A	01	P10-01	SpdRefJOG	Operation setting	Valid immediately	100	0~3000	rpm	16 Bit
200A	02	P10-02	RstFuncFac	Shutdown setting	Valid immediately	0	0 to 1	-	16 Bit

200A	03	P10-03	ServoErrClear	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
200A	04	P10-04	MotOLProtect_Coef	Operation setting	Valid immediately	100	0 to 800	%	16 Bit
200A	05	P10-05	Motor type	Operation setting	Power-on again	0	0 to 65535	-	16 Bit
200A	06	P10-06	AbsEncRst	Shutdown setting	Valid immediately	0	0 to 65535	-	16 Bit
200A	07	P10-07	Manual setting motor code	Operation setting	Power-on again	0	0 to 1	-	16 Bit
200A	08	P10-11	Motor stall over temperature enable	Operation setting	Valid immediately	0	0 to 1	-	16 Bit

Group 200D

	t dictionary (Hex)	Function code	Name	Setting	Valid time	Default	Range	Unit	Data
Index	Sub-index	(Dec)		method					type
200D	01	P13-01	CommVdi_1	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
200D	02	P13-02	CommVdi_2	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
200D	03	P13-03	CommVdi_3	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
200D	04	P13-04	CommVdi_4	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
200D	05	P13-05	CommVdi_5	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
200D	06	P13-06	CommVdi_6	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
200D	ОВ	P13-11	CommVdo_1	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
200D	ОС	P13-12	CommVdo_2	Operation setting	Valid immediately	0	0 to 1	-	16 Bit
200D	0D	P13-13	CommVdo_3	Operation setting	Valid immediately	0	0 to 1	-	16 Bit

DI/DO channel function definition

		DI channel function	n definition	
Channel function code	Name	Function name	Description	Remark
0	-	OFF (not used)	-	-
1	S-ON	Servo enabled	Invalid: Servo motor enabled function prohibited; Valid: Servo motor power-on enabled.	-
2	A-CLR	Fault and warning cleared	Invalid: Do not reset faults or warnings Valid: Reset fault or warning.	-
3	РОТ	Forward drive prohibited	Invalid: Forward drive allowed; Valid: Forward drive prohibited.	-
4	NOT	Reverse drive prohibited	Invalid: Reverse drive allowed; Valid: Reverse drive prohibited.	-
6	CL	Clear deviation counter	Invalid: The position deviation is not cleared; Valid: Position deviation is cleared.	-
8	E-STOP	Emergency stop	Invalid: Position lock after zero speed stop; Valid: Do not affect the current running state.	-
26	HOMEORG	Origin signal	Invalid: Do not affect the current operation of servo motor Valid: Servo motor implements origin regression mode.	-

	DO channel function definition							
Channel function code	Name	Function name	Description	Remark				
128	-	OFF (not used)	-	-				
129	RDY	Servo ready	Servo is ready, and could receive S-ON signal. Invalid: Servo is not ready Valid: Servo is ready	-				
130	ALM	Fault signal	Valid when the fault is detected	-				
131	WARN	Warning signal	Valid when warning signals are output	-				
132	TGON	Rotation	When the absolute value of servo motor	-				

_=		Cn	apter 11 Appendix	
		detection	speed is higher than 2005-10 set value:	
			Invalid: The motor rotation detection signal is invalid	
			Valid: The motor rotation detection signal is valid	
			The signal output by the servo motor when it stops:	
133	ZSP	Zero speed signal	Invalid: Motor zero speed signal is invalid	-
			Valid: Motor zero speed signal is valid	
134	P-COIN	Positioning completed	In the position control mode, the absolute value of the position deviation meets the setting conditions of the object dictionary 6067h and 6068h, indicating that the	-
			servo positioning is completed.	
137	V-NEAR	Speed approach	-	-
			Invalid: The absolute value of torque command is less than the set value	
138	T-COIN	Torque arrival	Valid: The absolute value of torque	-
			command reaches the set value	
			The confirmation signal of torque limit.	
139	T-LIMIT	Torque limit	Invalid: Motor torque is not limited	-
			Valid: Motor torque is limited	
			The confirmation signal of speed limit in torque mode.	
140	V-LIMIT	Speed limited	Invalid: Motor speed is not limited	-
			Valid: Motor speed is limited	
			Outputting this signal indicates that the	To use this DO
141	BRK-OFF	Brake output	Outputting this signal indicates that the brake of the servo motor is released.	function, you need to power
				it on again
142	SRV-ST	Servo start state	Invalid: servo drive is in non-running mode	-
172	Sitt 31	Output	Valid: servo drive in running mode	
145	COM_VDO1	Communication VDO1 output	Use communication VDO	
146	COM_VDO2	Communication VDO2 output	Use communication VDO	-
147	COM_VDO3	Communication VDO3 output	Use communication VDO	
			207	

Group 201E

	dictionary Hex)	Monitoring Quantity	Monitoring name	name Category		Data type
Index	Sub-index	(Dec)		3 /	Unit	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
201E	01	U0-01	SrvStatus	Universal	-	16 Bit
201E	02	U0-02	SpeedDis	Universal	rpm	16 Bit
201E	03	U0-03	SpdCmd	Universal	rpm	16 Bit
201E	04	U0-04	PosCmdToSpd	Universal	rpm	16 Bit
201 E	05	U0-05	PulsErr	Universal	Equivalent pulse unit	32 Bit
201E	09	U0-09	PulsTotal	Universal	Instruction unit	32 Bit
201E	0D	U0-13	EncTotal_LowWord (Low 32 bits)	Universal	Encoder unit	32 Bit
201E	0F	U0-15	EncTotal_HighWord (High 32 bits)	Universal	Encoder unit	32 Bit
201E	11	U0-17	DiData1	Universal	-	16 Bit
201E	13	U0-19	DoData1	Universal	-	16 Bit
201E	14	U0-20	InerRatioReal	Universal	%	16 Bit
201E	17	U0-23	DisVibFreq	Universal	Hz	16 Bit
201E	18	U0-24	DisVibMag	Universal	rpm	16 Bit
201E	19	U0-25	PToqLimitDis	Universal	%	16 Bit
201E	1A	U0-26	NToqLimitDis	Universal	%	16 Bit
201E	1B	U0-27	PSpdLimitDis	Universal	rpm	16 Bit
201E	1C	U0-28	NSpdLimitDis	Universal	rpm	16 Bit
201E	1D	U0-29	MachineAngle	Universal	۰	16 Bit
201E	1E	U0-30	ElecAngle	Universal	۰	16 Bit
201E	1F	U0-31	DcBusVoltDisp	Universal	V	16 Bit
201E	20	U0-32	Temperature_IPM	Universal	°C	16 Bit
201E	21	U0-33	OutputPowerInst	Universal	w	16 Bit
201E	22	U0-34	OutputPowerAverage	Universal	w	16 Bit
201E	23	U0-35	HourTotalRun	Universal	h	16 Bit

Chapter 11 Appendix

			Chapter 11 Appendix			
201E	25	U0-37	MinTotalRun	Universal	min	16 Bit
201E	26	U0-38	SecTotalRun	Universal	s	16 Bit
201E	27	U0-39	ToqOutRate	Universal	%	16 Bit
201E	28	U0-40	HourCurrentRun	Universal	h	16 Bit
201E	2A	U0-42	MinCurrentRun	Universal	min	16 Bit
201E	2В	U0-43	SecCurrentRun	Universal	s	16 Bit
201E	2C	U0-44	DisPwrInst	Universal	w	16 Bit
201E	2 E	U0-46	DisPwrAvg	Universal	w	16 Bit
201E	30	U0-48	PwrUpCount	Universal	Times	16 Bit
201E	32	U0-50	MotoTotal_LowWord (lower 32 bits)	Universal	Circle	32 Bit
201E	33	U0-51	MotoTotal_HighWord (high 32 bits)	Universal	Circle	32 Bit
201E	35	U0-53	MotoModel	Universal	-	16 Bit
201E	36	U0-54	AbsEncin1Cycle	Universal	Encoder unit	32 Bit
201E	37	U0-55	AbsEncMultiTurn	Universal	Circle	32 Bit
201E	38	U0-56	EncTotal_CmdUnit	Universal	Instruction unit	32 Bit

Group 201F

_	dictionary Hex)	Monitoring Quantity	Monitoring name	Category	Unit	Data type
Index	Sub-index	(Dec)				
201F	01	U1-01	NowErrorCode	Warning	-	16 Bit
201F	02	U1-02	NowWarmCode	Warning	-	16 Bit
201F	03	U1-03	luWarmOccur	Warning	Α	16 Bit
201F	04	U1-04	IvWarmOccur	Warning	Α	16 Bit
201F	05	U1-05	UdcWarmOccur	Warning	V	16 Bit
201F	06	U1-06	T_IPMWarmOccur	Warning	°C	16 Bit
201F	07	U1-07	IqWarmOccur	Warning	%	16 Bit
201F	08	U1-08	IdWarmOccur	Warning	%	16 Bit
201F	09	U1-09	PosErrWarmOccur			32 Bit
					Units	
201F	0A	U1-10	SpdWarmOccur	Warning	rpm	16 Bit
201F	ОВ	U1-11	Time1WarmOccur	Warning	s	16 Bit
201F	ОС	U1-12	ErrCntCurRun	Warning	-	16 Bit
201F	0D	U1-13	WarmCntCurRun	Warning	-	16 Bit
201F	0E	U1-14	ErrorTotalCnt	Warning	-	16 Bit
201F	OF	U1-15	WarmTotalCnt	Warning	-	16 Bit
201F	10	U1-16	ErrCodeLast1st	Warning	-	16 Bit
201F	11	U1-17	ErrCodeLast2nd	Warning	-	16 Bit
201F	12	U1-18	ErrCodeLast3rd	Warning	-	16 Bit
201F	13	U1-19	ErrCodeLast4th	Warning	-	16 Bit
201F	14	U1-20	ErrCodeLast5th	Warning	-	16 Bit

201F	15	U1-21	WarmCodeLast1st	Warning	-	16 Bit
201F	16	U1-22	WarmCodeLast2nd	Warning	-	16 Bit
201F	17	U1-23	WarmCodeLast3rd	Warning	-	16 Bit
201F	18	U1-24	WarmCodeLast4th	Warning	-	16 Bit
201F	19	U1-25	WarmCodeLast5th	Warning	-	16 Bit

	dictionary Hex)	Monitoring Quantity	Monitoring name	Category	Unit	Data type
Index	Sub-index	(Dec)				
2020	01	U2-01	ProductSer	Device	-	16 Bit
2020	02	U2-02	Model1	Device	-	16 Bit
2020	03	U2-03	Model2	Device	-	16 Bit
2020	04	U2-04	FirewareVer	Device	-	16 Bit
2020	05	U2-05	HardwareVer	Device	-	16 Bit
2020	06	U2-06	ExFactoryYear	Device	Year	16 Bit
2020	07	U2-07	ExFactoryMonth	Device	Month	16 Bit
2020	08	U2-08	ExFactoryDay	Device	Day	16 Bit
2020	09	U2-09	DeviceSerNum1	Device	-	16 Bit
2020	0A	U2-10	DeviceSerNum2	Device	-	16 Bit
2020	ОВ	U2-11	DeviceSerNum3	Device	-	16 Bit
2020	ОС	U2-12	EtherCAT XML version number	Device	-	16 Bit
2020	0D	U2-13	Chip model (high byte)	Device	-	16 Bit
2020	0E	U2-14	Chip model (low byte)	Device	-	16 Bit
2020	OF	U2-15	CPU ID (high byte)	Device	-	16 Bit

2020	10	U2-16	CPU ID (low byte)	Device	-	16 Bit

Object dictionary (Hex)	Name	Accessibility	Data mapping	Default	Data range	Unit	Data type
603F	Error code	RO	TPDO	0	0~65535	-	16 Bit
6040	Control word	RW	TPDO	0	0~65535	-	16 Bit
6041	Status word	RO	TPDO	0	0~65535	-	16 Bit
605A	Quick-stop option code	RW	No	2	0 to 7	-	16 Bit
605D	Halt option code	RW	No	1	1 to 3	-	16 Bit
6060	Modes of servo operation	RW	RPDO	0	0~10	-	8 bit
6061	Modes operation	RO	TPDO	0	0~10	-	8 bit
6062	Position demand value	RO	TPDO	0	-	Instruction unit	32 Bit
6063	Position actual value	RO	TPDO	0	-	Encoder Units	32 Bit
6064	Position actual value	RO	TPDO	0	-	Instruction unit	32 Bit
6065	Following error window	RW	RPDO	524288	1 to (2 ³² -1)	Instruction unit	32 Bit
6067	Position window	RW	RPDO	0	0 to 2 ³²	Encoder Units	32 Bit
6068	Position window time	RW	RPDO	0	0~65535	1ms	16 Bit
606C	Velocity actual value	RW	TPDO	0	-	Instruction unit/s	32 Bit
606D	Velocity window	RW	RPDO	10	0~65535	rpm	16 Bit
606E	Velocity window time	RW	RPDO	0	0~65535	ms	16 Bit
6071	Target torque	RW	RPDO	0	-5000~5000	0.1%	16 Bit
6072	Max torque	RW	RPDO	5000	0~5000	0.1%	16 Bit
6074	Torque demand	RO	TPDO	0	-5000~5000	0.1%	16 Bit
6077	Torque actual value	RO	TPDO	0	-5000~5000	0.1%	16 Bit
607A	Target position	RW	RPDO	0	-2 ³¹ to (2 ³¹ -1)	Instruction unit	32 Bit

			11 Appendix				
607C	Home offset	RW	RPDO	0	-2 ³¹ to (2 ³¹ -1)	Instruction unit	32 Bit
607D: 01	Min position limit	RW	RPDO	-2 ³¹	-2 ³¹ to (2 ³¹ -1)	User position unit	32 Bit
607D: 02	Max position limit	RW	RPDO	-2 ³¹ -1	-2 ³¹ to (2 ³¹ -1)	User position unit	32 Bit
607E	Command polarity	RW	RPDO	0	0 ~ 255	-	8 bit
607F	Max profile velocity	RW	RPDO		0 to (2 ³² -1)	Instruction unit/s	32 Bit
6081	Profile velocity	RW	RPDO	0	0 to (2 ³² -1)	User position speed unit	32 Bit
6083	Profile acceleration	RW	RPDO	100	0 to (2 ³² -1)	Instruction unit/s²	32 Bit
6084	Profile deceleration	RW	RPDO	100	0 to (2 ³² -1)	Instruction unit/s²	32 Bit
6085	Quick stop deceleration	RW	RPDO	100	0 to (2 ³² -1)	User acceleratio n unit	32 Bit
6086	Motion profile type	RW	RPDO	0	-2 ¹⁵ to (2 ¹⁵ -1)	-	16 Bit
6087	Torque slope	RW	RPDO	232-1	0 to (2 ³² -1)	0.1%/s	32 Bit
6091: 01	Gear ratio	RW	RPDO	1	1 to (2 ³² -1)	-	32 Bit
6091: 02	Motor revolutions	RW	RPDO	1	1 to (2 ³² -1)	-	32 Bit
6098	Homing method	RW	RPDO	1	1 to 35	-	8 bit
6099: 01	Speed during search for switch	RW	RPDO	100	0 to (2 ³² -1)	Instruction unit/s	32 Bit
6099: 02	Speed during search for zero	RW	RPDO	100	0 to (2 ³² -1)	Instruction unit/s	32 Bit
609A	Home acceleration	RW	RPDO	100	0 to (2 ³² -1)	Instruction unit/s²	32 Bit
60B0	Position offset	RW	RPDO	0	-2 ³¹ to (2 ³¹ -1)	Instruction unit	32 Bit
60B1	Velocity offset	RW	RPDO	0	-2 ³¹ to (2 ³¹ -1)	Instruction unit/s	32 Bit
60B2	Torque offset	RW	RPDO	0	-5000~5000	0.1%	16 Bit
60B8	Touch probe function	RW	RPDO	0	0~65535	-	16 Bit
60B9	Touch probe status	RO	TPDO	0	0~65535	-	16 Bit

			TT //pciraix				
60BA	Touch probe Pos1 Pos Value	RO	TPDO	0	-2 ³¹ to (2 ³¹ -1)	Instruction unit	32 Bit
60BB	Touch Probe Pos1 Neg Value	RO	TPDO	0	-2 ³¹ to (2 ³¹ -1)	Instruction unit	32 Bit
60BC	Touch Probe Pos2 Pos Value	RO	TPDO	0	-2 ³¹ to (2 ³¹ -1)	Instruction unit	32 Bit
60BD	Touch Probe Pos2 Neg Value	RO	TPDO	0	-2 ³¹ to (2 ³¹ -1)	Instruction unit	32 Bit
60E0	Forward Direction Torque Limit Value	RW	RPDO	5000	0~5000	0.1%	16 Bit
60E1	Reverse Direction Torque Limit Value	RW	RPDO	5000	0~5000	0.1%	16 Bit
60F4	Following error actual value	RO	RPDO	-	-	Instruction unit	32 Bit
60FC	Position demand value	RO	TPDO	-	-	Encoder Units	32 Bit
60FD	Digital Input	RO	PDO	-	0 to 2 ³²	-	32 Bit
60FE:01	Digital Output Dictionary	RW	RPDO	0	0~65535	-	32 Bit
60FE:02	Digital Output Dictionary	RW	RPDO	0	0~65535	-	32 Bit
60FF	Profile velocity	RW	RPDO	0	-	Instruction unit/s	32 Bit
6502	Support servo operation mode	RO	TPDO	-	-	-	32 Bit
· · · · · · · · · · · · · · · · · · ·	·			· ·			

11.2 List of Fault and Warning Codes

Clearable: the panel can stop the fault display state by giving a "clear signal".

Stop immediately: The control action state stops immediately.

Code	Content	Cleanable	Immediately Stop	Code	Content	Cleanable	Immediately Stop
Er.01	Parameter damage		0	Er.34	Motor overload protection	•	0
Er.02	Parameter storage error		0	Er.35	Electronic gear ratio exceeds limit	~	0
Er.03	ADC reference source error		0	Er.36	Position deviation is too large	~	0
Er.04	AD current sampling conversion error		0	Er.37	Abnormal torque saturation	•	0
Er.05	Abnormal FPGA communication		0	Er.38	Main circuit electrical phase loss	•	0
Er.06	Wrong FPGA program version		0	Er.39	Emergency stop	•	0
Er.07	Clock exception		0	Er.40	Encoder battery failure	•	0
Er.09	Abnormal network status switching	•	0	Er.41	Motor (encoder) over temperature	\	0
Er.10	Loss of synchronization	•	0	Er.42	Encoder write failure	•	0

				.I Appendix			
Er.11	Unburned XML configuration file	V	0	Er.44	Back to original timeout fault	•	0
Er.12	Network initialization failed	V	0	Er.60	ADC conversion is not completed		0
Er.13	Synchronization period setting error	V	0	Er.61	Internal software fault		0
Er.14	Synchronization period error is too large	V		Er.62	Internal software fault		0
Er.20	Overcurrent		0	Er.63	Internal software fault		0
Er.21	Main power supply is undervoltage	V	0	Er.64	Internal software fault		0
Er.22	Main power supply is overvoltage	V	0	Er.65	Internal software fault		0
Er.23	Braking resistor is not connected	V	0	A-81	Over speed alarm	•	
Er.24	The braking resistor is turned on abnormally		0	A-82	Overload	V	
Er.25	Wrong motor model	•	0	A-83	Braking resistor is over temperature or overload	V	
Er.26	Wrong motor model		0	A-84	Parameter modification that needs to be powered on	V	

				1 Appendix			
					again		
Er.27	Encoder is disconnected	•	0	A-88	Main circuit instantaneous power failure	\	
Er.28	Encoder Z pulse is lost		0	A-89	Duplicate DI port configuration	V	
Er.30	Encoder UVW signal error		0	A-90	Duplicate DO port configuration	✓	
Er.31	Power line disconnection	•	0	A-91	Parameter modification is too frequent	V	
Er.32	Exceeding motor maximum speed		0	A-92	Encoder battery voltage low warning	>	
Er.33	Power module is over temperature	V	0	A-93	Encoder read and write check is abnormal and frequency is too high	>	

11.3 Wire

Table 11-1 Appearance of servo motor power cable

Wire type	Cable length L	Appearance drawing of cable
		L L
P-Z3O1-R4M-3MX4	3 meters	
P-Z3O1-R4M-5MX4	5 meters	Label
P-Z3O1-R4M-10MX4	10 meters	Suitable for [VD3E type A drive], which can connect [60/80 flange conductor
		motor]
P-U3O1-R4M-3MX4	3 meters	
P-U3O1-R4M-5MX4	5 meters	Label
P-U3O1-R4M-10MX4	10 meters	Suitable for [VD3E type B drive], which can connect [80 flange conductor motor]
P-Z3O1-H28J4M-3MX4	3 meters	<u>L</u> 4
P-Z3O1-H28J4M-5MX4	5 meters	
P-Z3O1-H28J4M-10MX 4	10 meters	Suitable for [VD3E type A drive], which can connect [110/130 flange conductor motor]
P-U3O1-H28J4M-3MX4	3 meters	
P-U3O1-H28J4M-5MX4	5 meters	Label
P-U3O1-H28J4M-10MX 4	10 meters	
		Suitable for [VD3E type B drive], which can connect [110/130 flange





Table 11-2 Appearance diagram of servo encoder cable

Wire type	Cable length L	Appearance drawing of cable
E-J1394-R9M-3MX7-A1	3 meters	ledl led
E-J1394-R9M-5MX7-A1	5 meters	Label
E-J1394-R9M-10MX7-A	10	Soitable for NP35 and a drive landish are seen at 150 (00 flames and at the
1	meters	Suitable for [VD3E series drive], which can connect [60/80 flange conductor motor (multi-turn encoder)]
E-J1394-MC7S-3MX5-A	3 meters	
E-J1394-MC7S-5MX5-A	5 meters	Label
E-J1394-MC7S-10MX5-A	10	
	meters	Suitable for [VD3E series drive], which can connect [60/80 flange connector motor (single-turn encoder)]



11.4 Correspondence of International Standards

The products meet the requirements of EMC standards:

Certification information

Certification name	Certification symbol	Instruction Name		Standards	
CE certification		EMC Directive	2014/30/EU	Servo drive Servo motor	EN 61800-3 C2

The VD3E series drives comply with European EMC Directive 2014/30/EU and meet the requirements of EN 61800-3 C2 under the following conditions.

The recommended external EMC filter should be installed at the input terminal of the drive, and the shielded wire should be selected at the output terminal. Ensure the reliable grounding of the filter and 360° overlapping grounding of output line shielding. For the selection of EMC filters, check "11.4.1 Hardware Requirements (1) EMC Filter Recommendations" below Table 11-3 Recommended Manufacturers and Models of EMC Input Filters"";

The input terminal needs to be equipped with AC inductors that meet the requirements;

Shielded cable shall be used for driving cable between drive and motor. Please refer to below for cable selection and installation: "11.4.1 Hardware Requirements" [(3) Cable requirements and wiring]";

Install the drive and wiring according to the recommended cable wiring method as below: "11.4.1 Hardware Requirements" [(3) Cable requirements and wiring]";

Install a common mode filter if necessary.

11.4.1 Hardware requirements

(1) EMC filter recommendation

Recommended model: SCHAFFNER models are recommended as shown in the following table:

Table 11-3 Recommended manufacturers and models of EMC input filters

Series	Drive model	Rated input current	Filter model	
Series	Direct model	IN	SCHAFFNER	
VD3E-0xxSA10	;			
	VD3E-003SA1G	0.9	FN 2090-1-06	
Single-phase	VD3E-010SA1G	3.6	FN 2090-4-06	
220V	VD3E-014SA1G	6.7	FN 2090-8-06	
	VD3E-016SA1G	13.4	FN 2090-16-06	

VD3E-021SA1G	20	FN 2090-20-06
VD3E-016SA1G	7.7	FN 3258-16-44
VD3E-021SA1G	11.9	FN 3258-16-44
VD3E-030SA1G	13.4	FN 3258-16-44
VD3E-021TA1G	8.6	FN 3258-16-44
	VD3E-016SA1G VD3E-021SA1G VD3E-030SA1G	VD3E-016SA1G 7.7 VD3E-021SA1G 11.9 VD3E-030SA1G 13.4

Applicable to European EMC directives.

Servo drives and motors cannot be used in ordinary families or connected to low-voltage public communication circuits. The drive may send radio frequency if the similar loops above is connected.

For its application to EMC directives, please use noise filters and surge absorbers and ferrite magnetic rings. As for the EMC Directive's applies on machinery and equipment, and the final mechanical equipment for assembling drives and motors must be confirmed.

(2) Requirements for AC input inductors

The AC input inductor is mainly used to reduce the filtering in the input current. As an optional accessory, it should be external connect when the application environment has high harmonic requirements.

(3) Cable requirements and wiring

1 Cable requirements

In order to meet the EMC requirements of CE marking, shielding lines with shielding layer must be used. Shielding line has three phase conductors and four phase conductors. If the conductivity of the shielding line layer cannot meet the requirements, a separate PE wire needs to be added. Or shielding line with four phase conductors, one of which is PE wire. In order to effectively suppress the emission and conduction of radio frequency interference, the shielding layer of shielding wire is composed of coaxial copper braided tape. In order to increase shielding effectiveness and electrical conductivity, the braiding density of shielding layer should be greater than 90%.

2 Wiring requirements

Motor cables and their PE shielded wire (twister shield) should be as short as possible to reduce electromagnetic radiation and stray current and capacitive current outside the cable. If the length of motor cable exceeds 100m, it is required to install output filter or dv/dt inductor. It is recommended that all control cables should be shielding lines. Motor cable wiring must be far

away from other cable wiring. Motor cables of several drives can be wired side by side. It is recommended to put the motor cable, input power cables and control cables respectively distributed in different troughs. In order to avoid electromagnetic interference caused by rapid changes in the output voltage of the drive, long-distance side-by-side routing of motor cables and other cables should be avoided.

When the control cable must pass through the power cable, ensure that the included angle between the two cables is kept at 90 degrees as much as possible. Do not put other cables through the drive. The power input and output lines of the drive and weak current signal lines (such as control lines) should not be arranged in parallel as far as possible, but vertically when conditions permit. Cable troughs must be well connected and well grounded. Aluminum trough can be used to improve equipotential. Filters, drives and motors should be well overlapped with the system (machinery or device), and spraying protection should be done in the installation part, and conductive metals should be fully contacted.

(3) Leakage current suppression

Because the output of the drive is a high-speed pulse voltage, high-frequency leakage current will be generated. Drive equipment will generate DC leakage current in protective conductor, and B-type (delay type) leakage protection circuit breaker must be used. If it's necessary to install multiple drives, each drive shall be provided with a leakage protection circuit breaker.

11.4.2 Recommendations for common EMC issues

Drive products belong to strong interference equipment. When there are problems in wiring and grounding during use, interference may still occur. When interference with other equipment occurs, the following methods can be adopted for rectification.

Table 11-4 Common EMC interference problems and rectification methods

Interference states	Rectification method
	◆ Reduce the carrier frequency without affecting the performance;
	◆Reduce the length of driving line;
	◆Add a magnet ring to the input drive;
Switch trip of leakage protection circuit breaker	◆If the power-on trips instantly, it is necessary to disconnect the large ground current at the input terminal; (Disconnect the ground of the external or internal filter and the ground terminal of the input port to
	the ground y capacitor)
	♦In case of running or enabling trip, leakage current suppression
	measures should be installed at the input terminal. (Leakage current

	filter, safety capacitor and magnet ring, magnet ring)
	◆The motor shell is connected to the PE end of the drive;
Interference caused by drive	◆The PE terminal of the drive is connected to the power grid PE;
running	♦Add a magnet ring to input power;
	◆Power supply or magnet ring is added to the interfered signal port;
	◆Add additional common ground connection between devices.
	◆Connect the motor shell to the PE end of the drive;
	◆Connect the PE terminal of the drive to the power grid PE;
	◆Add a magnet ring to input power line;
	◆Add matching resistors to the communication line source and load terminal;
Communication interference	◆ Differential line of communication line adds external communication common ground line;
	◆Shielded wires for communication lines, and the shielding layer is connected to the communication common place;
	♦ Multi-node communication wiring needs daisy chain, and the length of branch line is less than 30cm.
	♦ Low-speed DI increases capacitance filtering, and the maximum value
I/O interference	is recommended to 0.1 uF;
	◆AI increases capacitance filtering, and the recommended maximum



Notice

- ♦ This series of products should strictly comply with EMC-related electrical installation requirements in the manual to meet EMC certification standards;
- ◆When the CE marking is attached to the equipment or device with this series of products, please confirm whether the final equipment or device meets the European unified standard, and the relevant responsibility shall be borne by the customer of the final assembled product;
- ◆ For more product certification information, please consult our agent or sales person in charge.